

Fixture fader labels — Mantra Lite 1-24 · Wing 1 25-36 · Wing 2 37-48

Unchanged from R8: R13 keeps the venue patch. Cut on the lines and stick one label above each fixture fader. Numbers = Mantra fixture numbers. Colour bar = fixture type.

CONSOLE · 1-12

1 · FOH FACE 1 DSR·HL C42	2 · FOH FACE 1 DSR·HR C42	3 · FOH FACE 2 DSC·HL C42	4 · FOH FACE 2 DSC·HR C42	5 · FOH FACE 3 DSL·HL C42	6 · FOH FACE 3 DSL·HR C42	7 · FOH SP1 ARIEL C42	8 · FOH SP2 SPIRIT C42	9 · LX1 SP3 OCTAVIA C42	10 · LX1 SP4 SHELL C42	11 · LX1 V1 DAME C42	12 · LX1 V2 FLANDERS C42
--	--	--	--	--	--	------------------------------------	-------------------------------------	--------------------------------------	-------------------------------------	-----------------------------------	---------------------------------------

CONSOLE · 13-24

13 · LX1 WASH DSR ZOOM	14 · LX1 WASH DSC ZOOM	15 · LX1 WASH DSL ZOOM	16 · LX1 WASH CSR ZOOM	17 · LX1 WASH CSC ZOOM	18 · LX1 WASH CSL ZOOM	19 · LX2 V3 THEODORE ZOOM	20 · LX2 V4 MARINA ZOOM	21 · SR BOOM HIGH SIDE ZOOM	22 · SL BOOM HIGH SIDE ZOOM	23 · LX2 BACK DSR COB	24 · LX2 BACK DSC COB
-------------------------------------	-------------------------------------	-------------------------------------	-------------------------------------	-------------------------------------	-------------------------------------	--	--------------------------------------	--	--	------------------------------------	------------------------------------

WING 1 · 25-36

25 · LX2 BACK DSL COB	26 · LX2 BACK CSR COB	27 · LX2 BACK CSC COB	28 · LX2 BACK CSL COB	29 · SR BOOM MID SIDE COB	30 · SR BOOM SHIN COB	31 · SL BOOM MID SIDE COB	32 · SL BOOM SHIN COB	33 · LX2 PIXBAR 1 PIX	34 · LX2 PIXBAR 2 PIX	35 · LX2 PIXBAR 3 PIX	36 · LX2 PIXBAR 4 PIX
------------------------------------	------------------------------------	------------------------------------	------------------------------------	--	------------------------------------	--	------------------------------------	------------------------------------	------------------------------------	------------------------------------	------------------------------------

WING 2 · 37-48

37 · LX2 PIXBAR 5 PIX	38 · LX2 PIXBAR 6 PIX	39 · LX2 BACK CENTRE COB	40 · FLOOR US HAZER HAZE	41 · FOH SR PINSPOT (opt) PIN	42 · FOH SL PINSPOT (opt) PIN	43 spare	44 spare	45 spare	46 spare	47 spare	48 spare
------------------------------------	------------------------------------	---------------------------------------	---------------------------------------	--	--	--------------------	--------------------	--------------------	--------------------	--------------------	--------------------

Lightsky C42 (U2) = yellow · Tour Pro Zoom = blue · TourCOB PAR = orange · PixBar = violet · hazer / pinspots = grey. HL/HR = focused from house left / right. SP = character special, V = voice-transfer special. #41-42 pinspots only if the mirror ball is used; 43-48 spare. Confirm #38 PixBar 6 and #39 TourCOB back centre exist on the rig.

Playback labels — 10 playback faders, one row per page

R13 splits the show: P2 Act One, P3 Act Two, P4 songs. QLab picks the right memory; keep the P2 row on the desk in Act One, swap to P3 at the interval, and keep P4 handy for song recovery. Blank cells are empty memories.

PAGE 1 – VENUE / RIG BASE

P1 · M1 STAGE WORK	P1 · M2 FULL WHITE	P1 · M3 WARM STAGE	P1 · M4 COOL STAGE	P1 · M5 BLUE STAGE	P1 · M6 RED STAGE	P1 · M7	P1 · M8	P1 · M9 PIXBAR WASH	P1 · M10 CURTAIN CALL
------------------------------	------------------------------	------------------------------	------------------------------	------------------------------	-----------------------------	---------	---------	-------------------------------	---------------------------------

PAGE 2 – ACT ONE · performance

P2 · M1 Q1-11 PRESHOW → ARIEL UPSET 11 cues	P2 · M2 Q12-17 SINGING LESSON → BLACKOUT 8 cues	P2 · M3 Q18-27.5 SHIP · STORM 15 cues	P2 · M4 Q28-30.5 SHORE · DUET 5 cues	P2 · M5 Q31-37 BAR · TRANSFORM · ACT 1 END 10 cues	P2 · M6 Q38 INTERVAL 1 cues	P2 · M7	P2 · M8	P2 · M9 WORK / FOCUS	P2 · M10 SAFE LIGHT
--	--	--	---	---	--	---------	---------	--------------------------------	-------------------------------

PAGE 3 – ACT TWO · performance

P3 · M1 Q39-44 PALACE 7 cues	P3 · M2 Q45-49 JELLYFISH 7 cues	P3 · M3 Q50-58.5 LAIR · VOICE · HAYWIRE 12 cues	P3 · M4 Q59-59.7 DRY LAND 3 cues	P3 · M5 Q60-63.5 WEDDING 6 cues	P3 · M6 Q64-65 BOWS · END 2 cues	P3 · M7	P3 · M8	P3 · M9	P3 · M10
---	--	--	---	--	---	---------	---------	---------	----------

PAGE 4 – SONGS · performance

P4 · M1 S1 ROCK LOBSTER 7 cues	P4 · M2 S2 FEELING GOOD 6 cues	P4 · M3 S3 PART OF YOUR WORLD 7 cues	P4 · M4 S4 WELLERMAN 7 cues	P4 · M5 S5 TIME OF MY LIFE 8 cues	P4 · M6 S6 CRAB RAVE 7 cues	P4 · M7 S7 JELLYFISH CHORUS 4 cues	P4 · M8 S8 POOR UNFORTUNATE SOULS 7 cues	P4 · M9 S9 ABSOLUTELY EVERYBODY 7 cues	P4 · M10 S10 HE'S A PIRATE 6 cues
---	---	---	--	--	--	---	---	---	--

PAGE 5 – FX / CHASES

P5 · M1 WARM CHASE 6 steps @150 BPM	P5 · M2 COOL CHASE 6 steps @144 BPM	P5 · M3 PARTY CHASE 8 steps @168 BPM	P5 · M4 HAZE #40	P5 · M5 HAYWIRE chase 5 steps @120 BPM	P5 · M6 JELLY PULSE	P5 · M7	P5 · M8	P5 · M9	P5 · M10
--	--	---	----------------------------	---	-------------------------------	---------	---------	---------	----------

PAGE 6 – LOOK LIBRARY

P6 · M1 M01 BLACKOUT	P6 · M2 M02 HOUSE	P6 · M3 M03 UNDERWATER	P6 · M4 M04 COMEDY	P6 · M5 M05 ROYAL	P6 · M6 M06 SHIP	P6 · M7 M07 SHORE	P6 · M8 M08 STORM	P6 · M9 M09 LIGHTNING	P6 · M10 M10 MAGIC
--------------------------------	-----------------------------	--------------------------------------	------------------------------	-----------------------------	----------------------------	-----------------------------	-----------------------------	---------------------------------	------------------------------

PAGE 7 – LOOK LIBRARY

P7 · M1 M11 LAIR	P7 · M2 M12 VOICE SHELL	P7 · M3 M13 JELLYFISH	P7 · M4 M14 DRYLAND	P7 · M5 M15 WEDDING	P7 · M6 M16 BOWS	P7 · M7 M17 SAFE LIGHT	P7 · M8	P7 · M9	P7 · M10
----------------------------	-----------------------------------	---------------------------------	-------------------------------	-------------------------------	----------------------------	----------------------------------	---------	---------	----------

P8 · M1 BACKUP SHOW 153 steps	P8 · M2	P8 · M3	P8 · M4	P8 · M5	P8 · M6	P8 · M7	P8 · M8	P8 · M9	P8 · M10
--	---------	---------	---------	---------	---------	---------	---------	---------	----------

Desk reminder strips, page tabs and spares

Stick a strip along the top of the Mantra, above the screen or playbacks.

QLab fires every cue · this desk is the backup · SAFE LIGHT = P2 · M10 · P2 Act One · P3 Act Two · P4 songs · P5 FX · flash returns are automatic from QLab

If QLab fails: pick the scene memory on P2/P3 (song → P4) › Next Cue · press Next Cue again after each flash · Q57 HAYWIRE = P5 M5 on, off at Q57b · O = All Cues Off · A L = Clear All · T S = Save

QLab fires every cue · this desk is the backup · SAFE LIGHT = P2 · M10 · P2 Act One · P3 Act Two · P4 songs · P5 FX · flash returns are automatic from QLab

If QLab fails: pick the scene memory on P2/P3 (song → P4) › Next Cue · press Next Cue again after each flash · Q57 HAYWIRE = P5 M5 on, off at Q57b · O = All Cues Off · A L = Clear All · T S = Save

PAGE TABS – stick beside the Page button

P1 VENUE	P2 ACT ONE	P3 ACT TWO	P4 SONGS	P5 FX / CHASE	P6 LOOKS M01-M10	P7 LOOKS M11-M17	P8 BACKUP 153	P9-10 FREE
-----------------	-------------------	-------------------	-----------------	----------------------	-----------------------------	-----------------------------	----------------------	-------------------

WING 1 PLAYBACKS – write-in (unused in this show)

M1	M2	M3	M4	M5	M6	M7	M8	M9	M10
----	----	----	----	----	----	----	----	----	-----

WING 2 PLAYBACKS – write-in (unused in this show)

M1	M2	M3	M4	M5	M6	M7	M8	M9	M10
----	----	----	----	----	----	----	----	----	-----

SPARE BLANK LABELS – write in by hand

--	--	--	--	--	--	--	--	--	--