



JOB SAFETY ANALYSIS (JSA)

Wet Utilities Installation — Sanitary Sewer

PROJECT NAME:	[Placeholder]	DATE:	[Placeholder]
PROJECT #:	[Placeholder]	PHASE:	[Placeholder]
WORK ACTIVITY:	Sanitary Sewer Installation — Trench Excavation, Gravity Pipe Laying, Manhole Setting, Service Connections, Testing & Backfill		PREPARED BY: Safety Manager
COMPANY:	Wicker Construction Inc.	JSA TYPE:	Wet Utility Installation

SCOPE OF WORK

This JSA covers all wet-utility installation activities for the Sanitary Sewer system, including: trenching and excavation, dewatering, bedding, pipe installation, structure/valve/hydrant setting, tie-ins, testing, backfill, and surface restoration. It is written for field execution and must be reviewed with the crew before work begins.

This JSA is one of five (5) wet-utility JSAs: Storm Sewer, Sanitary Sewer, Industrial Waste / NCCW / INDW, Domestic Water, and Fire Water.

SCHEDULE

MEILESTONE	DATE	DESCRIPTION / POTENTIAL IMPACTS
Predecessor Task	[Date]	Site clearing, erosion control, and access road preparation complete.
Start Date	[Date]	Begin trench excavation at upstream / building connection. Delays impact downstream gravity sequencing.
Milestone #1	[Date]	First manhole set and accepted by engineer. Initial run of pipe installed and surveyed.
Milestone #2	[Date]	Trench box advanced to mid-run. Dewatering operational if groundwater encountered.
Milestone #3	[Date]	All pipe joints complete. Third-party mandrel/deflection and low-pressure air test scheduled and passed.
Milestone #4	[Date]	All manholes set, frames/covers installed, channels grouted. CCTV inspection scheduled.
Milestone #5	[Date]	Final backfill and compaction complete. Compaction test reports submitted to engineer.
End Date	[Date]	Punch-list resolved. As-builts submitted. Site restored to pre-construction condition.
Successor Task	[Date]	Surface restoration, paving, or connection to existing sanitary system / lift station. Confirm SAN building connection (ref. SAN-54).

CREW & CONTACTS		
TRADE PARTNER CONTACTS	NAME	PHONE NUMBER
FOREMAN:	[Name]	[Phone]
SUPERINTENDENT:	[Name]	[Phone]
SAFETY PROFESSIONAL:	[Name]	[Phone]
WICKER SUPERINTENDENT:	[Name]	[Phone]
WICKER SAFETY PROFESSIONAL:	[Name]	[Phone]
CREW SPONSOR:	[Name]	[Phone]

REQUIRED CREW	PRODUCTIVITY REQUIREMENTS	WORK HOURS
• 1 × Foreman • 1 × Superintendent • 2 × Equipment Operators (Excavator) • 1 × Equipment Operator (Loader/Compactor) • 2 × Laborers (Trench) • 1 × Pipe Layer / Grade Setter • 1 × Truck Driver (Spoils Haul-off) • 1 × Spotter / Flagger • 1 × Safety Observer (excavation > 4 ft)	• Pipe Installation: 80–120 LF/day • Manhole Setting: 1–2 structures/day • Backfill & Compaction: Per lift per spec • Compaction Tests: Every 200 LF and each lift • CCTV / Air / Mandrel: Coordinated with owner	• Standard: [Start] – [End] • Monday – Friday • Saturday as required • Overtime subject to owner approval • No work during lightning standdown

MATERIALS		
MATERIAL	QTY	NOTES / STORAGE REQUIREMENTS
PVC Gravity Sewer Pipe (SDR per plan / spec)	Per plan LF	Store on flat, chocked ground. Protect PVC from UV. Handle per mfr. instructions.
Precast Concrete Manholes (48" / 60" dia. per plans)	Per plan EA	Delivered day of install. Set on firm bedding away from excavation edge.
Manhole Frame & Cover (HD, sanitary-marked, city standard)	Per plan EA	Verify casting weight / load rating. Vented vs. sealed per spec. Store on pallets.
Crushed Stone / Gravel Bedding (per spec)	Per plan TN	Stockpile in designated laydown area. Cover if rain expected.
Select Backfill (native or imported per spec)	Per plan CY	Verify approval with geotechnical engineer before placing.
Manhole Steps (OSHA-compliant, drop-in or cast-in)	Per MH EA	Install per manufacturer spacing requirements.
Joint Lubricant / Gaskets (mfr. supplied)	Per joint	Keep shaded. Do not freeze. Use only manufacturer-approved lubricant.
Non-Shrink Grout (manhole channel / inverts)	As needed	Keep dry until use. Dispose of unused mixed material per SDS.
Manhole Rubber Boot Connectors / Kor-N-Seal	Per connection	Match boot size to pipe OD and manhole opening. Store dry.

Service Wyes / Tees & Cleanouts (per plan)	Per plan EA	Verify connection size and invert. Mark and protect for future connection.
--	-------------	--

TOOLS / EQUIPMENT

TOOL / EQUIPMENT	QTY	NOTES
Excavator — Long Reach (Cat 320 or equiv., trench bucket)	1	Inspect boom, bucket teeth, and hydraulic lines daily.
Excavator — Standard (Cat 308 or equiv., for backfill / setting)	1	Used for precise backfill placement and trench box advancement.
Steel Trench Box / Trench Shield (rated for excavation depth)	1 set	Inspect spreaders and wales daily. Competent Person required.
Vibratory Plate Compactor (walk-behind, gas)	2	Use for compacting lifts adjacent to pipe. Do not compact directly on pipe.
Dewatering Pump (submersible, 3" or 4" discharge)	2	Discharge per permit — no direct surface discharge without approval.
Pipe Laser / Grade Laser (Topcon or equiv.)	1	Calibrate daily. Verify against benchmark.
Certified Lifting Bail / Slings (rated for heaviest pick)	2	Inspect before each lift. Match rating to heaviest section / pipe.
Confined Space Entry Kit (4-gas monitor, tripod, SRL, harness, winch)	1 set	Required when personnel enter any structure or excavation >4 ft. Calibrate daily.
Wheel Loader (for bedding / backfill material staging)	1	Used to move material from stockpile to trench area.
Dump Trucks (spoils haul-off)	2–3	Coordinate with traffic control. Cover loads leaving site.

HIGH-RISK ACTIVITY / ERROR-LIKELY

Attach specialized plans to the end of this document

HIGH-RISK ACTIVITY	SPECIAL PLAN REQUIRED?
Excavation / Trenching exceeding 5 ft depth — Cave-in / Engulfment hazard	YES ☒ NO ☐
Confined Space Entry — Manhole and deep trench atmospheric hazards (H ₂ S, O ₂ deficiency, methane)	YES ☒ NO ☐
Biological / sewage exposure during tie-ins to live / existing sanitary systems	YES ☒ NO ☐
Dewatering Operations — Groundwater infiltration, trench instability, discharge permit compliance	YES ☒ NO ☐

REQUIRED PERMITS

REQ'D	PERMIT / AUTHORIZATION
☐	Daily Dig / Excavation Permit (signed by Wicker Superintendent before any soil disruption)
☐	Confined Space Entry Permit (any structure or excavation >4 ft)
☐	Hot Work Permit (cutting / welding / grinding — if applicable)

☐	Dewatering / Stormwater Discharge Permit ([Permit No. / Agency])
☐	Line Breaking / Energy Isolation (LOTO) Permit for tie-ins to live systems
☐	Locate / One-Call (811) Ticket — current and valid before excavation
☐	Crane / Critical Lift Permit (if pick exceeds standard rigging plan)
☐	Other (project-specific): _____

EMERGENCY RESPONSE & STOP-WORK AUTHORITY

STOP-WORK AUTHORITY: Every worker has the unconditional right and duty to STOP WORK for any unsafe condition — trench instability, atmospheric alarm, utility strike, rigging concern, equipment fault, weather, or any uncertainty. Work does not resume until the condition is corrected and the Competent Person / Wicker Superintendent authorizes restart. No retaliation. Zero-incident mindset.

EMERGENCY PROCEDURES:

- Call 911. State exact site location / address: [Enter address & gate]. Send a runner to direct EMS.
- Notify Wicker Superintendent and Wicker Safety immediately: [Phone].
- Muster Point: [Enter location]. Account for all personnel. Report headcount to Superintendent.
- First Aid / AED location: [Enter]. Nearest hospital: [Enter name, address, phone].
- Trench collapse / engulfment: Do NOT enter to rescue. Call 911 / trained rescue. Shut down equipment, secure area.
- Atmospheric alarm or confined-space emergency: Entrant exits; attendant initiates non-entry rescue; never enter to rescue.
- Utility strike (gas/electric/comm): Stop work, evacuate, keep clear, call 911 and the utility owner. No equipment movement.
- Spill / release: Stop source if safe, deploy spill kit / containment, report to Wicker Safety and per permit.
- Severe weather / lightning: Standdown at 15 miles; resume 30 min after last strike. Exit trench.

CONTROLS REFERENCE — ENGINEERING · ADMINISTRATIVE · PPE

Applies to all tasks below. Task-specific controls are listed in the JHA.

ENGINEERING CONTROLS	ADMINISTRATIVE CONTROLS	PPE (MINIMUM)
• Trench box / shield, sloping, or shoring (>5 ft) • Spoils set back ≥4 ft from edge • Mechanical ventilation in confined spaces • Dewatering pumps & sumps • Ladder access within 25 ft, 3 ft above edge • Tag lines, restraints & thrust blocking • Trench plates / covers for after-hours • Backup alarms, cameras on equipment	• Competent Person daily trench inspection • Daily Dig & Confined Space permits • 811 locate; pothole; hand-dig within 3 ft • Pre-task huddle / JSA review & sign-on • 4-gas monitor calibrated & continuous • Trained/qualified operators & riggers • 15-ft exclusion zone & signage • Heat illness & lightning standdown plans	• Hard hat (ANSI Z89.1) • Hi-vis Class 2/3 vest • Safety glasses; face shield as needed • Steel/composite-toe boots • Cut-resistant (A4) gloves • Hearing protection near equipment • Harness/SRL near open edge & CSE • Task PPE: chem-resistant gloves/suit, FR, respirator per SDS/task

QUALITY

Required inspections & frequency, critical tolerances, and key performance indicators.

ITEM	REQUIREMENT
1. Pipe Grade & Alignment	Verify pipe grade with laser at every joint. Tolerance ± 0.01 ft from design grade. Alignment checked every 50 LF. No reverse grades permitted — sanitary is gravity-critical.
2. Bedding & Initial Backfill	Minimum bedding below invert per spec. Bedding compacted to springline before joint is made. No large rocks or frozen material within 12" of pipe.
3. Joint Integrity	Each joint inspected for proper gasket seating and full engagement before covering. Mandrel (deflection) test and low-pressure air test per ASTM C828 / spec before final backfill.
4. Manhole Setting	Verify manhole invert matches pipe invert. Channel grouted smooth. External joint wrap applied. Frame & cover set to finish grade. Vacuum test manholes if required by spec.
5. Service Connections	Wyes/tees installed at plan station & invert. Cleanouts marked. Building connection (ref. SAN-54) confirmed before backfill.
6. Compaction & CCTV	Backfill compacted in lifts per spec; min. 95% Standard Proctor (or per spec). Full-length CCTV of all installed pipe before acceptance — no infiltration, offsets, or debris.

REFERENCE DOCUMENTS & DRAWINGS

1. Approved Construction Drawings — Sanitary Sewer Plan & Profile Sheets (Sheet Nos. [X] through [X]); manhole schedule; building connection detail (ref. SAN-54)
2. Project Specifications — Division 33: Section 33 31 00 Sanitary Utility Sewerage Piping
3. Geotechnical Report — Soils Investigation & Recommendations — [Geotechnical Firm, Date]
4. Engineer of Record — Bohler Engineering — applicable sanitary details and standards (TxDOT / NTCOG as specified)
5. OSHA 29 CFR 1926 Subpart P — Excavations (Trenching & Shoring)
6. OSHA 29 CFR 1926 Subpart AA — Confined Spaces in Construction
7. Wicker Construction Inc. — Site-Specific Health & Safety Plan (HASP)
8. Wicker Construction Inc. — Confined Space Entry Program & Permit
9. Wicker Construction Inc. — Excavation & Trenching Safety Plan
10. Dewatering & Discharge Permit — [Permit No. / Agency]
11. Pipe Manufacturer Installation Manual — [Manufacturer Name]

JOB HAZARD ANALYSIS (JHA) — SANITARY SEWER INSTALLATION

OPERATIONAL STEPS IN LOGICAL ORDER. FOLLOW IN THE FIELD AS AN INSTRUCTION MANUAL: SETUP, OPERATION, INSPECTION, STOPPING POINTS, CLEANUP.

#	WALK-THROUGH STEP	HAZARDS	RISK	CONTROLS & SAFE PROCEDURES
1	All personnel informed of emergency procedures prior to performing any work on site.	- Worker injuries and exposures. - Hazardous flora and fauna. - Temperature extremes / heat stress.	LOW	- Emergency: Call 911. Know exact site location and address. Designated Muster Point staffed. Notify Wicker Safety immediately. - First Aid Kit location: [Enter Location]. Nearest hospital / urgent care posted: [Enter]. - All employees complete Site-Specific Safety Orientation before any work begins. - Flora/Fauna: Know poison ivy/oak/sumac, fire ants, snakes. Threatening animal — stop work, retreat, notify Supervisor and Safety. - Heat Stress: Water provided. Breaks in shade / A-C. Reference Wicker Heat Illness Prevention Plan. Buddy system in extreme heat.
2	Mobilize equipment (excavators, loader, trench box, compactor, dewatering pumps) to laydown yard via access road.	- Equipment/vehicle collisions on access road. - Poor road conditions or obstructions. - Dust impairing visibility. - Tipping/overturning on unstable ground.	MED	- Spotters and radio communication between all operators. - Inspect access road for stability and obstructions before mobilization. - Apply water / dust control as needed. - Keep delivery trucks centered — away from ditch and excavation edges. - Verify equipment weight does not exceed road / mat capacity.
3	Unload and stage equipment in designated laydown area. Equipment fueled prior to arriving on site.	- Slips, trips, falls on uneven ground. - Reduced visibility / blind spots during unloading. - Unauthorized personnel entering unloading zone. - Pinch points during chain/strap removal.	LOW	- Only trained / qualified personnel operate mobile equipment. - Flaggers / spotters required for every delivery. - Controlled access zone established opposite trailer. - Cut Level A4 gloves when unhooking safety chains. - Team lift required for items over 50 lbs or longer than 10 ft.
4	Superintendents / Forepersons inspect all equipment and work areas. Verify existing utilities. Complete Daily Dig Permit.	- Faulty or damaged equipment. - Exposure to moving equipment during inspection. - Slips, trips, falls. - Hydraulic leaks / spills. - Existing underground utilities struck.	MED	- Daily equipment maintenance check sheet completed and submitted to Wicker Superintendent. - GIS / One-Call (811) tickets current — all utilities marked and flagged before excavation.

				• Daily Dig Permit signed by Wicker Superintendent before any soil disruption. • LUAWA completed for excavation within 10 ft of any live utility. • No mechanical digging within 3 ft of known live utility — hand dig / pothole required. • Spill kits on site. Report spills immediately. • Lightning standdown at 15 miles. 30-min standdown from last strike.
5	Set up 15-ft exclusion zone around excavation area with weighted cones, red barrier chain, and signage. Establish Competent Person inspection protocol.	• Unauthorized personnel entering excavation zone. • Trench box not inspected before use. • Unidentified underground utilities in excavation path.	MED	• Delineate 15-ft exclusion zone. Post 'Excavation in Progress — Keep Out' signage. • Competent Person (CP) completes written daily excavation inspection BEFORE any worker enters trench. • All utilities physically potholed and located before excavator begins digging. • Field Engineer stakes pipe alignment and structure locations before excavation starts. • Daily Dig Permit signed and posted at excavation before work begins.
6	Begin trench excavation. Set spoils minimum 4 ft from edge of trench. Competent Person inspects trench before worker entry.	• Cave-in / trench wall collapse — engulfment hazard. • Workers struck by excavator or falling spoils. • Soil instability due to groundwater or poor soil type. • Equipment tipping from spoils surcharge near trench edge.	HIGH	• Competent Person classifies soil per OSHA 29 CFR 1926 Subpart P before excavation. • All excavations >5 ft require trench box, sloping, or shoring before worker entry. • Spoils minimum 4 ft from trench edge — no exceptions. • No workers in trench while excavator is actively digging. • Dewatering pump deployed if groundwater reaches excavation bottom. • Atmospheric monitoring required for all excavations >4 ft — test O₂, H₂S, CO, LEL before every entry.
7	Install trench box / trench shield. Establish fall protection, OSHA-compliant ladder access, and tie-off points before any workers enter excavation.	• Workers entering unshored excavation. • Trench box failure or improper installation. • Falls into open excavation. • Workers struck by trench box during installation.	MED	• Trench box inspected by Competent Person before installation — document inspection. • No worker entry until trench box is properly set and CP approves entry. • OSHA-compliant ladder extending 3 ft above trench edge installed within 25 ft of all workers. • SRL attached to certified tie-off point when near open excavation edge. • Laborers clear of area when trench box is being set or advanced.

				• Maintain spoils minimum 4 ft from trench edge at all times.
8	Prepare pipe bedding: place and compact bedding stone to required depth below pipe invert. Field Engineer verifies grade before pipe is set.	• Improper bedding causing pipe settlement or joint failure. • Workers struck by equipment placing bedding. • Grade error resulting in non-compliant pipe slope / cover.	MED	• Place bedding below pipe invert per spec. Set to laser / plan grade. • Field Engineer checks trench bottom elevation before any bedding is placed. • Workers in trench maintain visual and radio contact with excavator operator at all times. • Excavator operator uses slow, deliberate movements when placing bedding. • Pipe laser verified against established benchmark before bedding begins.
9	Tie in to live / existing sanitary sewer or building connection (ref. SAN-54). Plug, bypass, or pump-around flow as required.	• Exposure to raw sewage — biological / pathogen hazard (H₂S, hepatitis, bacteria). • Confined space atmospheric hazard at existing manhole / tie-in. • Uncontrolled sewage release / backup. • Slips on contaminated, wet surfaces.	HIGH	• Coordinate and confirm flow control (plug / bypass pump) before opening the live line. Verify shutdown with owner / utility. • Full PPE for sewage contact: face shield, chemical-resistant gloves, rubber boots, Tyvek as needed. No eating/drinking; wash stations on site. • Atmospheric test and continuous monitoring (O₂, H₂S, CO, LEL) for any entry near the tie-in. H₂S is the controlling hazard — alarm at exit. • Stage spill containment and pumps. Report any release per SWPPP / permit immediately. • Decon procedure at end of task — remove and bag contaminated PPE; hand/face wash before breaks.
10	Perform low-pressure air test, mandrel/deflection test, and CCTV inspection of completed sanitary line.	• Stored pneumatic energy during air test — blown plug / projectile. • Confined space hazard during CCTV / camera setup in manholes. • Test failure requiring excavation and repair.	HIGH	• Restrain / brace test plugs. No personnel in line of plug ejection path during air test. Bleed pressure before removing plugs. • Confined Space Entry Permit and continuous atmospheric monitoring for all manhole entry during CCTV. • Follow ASTM C828 / project spec pressures and hold times exactly. Document results; submit within 24 hrs. • Failed sections excavated, repaired, and re-tested before proceeding.
11	Perform atmospheric monitoring and confined space entry (CSE) for joint inspection, grade confirmation, or structure work inside trench / structure.	• O₂ deficiency or toxic gas (H₂S, CO, methane) in trench or structure. • Engulfment if trench wall collapses during entry.	HIGH	• Confined Space Entry Permit completed and posted before ANY worker enters excavation >4 ft or any structure. • 4-gas monitor (O₂, H₂S, CO, LEL)

		• Worker unable to self-rescue from excavation. • Heat illness in confined, low-airflow trench.		calibrated and tested daily. Test before entry and continuously during. • Acceptable atmosphere: O₂ 19.5–23.5%, H₂S <10 ppm, CO <35 ppm, LEL <10%. • Rescue plan established. Tripod, SRL, and rescue winch at entry point. Attendant at surface — NO entry to rescue. • Minimum 2 workers for confined space entry: 1 entrant, 1 attendant. • Ventilation fan deployed to maintain fresh air in deep / enclosed sections. • If alarm activates — immediate exit. Do not re-enter until source identified and cleared.
12	Perform initial backfill from pipe springline to 12" above pipe crown using approved material. Compact in lifts per spec. Third-party compaction testing.	• Pipe deflection or damage from improper backfill or compaction. • Workers struck by equipment during backfill. • Trench box movement damaging pipe during advancement. • Compaction equipment too close to pipe.	MED	• Initial backfill placed by hand or small equipment — no heavy equipment directly over pipe until adequate cover (per spec, typ. 24"). • Walk-behind vibratory plate for initial lifts. No jumping-jack compactor directly over pipe. • Third-party geotechnical inspector performs proctor testing per spec — every 200 LF and each lift. • Workers clear of excavator backfill zone. Radio and eye contact maintained. • Advance trench box in lifts — never pull box while workers are in trench. • CP re-inspects excavation walls after trench box is advanced.
13	Continue excavation, pipe installation, and backfill sequencing (repeat prior steps) as work progresses throughout the day.	• Complacency from repetitive tasks. • Fatigue increasing risk of errors. • Changing soil conditions as excavation advances. • Dewatering failure allowing water accumulation in trench.	MED	• Daily morning huddle: review JSA, JHA, and lessons learned from prior shift. • CP re-inspects trench at start of each day and after any rain event. • Dewatering pumps monitored throughout shift — dedicate one laborer to monitor pump operation. • Rotate workers in trench positions to reduce fatigue. Max 2-hour continuous trench work before break. • Foreman maintains constant awareness of trench conditions — STOP WORK if soil behavior changes. • Any near-miss or incident reported to Wicker Safety immediately — document and review before resuming.

14	Complete final backfill above pipe zone in compacted lifts using approved material. Loader / dozer and plate compactor used for upper lifts.	• Uneven / insufficient compaction causing surface settlement. • Equipment collision — loader and excavator in close proximity. • Workers struck by loader or compactor. • Compaction test failure requiring rework.	MED	• Clear radio communication between excavator and loader operators at all times. • Enforce no-walk zones around loader and compactor operation. • Minimum 1-ft clearance from placed pipe during compaction. • Third-party compaction testing at each lift per spec — do not advance to next lift until passing results received. • CP / Foreman signs off on each lift before proceeding.
15	End-of-day equipment refueling in designated fueling area. Secure all open trenches and structures before leaving site.	• Fire hazard during refueling. • Chemical spill — fuel or hydraulic fluid. • Public / unauthorized entry into open trench after hours.	MED	• All equipment completely shut off before refueling. No open flames within 50 ft. • Spill kit at fueling station. Fueling operator certified. Containment deployed under transfer hose. • Report all spills immediately. Document on spill report form. • Open excavations secured with trench plates, steel decking, or water-filled barriers after hours. • Warning lights and reflective signage placed around all excavations before leaving site. • Wicker Superintendent verifies site is secure before last person leaves.

RISK KEY: **HIGH** = serious injury/fatality potential — special plan & extra controls. **MED** = controllable with standard controls. **LOW** = routine.

KEY SITE-SPECIFIC HAZARDS & CONTROLS — Sanitary Sewer

HAZARD	RISK	PRIMARY CONTROLS
Cave-in / Engulfment (excavations >5 ft)	HIGH	CP daily inspection & soil classification; trench box/shield, sloping or shoring before entry; spoils ≥4 ft from edge; no entry while digging.
Confined Space (structures & deep trench)	HIGH	CSE permit; 4-gas monitor before & continuously; ventilation; tripod/SRL/winch; attendant — non-entry rescue only.
Sewage / biological exposure on tie-ins	HIGH	Flow control before opening live line; full contact PPE; H ₂ S monitoring; decon & wash stations; report releases.
Struck-by / caught-between (equipment, loads)	MED	Spotters & radio; exclusion/no-walk zones; tag lines; certified rigging inspected each lift; never under suspended load.
Underground utility strike	HIGH	Current 811 ticket; pothole & hand-dig within 3 ft; LUAWA within 10 ft of live utility; stop/evacuate/call on strike.
Dewatering & discharge compliance	MED	Monitor pumps each shift; discharge per permit; no untreated/unpermitted surface discharge; treat as required.
Heat illness & weather	MED	Water/rest/shade; acclimatization; buddy system; lightning standdown at 15 mi, resume 30 min after last strike.

APPROVAL SIGNATURES

PREPARED BY — SAFETY MANAGER, Wicker Construction Inc. Signature: _____ Print Name: _____ Date: _____	WICKER SUPERINTENDENT Signature: _____ Print Name: _____ Date: _____
FOREMAN Signature: _____ Print Name: _____ Date: _____	WICKER SAFETY PROFESSIONAL Signature: _____ Print Name: _____ Date: _____
PROJECT MANAGER Signature: _____ Print Name: _____ Date: _____	OWNER / GC REPRESENTATIVE (as required) Signature: _____ Print Name: _____ Date: _____

CREW REVIEW & SIGN-ON: By signing the attached crew sign-on sheet, each worker confirms this JSA was reviewed in the daily huddle, they understand the hazards and controls, and they understand their Stop-Work Authority.

REVISION LOG

DATE	REV #	DESCRIPTION OF CHANGE	BY
[Date]	Rev 0 — Original	Initial JSA release — Sanitary Sewer wet-utility installation.	Safety Manager
