HANDBOOK OF DEFENCE LAND RANGES SAFETY VOLUME IV

GLOSSARY OF TERMS AND DEFINITIONS

By Command of

The Defence Council

Ministry of Defence

CONDITIONS OF RELEASE

- 1. This information is Crown copyright and the intellectual property rights for this publication belong exclusively to the Ministry of Defence (MOD). No material or information contained in this publication should be reproduced, stored in a retrieval system or transmitted in any form outside MOD establishments except as authorised by both the sponsor and the MOD where appropriate.
- 2. This information is released by the United Kingdom Government to a recipient Government for defence purposes only. It may be disclosed only within the Defence Department of a recipient Government, except as authorised by MOD.
- 3. This information may be subject to privately owned rights.

Apr 08 Page i

Intentional blank page

Page ii Apr 08

HANDBOOK OF DEFENCE LAND RANGES SAFETY VOLUME IV - GLOSSARY OF TERMS AND DEFINITIONS RECORD OF CHANGES

CHANGE NUMBER	DATE OF CHANGE
ONE	FEB 04
TWO	APR 06
THREE	APR 08

Joint Service Publication 403 - Handbook of Defence Land Ranges Safety (Volumes I - V)

Volume I: Range management - policy, responsibilities,

authorisation, use, maintenance and inspection of land

ranges.

Volume II: Design, construction and maintenance of small arms

Infantry and 30mm weapon systems ranges.

Volume III: Part 1 - Use of fixed wing aircraft and

helicopter mounted weapon systems, and unmanned

aircraft systems, on land ranges.

Part 2 - Use of surface to air weapon systems on land

ranges.

Volume IV: Glossary of terms and definitions.

Volume V: Demolitions, ordnance disposal and battle simulation.

Apr 08 Page iii

INTRODUCTION

GENERAL

Joint Services Publication (JSP) 403 is issued under the overall direction of the Defence Council. It contains the Ministry of Defence regulations for the safety of land ranges and is a Ministry of Defence Approved Code of Practice (ACOP). Where issues of health and safety are concerned it takes into account the provisions of the Health and Safety at Work Act and other legislation.

JSP 403 is designed to provide a comprehensive handbook covering safety on Ministry of Defence land ranges. It provides direction, guidance and instructions on which the Services and Ministry of Defence civilian organisations and agencies can base their safety regulations. There are currently five volumes issued and further volumes may be produced if required. JSP 403 as a whole is sponsored by the Chairman of the Defence Land Ranges Safety Committee.

SCOPE OF VOLUMES

JSP 403 Volume I covers the range management aspects of the use of land ranges and deals specifically with the responsibilities, authorisation, use, maintenance and inspection of ranges. The current version Edition 2, replaced the original version dated 31 August 1997.

JSP 403 Volume II covers the design and construction of land ranges and deals specifically with small arms, infantry and 30mm weapon systems ranges. Edition 3 of Volume II is the current version. Volume II replaced Infantry Training, Volume IV, Ranges, Pamphlet No. 22 Range Construction and Regulations (Army Code 71053).

JSP 403 Volume III is in two parts. Part 1 covers the firing of weapon systems from fixed wing aircraft and helicopters on to land ranges. It has introduced commonality into control systems, procedures and management. It also explains the terminology used in air to surface engagements. Part 2 details the policy and principles for the safety of surface to air weapon systems firing against air or surface targets on land ranges.

JSP 403 Volume IV provides a glossary of range safety terms and definitions and also lists the abbreviations used in the other volumes. It is intended as a reference tool for the better understanding of range safety policy, regulations and procedures. The current version Edition 2, replaced the original version dated 31 August 1997.

JSP 403 Volume V covers the design and construction of demolition ranges and explosive ordnance disposal training areas, the clearance of ordnance from ranges and training areas and safety of ranges and training areas used for demolitions and ordnance disposal training and for battle simulation.

Page iv Apr 08

SPONSOR

Queries concerning any volume of JSP 403 should be directed to:

The Secretary

Defence Land Ranges Safety Committee

Ash 2b, MOD Abbey Wood #3212

Bristol BS34 8JH

Tel No: 0117 91 35339 Fax No: 0117 91 35903

e-mail: deswpns-dosg-dlrsc1@mod.uk

Apr 08 Page v

ASSOCIATED PUBLICATIONS

Where an associated publication is referred to in this volume or any other volume of JSP 403 it is to be taken as the authoritative MOD document on the subject.

Reference	Code	Title
A1	JSP 403 Vol 1	Handbook of Defence Land Ranges Safety Volume I – Range Management: Policy, Responsibilities, Authorisation, Use, Maintenance and Inspection of Land Ranges.
A2	JSP 403 Vol 2	Handbook of Defence Land Ranges Safety Volume II Design, Construction and Maintenance of Small Arms, Infantry and 30mm Weapon System Ranges.
АЗ	JSP 403 Vol 3	Handbook of Defence Land Ranges Safety Volume III – Part 1: Use of Fixed Wing and Helicopter Mounted weapon Systems, and Unmanned Aircraft Systems, on Land Ranges. Part 2: Use of Surface to Air Weapon Systems on Land Ranges.
A5	JSP 403 Vol 5	Handbook of Defence Land Ranges Safety Volume V Demolitions, Ordnance Disposal and Battle Simulation.
В	Army Code No. 71751	Infantry Training, Volume IV, Ranges, Pamphlet No. 21, Regulations for the Planning, Conduct and Supervision of Firing and Training with Infantry Weapon Systems and Pyrotechnics.
C1	Army Code No. 71795	Army Operational Shooting Volume 1 - Personal Weapons.
C2	Army Code No. 71643	Army Operational Shooting Volume 2 – Individual Weapons.
C3	Army Code No. 71789	Army Operational Shooting

Page vi Apr 08

		Volume 3 – Support Weapons.
D	JSP 315	Service Accommodation Code.
Е	JSP 375	MOD Health and Safety Handbook.
F	JSP 362	Defence Lands Handbook.
G	JSP 434	Defence Construction in the Built Environment.
Н	JSP 482	Explosives Regulations
I	JSP 462	Financial Management Policy Manual.
J	JSP 390	Military Laser Safety.
K	Army Code 71670	Military Engineering Volume II, Field Engineering Pamphlet No. 4, Demolitions.
L	Army Code 71461(01)	Royal Armoured Corps Training Volume III, Armaments, Pamphlet No. 1, Planning Control and Safety for Live Firing Practices.
M	Army Code 71035	Artillery Training Volume III, Field Artillery, Pamphlet No. 19, Regulations for Planning, Control, Conduct and Safety for Firing
N	Army Code 71687	Practices. Helicopter Training Volume III, Ranges, Pamphlet No. 300, Regulations for the Planning, Conduct and Supervision of Firing (Helicopter Weapons).
0	JSP 418	Environment Manual
Р	AP 3205	RAF Land Ranges Policy
Q - V	Reserved	
W	Army Code 71053	Infantry Training Volume IV, Ranges, Pamphlet No. 22, Range Construction and Regulations (All Arms), 1976 (for historical reference only).

Apr 08 Page vii

X	Army Code 62230	Limitations in the Use of Missiles and Ammunition for Training (LUMAT), Volume 2, Ammunition other than Field Artillery Natures.
Y	ACAWEWRO	Air Command Air Weapon and Electronic Warfare Range Orders
Z1		The Setting of Safety Standards - A Report by an Interdepartmental Group and External Advisers, HM Treasury, 28 June 1996.
Z2		Managing risks to the public: appraisal guidance - draft for consultation, HM Treasury, October 2004.

Page viii Apr 08

GLOSSARY OF TERMS AND DEFINITIONS

Α

Acceptance Trial. An acceptance trial is a trial carried out by nominated representatives of the eventual military users of the weapon, delivery means or equipment to determine if the specified performance and characteristics have been met.

(AAP-6)

Accident. An accident is an unintended event or sequence of events that causes death, injury, environmental damage or material damage. (also see the definition of incident)

(Def Stan 00-56)

Training Accident. A training accident is an unintended event or sequence of events that cause death, injury, environmental damage or material damage during the course of, or as a result of, authorised live or dry training by MOD personnel on public or private property.

Note: Training accident defined here for ease of reference.

Accident Sequence. An accident sequence is the progression of events that results in an accident.

(OB Proceeding 118(1))

Accuracy of Fire. Accuracy of fire is the component of precision of fire which is expressed by the closeness of the Mean Point of Impact (MPI), of a group of shots, at and around the point of aim. (AAP-6)

Acute Angle. An acute angle is an angle of less than 90 degrees (1600 mils). Aerodynamic Drag (see Ballistic Trajectories)

Aimer Error. An unintended directional error by the firer which causes the shot to deviate from the intended point of impact.

Airburst. Airburst is the explosion of a shell or missile above the surface as distinguished from an explosion on contact with the surface or after penetration. (AAP-6)

Air Danger Area. An Air Danger Area (ADA) is the airspace which has been notified as such within which activities dangerous to the flight of aircraft may take place at such times as may be notified.

Air Danger Height. The Air Danger Height (ADH) is the maximum height above ground level at which a hazard may exist. (also see the definition of Control Zone)

Apr 08 A-1

Note: An ADH is measured in feet above ground level. Altitude is measured in feet above Mean Sea Level (MSL).

Air Weapons Range. A range whose principal use is for firing or launching fixed wing or helicopter mounted weapons from the air to the surface.

Allowable Cone of Fire (see Cone of Fire)

Altitude. Altitude is the vertical distance of a level, a point or an object considered as a point, measured in feet above Mean Sea Level (MSL) (see also the definition of Elevation). (AAP-6)

Ammunition/Munition. Ammunition/munition is a projectile (kinetic energy projectile or shell), missile or bomb charged with explosive, propellant, pyrotechnics, initiating composition, or nuclear, biological, or chemical material for use in connection with military operations, including demolition. Certain suitably modified ammunition/munitions are intended to be used for training, ceremonial or non-operational purposes. (See also Stray Ammunition). (AAP-6)

Note: Munition is the preferred NATO term. The terms are interchangeable but it is desirable to choose and use only one.

Ammunition/Munition Danger Area/Zone (see Weapon Danger Area/Zone)

Ammunition/Munition Lot. An ammunition/munition lot is a quantity of homogeneous projectiles, identified by a unique lot number, which is manufactured, assembled or renovated by one producer under uniform conditions and which is expected to function in a uniform manner. (AAP-6)

Ammunition/Munition Natures. For any given calibre there are likely to be a number of different ammunition/munition natures. These natures are largely distinguished by the type and make-up of the projectile. The more common projectiles are:

Armour Piercing. An Armour Piercing (AP) projectile is a weapon which consists of a Gilding Metal (GM) envelope containing a hard metal penetrator.

AP Discarding Sabot. An AP Discarding Sabot (APDS) projectile normally consists of a hard metal sub calibre projectile supported in a sabot which is discarded on muzzle exit. The projectile may be seated on an obturating pusher which is also discarded on muzzle exit.

Ball. A ball projectile is an inert weapon which consists of a gilding metal (GM) envelope filled with a solid lead/antimony core. In some ball rounds the core may be either tipped by, or contain, a mild steel penetrator.

A-2 Apr 08

Baton. Baton rounds contain a projectile, normally solid, designed to strike a target with sub-lethal force for use in riot control situations.

Chemical. Chemical shells contain agents which may be in liquid, solid or slurry form.

Depleted Uranium. A Depleted Uranium (DU) projectile is an AP projectile whose core is made of DU.

Frangible. A frangible projectile is designed to reduce the risk of either ricochet or splash back by disintegrating into small particles on striking a hard surface.

High Explosive. A High Explosive (HE) shell contains HE which may be electronically, mechanically or pyrotechnically fuzed. The shell may be designed to either produce fragments/splinters or contain a shaped charge. Shells which fulfil both functions are described as High Explosive Dual Purpose (HEDP).

High Explosive Anti-Tank (HEAT). An anti armour munition using the hollow or shaped charge principle.

Illuminating. An Illuminating shell contains a pyrotechnic illuminant.

Incendiary/Smoke. An Incendiary/Smoke shell contains an incendiary or smoke compound.

Reduced Range Training Projectile. A Reduced Range Training Projectile (RRTP) is a projectile with a reduced total energy trace compared with the operational round which it is designed to simulate. The reduction in projectile range is normally achieved by reducing mass or adjusting geometry.

Semi-Fixed Ammunition. Semi-fixed ammunition is an ammunition in which the cartridge case is not permanently attached to the projectile. (AAP-6)

Target Marking. A Target Marking (TM) projectile is normally an inert projectile which simulates the ballistic performance of an operational weapon but has a frangible nose cone containing a pulverant compound to indicate the strike on the target.

Tracer. A tracer projectile is a weapon containing a pyrotechnic trace element which may be made up of one or more compounds.

Note: Small Arm tracer ammunition includes an envelope, normally of Gilding Metal Clad Steel (GMCS), containing a lead/antimony core.

Angles. The following Angles are defined: Arrival, Departure, Descent, Impact, Incidence, Projection, Safety, Sight, T, Yaw, Ballistic, Critical Impact and Gun.

Apr 08 A-3

Angle of Arrival (see Angle of Impact)

Angle of Departure. The Angle of Departure (AofD) is the acute angle between the horizontal plane and the line of departure.

Angle of Descent. The angle of descent is the acute angle between the line of impact and the horizontal plane.

Angle of Impact (sometimes called the Angle of Arrival). The angle of impact is the acute angle between the line of arrival, which is a tangent to the weapon trajectory, and the tangent to the ground surface at the point of impact.

Angle of Incidence or Attack. The angle of incidence or attack is the angle between the line of arrival (tangent to the weapon trajectory) and a line drawn at right angles to the surface of the target.

Angle of Projection. The Angle of Projection (AofP) is the acute angle between the line of sight and the line of departure of the weapon.

Angle of Safety. The angle of safety is the minimum permissible angle between the line clearing above and beside friendly troops and the line of the trajectory of the weapon. (AAP-6)

Angle of Sight. The Angle of Sight (AofS) is the acute angle between the line of sight and the horizontal plane (described as 'Elevation' if the target is above the line of sight, and as 'Depression' if the target is below).

Angle T. In artillery and naval gunfire support, the angle T is the angle formed by the intersection of the gun-target line and the observer-target line. (AAP-6)

Angle of Yaw (of a weapon). The angle of yaw is the acute angle of incidence between the axis of the projectile and the line of the trajectory.

Azimuth Angle. The azimuth angle is the angle measured clockwise in the horizontal plane between a reference direction and any other line. (AAP-6)

Ballistic Angles. Ballistic angles are vertical and horizontal angles associated with the trajectory of a weapon.

Bearing. A bearing is the clockwise angular measurement in the horizontal plane from grid north (see Angles: Switch).

Critical Impact Angle. The Critical Impact Angle (CIA) is the acute angle between the line of arrival of a weapon and the horizontal plane above which a ricochet should not occur.

Note: In UK service the CIA is taken to be 533 mils (30°) (the angle is often rounded to 530 mils) although it has proved possible for a weapon to ricochet from a steeper angle of arrival.

A-4 Apr 08

Gun Angles. Gun angles are vertical or horizontal angles which are directly or indirectly set on the gun or associated with the gun.

High Angle. High angle fire is the projection of projectiles at Angles of Departure (AofD) above that at which occurs the maximum range for the gun and ammunition concerned (AofD above 45 degrees or 800 mils).

Low Angle Fire. Low angle fire is the projection of projectiles at Angles of Departure (AofD) below that at which occurs the maximum range for the gun and ammunition concerned (AofD below 45 degrees or 800 mils).

Switch. Switch is an angular correction to bearing. If it is in a clockwise direction it is called More, if anti-clockwise Less.

Anti-Riot Weapons (see Small Arm)

Approval. Approval is the formal act of authorisation, usually in document form, by the responsible authority that the product meets the stated requirement and is suitable for Service/MOD Agency use, with or without limitations.

Note: DLRSC Approval is required for the inclusion of any material in JSP 403 and is documented in the appropriate minute.

Approved Range. A range which varies from the design and build criteria specified for its type in JSP 403 or the appropriate Single Service publication. However, the resultant risk is assessed not to exceed the level authorised for a Compliant Range of the same type.

Arc of Fire. The arc of fire is the angle defining a left and right boundary between which the individual or group is responsible and engages targets.

Area. Area is the extent of a two dimensional surface enclosed within a specified boundary. Armed. A fuzing system is considered to be armed when a fuze function can be stimulated.

Arming. As applied to explosives, weapon or weapon systems, arming is the changing from a safe condition to a state of readiness for initiation. (AAP-6)

Primary Arming. Primary arming is an event that occurs at a point along the trajectory before which the fuze must not function. (OHSWG Overhead Safety Working Group)

Proximity Arming (Secondary Arming). Proximity arming (Secondary Arming) is an event that occurs at a point along the trajectory when the sensor of a proximity fuze, or Multi Role/Purpose Fuze (MRF/MPF) set to proximity, commences the final stage of the arming operation.

Artillery Training Levels. The following levels of Artillery training are approved:

Apr 08 A-5

- (1) Observation of fire training with forward observers static with predetermined safe target areas.
- (2) Observation of fire training by mounted or dismounted forward observers. Mobile up to and around pre-determined safe target areas.
- (3) Unprotected mounted or dismounted Combined Arms Live Firing Exercise (CALFEX) with pre-determined safe target areas modified as troops move.
- (4) Mounted CALFEX with pre-determined safe target areas which are modified as (Armoured Fighting Vehicles (AFVs) move. When using Special Burst Safety Distances (SBSD) vehicles are to be closed down.
- (5) Mounted under armour or dismounted with the correct overhead cover CALFEX using the target safe system.

Authorising Officer (see Range Authorising Officer)

Automatic Fire. Automatic fire occurs when the trigger is pressed once and shots continue to be fired until the trigger is released; as opposed to single shot when between each shot the trigger must be released and subsequently pressed each time to fire.

Axis of the Bore. The axis of the bore is the line passing along the centre of the barrel. The axis may be slightly curved due to barrel droop.

Azimuth Angle (see Angles)

Azimuth Resolution. The azimuth resolution is the ability of radar equipment (or any other kind of measuring equipment) to separate two reflectors at similar ranges but different bearings from a reference point. Normally the minimum separation distance between the reflectors is quoted and expressed as the angle subtended by the reflectors at the reference point. (AAP-6)

A-6 Apr 08

В

Backsplash. Backsplash is fragmentation or target debris thrown back towards the firing point as a result of projectile impact.

Notes:

- (1) This may be a projectile bouncing, projectile or target material fragmenting, or earth throw.
- (2) On a range the standard minimum distance for direct fire engagement should be planned to be greater than the backsplash distance.

Ballistic Angles (see Angles)

Ballistic Coefficient. The Standard Ballistic Coefficient (Co) is a measure of the ability of a projectile to overcome air resistance (carrying power). Co is a function of the projectile mass, shape, diameter and coefficient of steadiness (see the definition of Drag Factor). The greater the Co the further the projectile will go, given the same conditions of projection.

Note: The Co must be stated with respect to some 'Resistance Law' which describes how the resistance of the air varies with velocity.

Ballistic Missile. A ballistic missile is one which does not rely upon aerodynamic surfaces to produce lift and consequently follows a ballistic trajectory when thrust is terminated. (AAP-6)

Ballistics. Ballistics is the science that deals with the motion, behaviour, appearance, or modification of projectiles acted upon by propellants, wind, gravity, temperature, or any other modifying substance, condition, or force.

Note: Ballistics is divided into, Internal, Intermediary, External, Secondary, Terminal and Wound Ballistics. Each part is defined as follows:

Internal Ballistics. Internal ballistics is the aspect of ballistics concerned with the processes that take place within the chamber and the bore of a delivery system (normally a gun) after the ignition of the propelling charge and up to the exit of the projectile from the muzzle.

Note: The scope of internal ballistics also covers the ballistic properties of propellants.

Intermediate Ballistics. Intermediate ballistics is the aspect of ballistics concerned with the transition regime between internal and external ballistics.

External Ballistics. External ballistics is the aspect of ballistics concerned with the motion of a projectile, or its fragment, through an external medium (normally air) between the muzzle of the gun and its final point of impact.

Apr 06 B-1

Secondary Ballistics. Secondary ballistics are the external ballistics of a staging round. For smart munitions the secondary ballistic phase includes the sub-munition guidance phase.

Terminal Ballistics. Terminal Ballistics is the study of the functioning of projectiles at the point of impact, including the mechanism of penetration, distribution of fragmentation and target vulnerability

Wound Ballistics. Wound ballistics is the study of the motion of projectiles or fragments in the body and their capacity to injure.(AAP-6)

Ballistic Wind (see Equivalent Constant Wind)

Ballistic Trajectory. The ballistic trajectory is the three dimensional path traced by the weapon after the propulsive force is terminated and the body is acted upon only by gravity and aerodynamic forces.

(AAP-6)

Barrel. The barrel is that part of a weapon system through which the projectile is propelled and given direction.

Base Ejection Shell. A Base Ejection (BE) shell is a type of shell which ejects its load from its base. (AAP-6)

Base Fuze (see Fuze)

Base Line. A base line is a survey line established with more than usual care, to which surveys are referred for co-ordination and correlation. (AAP-6)

Base Map. A base map is a map or chart showing certain fundamental information, it can be used as a foundation upon which additional specialised data can be compiled or overprinted. A base map is also a map containing all the information from which maps showing specialized information can be prepared.

Battery Centre. The battery centre refers to a point on the ground, the coordinates of which are used, for safety purposes, to define the location of an artillery battery. (AAP-6)

Bearing. A bearing is the clockwise angular measurement in the horizontal plane from grid north.

Beaten Zone. The beaten zone is the pattern formed on the ground by the strike of projectiles fired on a specific point of aim and it will vary with range and the physical characteristics of the area of strike.

Blast. A blast is a brief and rapid movement of air, vapour or fluid away from the centre of detonation, as in an explosion or in the combustion of rocket fuel; the

B-2 Apr 06

pressure accompanying this movement. This term is commonly used for 'explosion', but the two terms may be distinguished. (AAP-6)

Blast Wave. A blast wave is the movement of the region of high pressure created by an expansion of hot gases in the atmosphere which results from an explosion. (AAP-6)

Blind. Explosive ordnance which has been primed, fuzed, armed, initiated or otherwise prepared for action, and which has been dropped, fired, launched, projected, or placed in such a manner as to constitute a hazard to operations, installations, personnel or material and remains unexploded either by malfunction or design, or for any other cause.

Note: The term 'Blind' can be used by pilots of fixed wing aircraft to indicate that they are unable to see something, but it is not used in the context of firing from the air on to land ranges.

Bore. The bore is the interior of a gun barrel that extends from the muzzle to the rear end of the forcing cone.

Blowback (Design Feature). Blowback is the type of delivery system operation designed so that the force of expanding gases furnishes all the energy required to initiate the complete cycle of operation. (AAP-6)

Blowback (Malfunction). Blowback is the escape, to the rear whilst under pressure, of gases formed during the firing of a weapon. It may be caused by a defective breech mechanism, a ruptured cartridge case or a faulty primer. (AAP-6)

Bomb. A bomb is an aircraft or mortar delivered weapon.

Booster (High Explosive). A booster is a high explosive element sufficiently sensitive to be actuated by small explosive elements in a fuze or primer whilst being powerful enough to cause detonation of the main explosive filling. (AAP-6)

Booster (Propulsion). A booster is an auxiliary or initial propulsion system which travels with the missile or aircraft and which may or may not separate from the parent craft when its impulse has been delivered. A booster system may contain, or consist of, one or more units. (AAP-6)

Boresafe Fuze (see Fuze)

Bullet. A bullet is a projectile fired from a Small Arm (SA)(small calibre delivery means).

Bullet Catcher. The bullet catcher is a structure or receptacle placed behind the target line for the purpose of capturing the majority of rounds fired at each target.

Apr 06 B-3

Burnout. The burnout point is the point in time or weapon trajectory when the combustion of fuels or tracer element has terminated by other than programmed cut off.

(AAP-6)

Burnout Velocity. The burnout velocity is the velocity attained by a missile/rocket at the point of fuel/motor termination. (AAP-6)

Burst Height (Design). The design burst height is the height at which it is intended that the fuze, when set to proximity or mechanical time, initiates the shell, bomb or missile.

Burst Safety Distances. Burst Safety Distances (BSD) are hazard distances, calculated for still air at sea level, away from a fragmenting weapon, that are defined as Normal (N), Reduced (R) or Special (S). Definitions of N, R and SBSD are as follows:

Normal Burst Safety Distance. The Normal Burst Safety Distance (NBSD) is the distance from the point on the ground, at or below the point of burst, beyond which it is improbable that any fragment from a bursting weapon will travel (See Notes 1 & 2). Reduced Burst Safety Distance. The Reduced Burst Safety Distance (RBSD) is the distance from the point on the ground, at or below the point of burst, beyond which it is improbable that more than one fragment per bursting weapon could travel (See Note 3).

Reduced Burst Safety Distance. The Reduced Burst Safety Distance (RBSD) is the distance from the point on the ground, at or below the point of burst, beyond which it is improbable that more than one fragment per bursting weapon could travel (See Note 3).

Special Burst Safety Distance (for troops under various degrees of protection). The Special Burst Safety Distance (SBSD) is the distance from the point on the ground, at or below the point of burst, where it is improbable that more than one fragment could penetrate the weakest armour or other protection presented to each bursting weapon (See Note 4).

Notes:

- (1) A fragment encompasses all parts of the shell which are accelerated by effect of explosive detonation. A shell splinter is a fragment, the size of which is the product of design.
- (2) The NBSD is applied whenever civilians are involved or when 100 or more service personnel are in one area (100 x 100 metres) watching or participating.
- (3) The RBSD is applied when 99 or less service personnel, without protection, are in one area (100 x 100 metres) watching or participating.

B-4 Apr 06

(4) The SBSD is only applied when servicemen are fully closed down in specified armoured vehicles, field defences or buildings. All specified areas must be suitably protected. Some damage to vehicles and external fittings may be expected.

Apr 06 B-5

Intentional blank page

B-6 Apr 06

C

Calibrated Airspeed/Altitude. Calibrated airspeed/altitude is the indicated airspeed/altitude corrected for instrument and installation errors. (AAP-6)

Calibre. Calibre is the diameter of the bore measured across the lands (excluding the depth of the rifling grooves) which is also used as a measure of barrel or projectile

length in multiples of calibre.

Notes:

- (1) The calibre is sometimes given as the nominal diameter of the shell or projectile.
- (2) Where the projectile has a discarding sabot, the calibre of the projectile will not equal the calibre of the bore.

Cap (Percussion Cap). A percussion cap is a small container (normally metal) containing a flame producing explosive composition which is designed to be detonated by impact.

Captive Firing. Captive firing is a firing test of short duration, conducted with the missile propulsion system operating while secured to a test stand. (AAP-6)

Captured by Ground. Captured by ground is when the first strike from a projectile fired within the CofF is guaranteed to impact a surface on or near the target.

Cartridge. A cartridge is a cased quantity of propellant complete with its own means of ignition.

Cartridge Case. A cartridge case is a brass or steel metal container holding propellant and supporting the projectile and primer cap.

Carrier Shell. A carrier shell is a specially designed, base or nose ejection, hollow weapon which carries sub-munitions, illumination flares, smoke canisters or other material. (See Secondary Trajectories)

Note: Whilst not normally referred to as a 'Carrier Munition' certain types of bomb or missile could be defined as such.

Caseless. Caseless is a cartridge with no metal case and with the propellant formed into a block, into which the bullet and cap are embedded.

Centre fire. Centre fire is that class of Small Arm (SA) munition which has the primer cap located centrally in the base of the cartridge case.

Apr 08 C-1

Certification. Certification is a signed statement by a qualified person that the product wholly or partially meets or complies with the approved specification(s).

Note: The specification may include a requirement for national legislation prior to certification.

Charge (Combat Engineering). A charge in combat engineering, is a quantity of explosive, prepared for demolition purposes. (See also Shaped Charge and Booster) (AAP-6)

Charge (Cratering). A charge placed at an adequate depth to produce a crater. (AAP-6)

Charge (Cutting). A charge which produces a cutting effect in line with its plane of symmetry. (AAP-6)

Charge (Propelling). A charge is the amount of propellant required to propel a fixed, semi-fixed round or separate loading projectile or shell. (See also Booster) (AAP-6)

Checkout. A checkout is a sequence of functional, operational and calibration tests to determine the condition and status of a weapon system or element thereof. (AAP-6)

Chemical Energy Weapon. A Chemical Energy (CE) weapon is any weapon which achieves its primary effect through the release of chemical energy.

Circular Error Probable. The Circular Error Probable (CEP) is an indicator of the dispersion of a weapon system and can be used as a factor in determining safety distances and the probable damage to a target. One CEP is the radius of the circle within which half of the weapons are expected to fall or have warhead event. (AAP-6)

Clearance (Explosive Ordnance) (see Explosive Ordnance Clearance)

Clear Range Procedure. A procedure followed by the Range Administering Unit and the user unit to ensure that the Range Danger Area is clear of unauthorised persons before firing commences and that it remains clear throughout the time firing is in progress. The procedure includes provision for the timely cessation of firing before it poses a risk of hazard to an intruder in the Range Danger Area.

Clear Vision Line. Lines projected from above and below the firer to the target to ensure that there are no distracting protrusions within the firer's peripheral field of vision in all firing postures.

Cleared Area. An area that has been physically and systematically processed by a demining organization to ensure the removal and/or destruction of all mine and unexploded explosive ordnance hazards to a specified depth. (Also cleared land)

C-2 Apr 08

Notes:

- (1) IMAS 09.10 specifies the quality assurance system (i.e. the organization, procedures and responsibilities) necessary to determine that land has been cleared by the demining organization in accordance with its contractual obligations.
- (2) Cleared areas may include land cleared during the technical survey process, including boundary lanes and cleared lanes. Areas cleared for worksite administrative purposes, such as car parks, storage locations, and first aid posts need not be officially documented as cleared, unless national procedures so require.

Clearance Diving. The process involving the use of divers for locating, identifying and disposing of mines. (AAP-6)

Climate Categories. For munitions of all types the world has been broken down into areas with similar conditions. Eleven Climatic Categories have been selected to describe the land surfaces of the world. A further three have been selected to describe the conditions found at sea (away from land). Details are contained in LUMAT Volume 2/STANAG 2895.

Closed Area / Zone. A closed area / zone is a designated space in, over or through which, passage of any kind is prohibited. (AAP-6)

Closed Impact Area/Zone (see also Impact Area/Zone). A closed impact area is that part of an impact area, known or thought to contain unexploded munitions (blinds), where access is prohibited to all persons except those involved in the clearance of ordnance.

Coefficient of Drag (see Drag Coefficient)

Combination Firing Circuit. A combination firing circuit is an assembly comprising two independent firing systems, one non-electric and one electric, so that the firing of either system will detonate all charges.

(AAP-6)

Common User Item. A common user item is an item, of an interchangeable nature, which is in common use by two or more nations or services of a nation. (AAP-6)

Compatibility. Compatibility is the capability of two or more items or components of equipment or material to exist or function in the same system or environment without mutual interference.

(AAP-6)

Compatibility Group. Each article of military ammunition is assigned to one of the twelve compatibility groups on the basis of their characteristics and associated

Apr 08 C-3

hazards to regulate the conditions under which they are handled, stored and transported.

Complete Round. The complete round refers to a munition (ammunition) which contains all the components necessary for it to function (weapon, propelling charge and a means of initiation). (also see the definition of Round)

Complex. (See Range Complex).

Compliant Range. A range which meets the design and build criteria specified for its type in JSP 403 or the appropriate Single Service publication.

Cone of Fire. The cone of fire is the distribution of fired projectiles within a margin of error in the vertical and horizontal plane.

Contractor Operated Range. A range owned by the MOD and operated by a civilian commercial organisation under licence, contract or partnership arrangements with the MOD. The criteria to be met in operating the range are laid down by the MOD in the licence, contract, protocol or other instruction drawn up with the contractor. A contractor operated range is to be controlled and operated in accordance with the range management principles stipulated in JSP 403.

Allowable Cone of Fire. The allowable cone of fire defines an acceptable left and right boundary and a maximum safe elevation and depression for the weapon system. (defined here for ease of reference)

Note: Projectiles are predicted to be fired within a margin of error off the line of sight. The error margin accounts for aimer error, weapon system inaccuracies and ballistic curve.

Consistency (see Dispersion)

Control Zone (see Air Danger Height). The Control Zone is the controlled airspace extending upwards from the surface of the earth to a specified upper limit. (AAP-6)

Controlled Impact Area/Zone (see also Impact Area/Zone). A controlled impact area is an area known or thought to contain unexploded munitions (blinds) where, due to public rights of way or for other reasons, public access can not be prohibited. After firing has ceased and designated routes through the area have been cleared of any blinds, controlled access is permitted.

Cook off. Cook off is the premature functioning of any or all of the explosive components of a munition due to high temperatures within a weapon system.

Correction. Correction refers to any change in the magnitude of a function which is required to compensate for one or more effects in order to achieve a desired objective.

(STANAG 4119)

Control Point. A point used to control the movements of range visitors, staff and users.

Conventional Munition Disposal. Conventional Munition Disposal (CMD) is the detection, identification, field evaluation, rendering safe, recovery and final disposal of unexploded ordnance, excluding Improvised Explosive Devices (IEDs), biological, chemical and nuclear weapons disposal. It may also include the rendering safe, and or disposal of explosive ordnance (excluding IEDs, biological, chemical and nuclear weapons) which become hazardous through damage or deterioration.

Crest. A crest is a terrain feature of such altitude that it restricts the minimum elevation, the observation of targets or results in dead ground beyond the feature. (AAP-6)

Crew Served Weapon (see Small Arm)

Critical Elevation. The Critical Elevation (Crit Elev) is that quadrant elevation required, under standard firing conditions, to give an impact angle equal to the critical impact angle on a horizontal range surface. (AAP-6)

Critical Impact Angle (see Angle)

CS Gas. CS Gas is O-chlorobenzolmalonitrile. A chemical irritant agent used in riot control munitions. CS, adopted as a code designation, from the names of the inventors, Carson and Stoughton.

Cumulative Risk (see Risk)

Apr 08 C-5

Intentional blank page

C-6 Apr 08

D

Danger. Danger is the circumstance under which harm or the risk of injury or damage may occur.

Danger Area/Zone. The Danger Area/Zone (DA/Z) is the space in which there may be a hazard which could result in a risk to personnel, equipment or property. (also see definitions of Total Energy Area/Zone & Range Danger Area/Zone)

Note: The space is defined as weapon or range specific ie: Weapon DA/Z (WDA) or Range DA/Z (RDA).

Danger Area Template (see Template)

Danger Area Trace. A Danger Area Trace (DA Trace) is a technical drawing of a common composite DA which is deduced from an amalgamation of a number of Weapon DA Templates (WDA Templates). The trace is worked to a given scale and produced on appropriate material for convenient application to a map.

Dangerous Space. The dangerous space is a Small Arm (SA) term used to define the space between the first catch and the first graze.

Note: First Catch and First Graze are defined elsewhere in this Glossary.

Dangerous Zone. The dangerous zone is a Small Arm (SA) term used to define the combination of the dangerous space and the beaten zone.

Datum. Datum is any numerical or geometrical quantity or set of such quantities which may serve as reference or base for other quantities. (AAP-6)

Note: Where the concept is geometric, the plural form is "datums" in contrast to the normal plural "data".

Datum Level. Datum level is a surface to which elevations, height or depth, on a map or chart are related. (AAP-6)

Datum Point. The datum point is any reference point or assumed co-ordinates from which calculation or measurements may be taken. (AAP-6)

Dead Ground/Space (Fire). Dead ground/space is an area or zone within the maximum range of a weapon, radar, or observer, which cannot be covered by fire (hit) or observation (seen) from a particular position because of intervening obstacles, the nature of the ground, the characteristics of the trajectory, or the mechanical limitations of the weapon system.

Apr 08 D-1

Dead Space (Mechanical Limitations). Dead space is the area or zone into which a weapon system cannot fire because of mechanical or electrical firing/aiming limitations.

(AAP-6)

Dead Space (Radio Reception). Dead space is an area or zone which is within range of a radio transmitter but in which a signal is not received. (AAP-6)

Debris Area. A debris area is the area in which debris is predicted to fall.

Dedicated Danger Area/Zone. A dedicated Danger Area/Zone (DA/Z) is a space permanently designated within which specified weapons and explosives which have been fired, launched or detonated (the resulting fragments, debris, components and ricochet) will be contained.

Trajectory Danger Area. The Trajectory Danger Area (DA) is the identified DA beneath the trajectory of certain specified weapons. No one may be in the Trajectory DA whilst weapons are being fired unless they are authorised and suitably protected. (defined here for ease of reference, also see definition of Trajectory)

Dedicated Impact Area/Zone (see Impact Area)

Defect. A defect is any fault in the design, construction, manufacture, marking or packaging of the munition or any deterioration in or damage to the physical state of the munition packaging, Unit Load Carrier (ULC) or Unit Load Specification (ULS)

Defence Zone. That part of an indoor range which may be struck by occasional predicted low angle shot, ricochet or backsplash only, at the extremities of the cone of fire.

Defilade Position. A defilade position is a position at an angle to the target which enables engagement from a flank.

Defiladed Zone. The defiladed zone is the zone which would be included in the beaten zone but for the fact that a proportion of the bullets have met an obstruction.

Deflagration. A rapid chemical reaction (burning) through an explosive/pyrotechnic in which the output of heat is sufficient to enable the reaction to proceed and be accelerated without influence from an external source.

Note: With reference to the response of an explosive store – Ignition and burning of the confined energetic material leads to non-violent pressure release of a low strength case or venting through case closures (leading port/fuse wells etc). The case might rupture but does not fragment; closure covers might be expelled, and unburned or burning energetic material might be thrown about and spread the fire. Pressure venting can propel an unsecured test item, causing an additional hazard. No blast or significant fragmentation damage to the surroundings; only heat and smoke damage from the burning energetic material.

D-2 Apr 08

Delivery Error. The delivery error is the inaccuracy associated with a given weapon system resulting in a dispersion of shots about the aiming point. (AAP-6)

Demolition. Demolition is the destruction of structures, facilities or materials by the use of fire, water or explosives, mechanically or by other means. AAP-6

Demolitions Conducting Officer. The officer or senior NCO qualified as either a Demolitions Safety Officer (DSO) or a Battle Noise Safety Supervisor (BNSS), as appropriate, appointed to plan, conduct and supervise all practices and training involving the use of explosives, simulators or accessories.

Note: The qualification criteria for a DSO and a BNSS are as given in Reference K.

Demolition Firing Position. A demolition firing position is the point or location on the ground where the firing team or crew is located during demolition operations.

Design Approval. Design approval is the formal act of authorisation, usually in document form, by the Responsible Authority that the design meets the stated requirements and is suitable for MOD use with or without limitations.

Design Authorisation. Design authorisation is the order or direction to do something to meet stated requirements, by the branch or establishment responsible for doing so (by the responsible Authority (DEF STAN 05-10)). The responsibility may be more limited, eg: Design or Technical Authorities. Their appointment and limitations are authorised by the Responsible Authority.

Design Certification. Design certification is a signed statement by a qualified person that the design wholly or partially meets or complies with the approved specification(s), which includes legislation.

Detonation. An exothermic reaction at molecular level induced by the action of a disruptive wave through an explosive material causing a sudden violent increase in volume due to the evolution of gaseous products. There are three forms that detonation may take:

High Order. Detonation at a velocity approaching the maximum stable velocity of detonation for a system. Usually applied to NG based compositions.

Low Order. Detonation at a velocity well below the maximum stable velocity of detonation for a system. Usually applied to NG based compositions.

Partial. The incomplete detonation of a high explosive caused by a physical break or lack of chemical homogeneity within the explosive material.

Detonating Cord. A waterproof flexible fabric tube containing a high explosive designed to transmit the detonation wave. (AAP-6)

Apr 08 D-3

Detonator. A device containing a sensitive explosive intended to produce a detonation wave.

(AAP-6)

Deviation. Deviation is the measurement (distance or angle) by which a point of impact or burst misses the target. (AAP-6)

Direct Fire. Direct fire is an engagement in which the target can be seen by the firer. (AAP-6)

Dispensation (see Range Safety Dispensation)

Dispensation Range. A range which varies from the design and build criteria specified for its type in JSP 403 or the appropriate Single Service publication, and results in a level of risk which exceeds that currently accepted for a Compliant Range of the same type.

Dispersion (also called Consistency). Dispersion is the scatter pattern of hits around the Mean Point of Impact (MPI) of bombs and other weapons dropped or fired under identical conditions. (AAP-6)

Dispersion Error. Dispersion error is the distance from the point of impact or burst of a projectile or shell to the Mean Point of Impact (MPI) or burst of a number of weapons. (AAP-6)

Dispersion Pattern. The dispersion pattern is the distribution of a series of weapons fired from one or more delivery means under conditions as nearly identical as possible, the points of burst or impact being dispersed about the Mean Point of Impact (MPI). (AAP-6)

Note: The size of the area to be covered by the dispersion pattern can be estimated using range dependent probable error data (see Probable Error).

Disposal (Explosive Ordnance) (see Explosive Ordnance Disposal)

Disposal Area. A disposal area is a space which is large enough to contain all appropriate safety distances within a controlled area and has ground which is free from foreign objects likely to produce or enhance a secondary weapon hazard. The space provides a safe and efficient environment for the disposal of munitions and explosives in accordance with existing procedures.

Disposal Site. An area authorised for the destruction of ammunition and explosives by detonation and burning.

Doppler Effect. The doppler effect is the phenomenon produced by the change in the observed frequency of a sound or radio wave caused by a time rate of change in

D-4 Apr 08

the effective length of the path of travel between the source and the point of observation.

(AAP-6)

Doppler Radar. Doppler radar is any form of radar which detects motion relative to a reflecting surface by measuring the frequency shift of reflecting radio energy due to themotion of the observer or of the reflecting surface. (AAP-6)

Drag. Drag is the resistance to motion of a projectile through the air, caused by the air's displacement.

Drag Coefficient. Drag coefficient is the ratio of the drag force on the projectile or shell divided by the product of its dynamic pressure and frontal area.

Drag Factor. The drag factor is an index which relates the size, shape and mass of a weapon to its aerodynamic drag.

Drag Loading. Drag loading is the force on an object or structure due to transient winds accompanying the passage of a blast wave.

Drag Pressure. Drag pressure is the product of the dynamic pressure and the drag coefficient which is dependent upon the shape (or geometry) of the structure or project. Drift (Ballistic). In ballistics drift is a shift in the direction of the shell or projectile due to gyroscopic action which results from gravitational and atmospheric induced torques on the spinning weapon. (AAP-6)

Drone. A drone is an Unmanned Air Vehicle (UAV) which conducts its mission without guidance from an external source. (AAP-6)

Droop. Droop is the vertical component of the acute angle measured from the projectile axis to the muzzle axis. It varies between weapon systems and is dependent on the length and construction of the barrel. (STANAG 4119)

Dud (see Blind)

Dump. A dump is a temporary storage area, usually in the open, for bombs, ammunition, equipment, or supplies. (AAP-6)

Dynamic Pressure. Dynamic pressure is stagnation pressure minus ambient pressure (see Stagnation Pressure)

Apr 08 D-5

Intentional blank page

D-6 Apr 08

Ε

Early Burst. An early burst occurs if the fuze, set to the proximity role, initiates the shell beyond the position in the trajectory where proximity arming is complete, but before the intended burst height.

Electro-Explosive Device. An electro-explosive device is an explosive or pyrotechnic component that initiates an explosive, burning, electrical or mechanical train and is activated by the application of electrical energy. (AAP-6)

Enfilade. Enfilade fire is fire which strikes the side of a target.

Equivalent Constant Wind (also called Ballistic Wind). The Equivalent Constant Wind (ECW) is the wind which, if blowing at constant speed and direction at all points of the trajectory, will produce the same changes in range and line, to the point of graze, as does the actual wind.

Note: The ECW value is a weighted mean of the actual winds from the surface to the vertex; the weighting factors used are applied to the wind measurements at various levels which allows for the fact that the time spent by the projectile in a layer of given thickness varies at different levels.

Exercise Trace. An exercise trace is a technical drawing of a common composite exercise danger area which is deduced from an amalgamation of a number of Weapon DA Templates (WDA Templates). The trace is worked to a given scale and produced on appropriate material for convenient application to a map.

Exercise Director. The person who directs that a particular live firing training exercise or practice is to be carried out and who appoints officers to plan and conduct the training. The Exercise Director can not be the person appointed to plan or conduct the training but ensures that the plan meets the requirements of the aim of the exercise and that exercising troops are competent to undertake the training.

Exploder. An exploder is a device designed to generate an electric current in a firing circuit after deliberate action by the user in order to initiate an explosive charge or charges. (AAP-6)

Explosion (Munition). An explosion is a very rapid transfer of heat through a layer or layers of material which is characterised by heat, flash, sound and large quantities of gas.

Note: An explosion can take place without oxygen.

Explosive. An explosive is a substance or a mixture of substances which, under external influences (initiation), is capable of rapidly releasing energy in the form of gases, heat, flash and sound. (AAP-6)

Apr 06 E-1

Explosive Content. The explosive content is the quantity of explosive filling contained in a shell, bomb, mine or missile.

Explosive Materials. Components or ancillary items which contain some explosives, or behave in an explosive manner, such as detonators, fuzes and primers.

Explosive Ordnance. All munitions containing explosives, nuclear fission or fusion materials and biological and chemical agents. This includes bombs and warheads; guided and ballistic missiles; artillery, mortar, rocket and small arms ammunition; all mines, torpedoes and depth charges; pyrotechnics; clusters and dispensers; cartridge and propellant actuated devices; electro-explosive devices; clandestine and improvised explosive devices; and all similar or related items or components explosive in nature. (AAP-6)

Explosive Ordnance Disposal. Explosive Ordnance Disposal (EOD) is the destruction, identification, evaluation, rendering safe, recovery and final disposal of unexploded explosive ordnance. It may include the rendering safe, or disposal of explosive ordnance which have become hazardous by damage or deterioration. (AAP-6)

Explosive Ordnance Disposal Procedures. Those particular courses or modes of action taken by explosive ordnance disposal personnel for access to, diagnosis, rendering safe, recovery and final disposal of explosive ordnance or any hazardous material associated with an explosive ordnance disposal incident.

Access Procedures. Those actions taken to locate exactly and to gain access to unexploded explosive ordnance.

Diagnostic Procedures. Those actions taken to identify and evaluate unexploded explosive ordnance.

Render-safe Procedures. The portion of the explosive ordnance disposal procedures involving the application of special explosive ordnance disposal methods and tools to provide for the interruption of functions or separation of essential components of unexploded explosive ordnance to prevent an unacceptable detonation.

Recovery Procedures. Those actions taken to recover unexploded explosive ordnance.

Final Disposal Procedures. The final disposal of explosive ordnance which may include demolition or burning in place, removal to a disposal area or other appropriate means.

(AAP-6)

Explosive Ordnance Clearance. Explosive Ordnance Clearance (EOC) is the destruction or rendering safe, recovery and final disposal of unexploded explosive ordnance on or from ranges and training areas, including areas formerly used as such.

E-2 Apr 06

Explosive Ordnance Reconnaissance. A reconnaissance involving the investigation, detection, location, marking, initial identification and reporting of suspected unexploded explosive ordnance, by explosive ordnance reconnaissance agents, in order to determine further action. (AAP-6)

Explosive Safety Distance. In Explosive Demolition or Explosive Ordnance Disposal (EOD), the Explosive Safety Distance is the distance at which individuals are physically safe from the effects of Explosive Demolition or EOD activity. This distance takes into account the danger posed by the target and any Demolition/EOD explosives and equipment used in the process. It includes any fragmentation and secondary debris from the event and any Downwind Hazard Area created by any toxic bi-products of initiation. (see also Burst Safety Distances)

External Ballistics (see Ballistics)

Apr 06 E-3

Intentional blank page

E-4 Apr 06

F

Fail Safe. Fail safe is a provision built into a weapon, or component part of the weapon system, so that the item reverts to a safe condition, if it, or part of it, fails to perform its design function.

Field of Fire. The field of fire is the area or zone in front of direct fire weapon systems within which targets can be effectively engaged.

Field Firing Area. An open range having no constructed bullet catchers, stop butts or backstops but with an impact area that can contain the full danger areas of authorised weapon systems, munitions and explosives within the overall range boundary.

Firing Circuit. The firing circuit is an electrical or mechanical train designed to detonate connected charges or to initiate a weapon. (AAP-6)

Firing Lane. A firing lane is a designated zone (usually marked on the ground) in which a direct fire weapon system is located and within which it is authorised to be fired. A range may have a number of firing lanes in parallel.

Firing Mechanism (see Firing Circuit)

Firing Point (in a firing circuit). The firing point is that point in the firing circuit where the device employed to initiate the detonation of the charges is located.

(AAP-6)

Firing Position/Point (Demolition). A demolition firing position/point is the location on the ground at which the firing team or crew is situated during demolition operations.

Firing Position/Point (Weapon). The firing position/point is the location on the ground at which a weapon delivery means (excluding demolitions) is placed for firing.

Firing Position Danger Zone. A firing position danger zone is a space around a firing position in which the direct effects of firing the weapon system could create a hazard to unprotected personnel or material.

Firing Table Elevation. Firing table elevation is the elevation angle at which the gun is required to be laid under standard firing table conditions to achieve the objective stated in the firing table. (STANAG 4119)

First Catch. First catch is the point on the trajectory of a projectile when it would first strike the target.

Apr 08 F-1

First Graze. First graze is the point in the trajectory when the uninterrupted projectile first strikes the ground.

Fixed Ammunition. Fixed ammunition is a round in which the cartridge case is permanently attached to the projectile. (AAP-6)

Flight Path. The flight path is the line connecting the successive positions occupied, or to be occupied, by an aircraft, missile or space vehicle as it moves through the atmosphere or outer space. (AAP-6)

Flight Premature (see Premature)

Flight Termination. Flight termination is the termination of the flight of a Unmanned Aerial Vehicle (UAV), Remotely Piloted Vehicle (RPV) or Guided Weapon (GW) through the initiation of the flight termination system.

Flight Termination Boundary. The flight termination boundary is the outside edge of a free flight zone.

Flight Termination System. A flight termination system is a system fitted to an Unmanned Aerial Vehicle (UAV), Remotely Piloted Vehicle (RPV) or Guided Weapon (GW) which, when initiated will terminate flight.

Fragment (Controlled or Pre-formed). Controlled or pre-formed fragments are defined geometrical structures, such as cubes or balls, which are designed to be propelled outward at high velocities to a predicted pattern.

Fragment (Natural). A natural fragment is a variable sized part of a shell body, which, as a result of the detonation of the high explosive filler, is thrown outward at high velocity. The term can encompass all parts of the shell which are accelerated by effect of explosive detonation.

Fragment (Projectile). A projectile fragment is a variable sized part of a kinetic energy weapon which is produced as a result of high speed impact.

Fragment (Representative). A representative fragment is a fragment that is related to a specified part of a shell.

Fragment (Shell Splinter). A shell splinter is a long thin fragment which usually is the product of design.

Note: The size of naturally formed fragments is independent of design.

Fragmentation. Fragmentation is the combined effect of explosive and shell wall composition producing high velocity fragments.

Fragmentation Area. The fragmentation area is the area surrounding the point of impact into which a propelled fragment may fall.

Free Flight Area. The free flight area is the area beneath the free flight zone.

Free Flight Rocket. A free flight rocket is a rocket not subject to guidance or control during flight. (AAP-6)

Free Flight Zone. The free flight zone is the space within a danger zone in which an Unmanned Aerial Vehicle (UAV), Remotely Piloted Vehicle (RPV) or Guided Weapon (GW) is free to manoeuvre.

Frequency. Frequency is the measured or forecast occurrence of events per unit time of operation. (P118(2))

Frequency (Statistical). Statistical frequency is the ratio of the number of actual to possible occurrences of an event.

Full (Weapon) Danger Area Ranges (see Range (Zone))

Fuze. The fuze is a device which initiates an explosive train. (AAP-6)

The following fuze definitions are listed elsewhere within the Glossary of Terms.

Base Fuze. A base fuze is the type of fuze located in the base of a weapon. (AAP-6)

Boresafe Fuze. A boresafe fuze is a type of fuze having an interrupter in the explosive train that prevents a weapon from exploding until after it has cleared the point of primary arming. (AAP-6)

Note: All fuzes authorised for use by NATO Forces are boresafe.

Impact Action Fuze (also known as Percussion, Direct Action, Contact or Point Detonating Fuze). An impact action fuze is a fuze, with or without a delay mechanism, which is initiated by it striking against an object.

(AAP 6)

Proximity Fuze. A proximity fuze is a fuze wherein primary initiation occurs by remotely sensing the presence, distance, and/or direction of a target or its associated environment by means of a signal generated by the fuze or emitted by the target, or by detecting a disturbance of a natural field surrounding the target.

(AAP 6)

Stand Off Fuze. A stand off fuze is one which is designed to operate when the weapon is physically separated at the optimum distance from

Apr 08 F-3

the surface of the target.

Time Fuze. A time fuze is a fuze which contains a graduated time element to regulate the time interval after which the fuze will function. (AAP-6)

Note: There are multiple purpose fuzes which combine impact, proximity and time (Multi-Role/Purpose Fuze (MRF/MPF).

G

Grooves. Grooves are spiral cuts in the interior of the barrel which form the rifling and thus impart spin to the projectile.

Ground Target (see Target)

Guidance Station Equipment. Guidance station equipment is the ground based portion of a guided missile system necessary to provide guidance during flight.

(AAP-6)

Guided Missile. A guided missile is a self propelled weapon, the trajectory of which is controlled in flight. (AAP-6)

Gun Angles (see Angles)

Gun System (see Weapon System)

Feb 04 G-1

Intentional blank page

G-2 Feb 04

Н

Hand Held Weapon. A hand held weapon is a delivery system, which is normally a Small Arm (SA) that can be carried, held and aimed by a single operator (see Small Arm (SA) for categories).

Hangfire. Hangfire is an undesired delay in the complete functioning of a firing system. (AAP-6)

Notes:

- (1) **Missile.** A hangfire occurs if the firing squibs to the missile/rocket are initiated but the main weapon motor fails to function in the manner predicted. The initiation of the squibs indicate that the weapon motor may function at any time and therefore a delayed firing or hangfire situation exists. (Notes are not extracted from AAP-6)
- (2) **Projectile/Shell.** A hangfire occurs if the projectile/shell propelling charge is partially ignited, or initiated by a firing impulse (electrical or mechanical), but fails to combust fully/ignite or burns so slowly that the gases fail to propel the weapon at the expected time.

Hard Target (see Target)

Hardened Site. A hardened site is a site constructed under rock or concrete cover, designed to provide protection against the effects of conventional weapons. It may also be equipped to provide protection against the side effects of a nuclear attack and against a chemical or biological attack. (AAP-6)

Harm. Harm is a physical injury or damage to health, property or the environment. (P118(2))

Hazard. A potential source of harm.

Hazard Area. The hazard area is the area within which a specified hazard can be identified. A risk assessment defines what level of hazard is acceptable for a particular activity. The edge of the hazard area is the hazard boundary.

Note: The assessor identifies and quantifies the hazard, the acceptor identifies and quantifies the level of risk.

Hazard Boundary. The hazard boundary is the outer edge of the hazard area. It is deemed that at the boundary the risk from the defined hazard is as low as is reasonably practicable.

Hazard Identification. Hazard identification is the process of recognising that a hazard exists and defining its characteristics. (P118(2))

Feb 04 H-1

Hazard Log. A hazard log is a record of the hazards associated with a specific project or activity and the methods by which they have been controlled. (P118(2))

Hazard Marker. Object, other than mine sign, used to identify the limits of a mine and unexploded explosive ordnance hazard area. The marker shall conform to the specification established by the national mine action authority.

Hazard Marking System. Measures designed to provide the public with warning and protection from mine and unexploded explosive ordnance hazards. The system may include the use of signs or markers, or the erection of physical barriers.

Height. The height is the distance measured along the vertical line between a reference level surface and a point. (STANAG 4119)

Height (of an object). The vertical dimension of an object. (AAP-6)

HE Shell (see Shell).

Hazard Impact Area Trace. A Hazard Impact Area Trace (HIAT) defines the boundaries of the Weapon Danger Area/Zone on an air to surface range and is provided as a scaled overlay for use with range maps. In addition, it identifies the release conditions (with associated tolerances), the normal wind and the system aiming error. The HIAT also defines the dimensions and positioning of the release box in which the aircraft must be at weapon release.

High Angle Fire. High angle fire is the firing of shells or kinetic energy projectiles at angles of elevation higher than that which corresponds to the maximum range of the weapon fired with a specified propelling charge. The maximum range of the weapon decreases as the identified angle is changed (either up or down). (AAP-6)

High Elevation Fire. High Elevation Fire (HEF) is a variable, small arm specific, vertical firing angle for engaging targets where the CofF is elevated so that no portion touches the ground within a general firing angle of 200-1250 mils.

Note: The authorised minimum firing elevation varies between ammunition natures.

High Explosives. High explosives are substances or mixtures of substances which, in their application as primary, booster or main charges in shells, missiles, and demolition systems, are required to detonate.

Hill Background. A hill background describes the situation where ground immediately behind the targets on a Gallery Range rises to form a hill beyond which no ricochet hazard is predicted to exist, so that consideration can be given to reducing the size of the Range Danger Area.

H-2 Feb 04

Homing Guidance. Homing guidance is a weapon sub-system which steers a missile towards a target by means of a self-contained mechanism which is activated by a distinguishing characteristic of the target. (AAP-6)

Horizontal Error. Horizontal error is the error in range, deflection, or in radius, which a weapon may be expected to exceed as often as not. The horizontal error of a weapon making a near vertical approach to a target is described in terms of a circular error probable. The horizontal error of a weapon producing an elliptical dispersion pattern is normally expressed in terms of range and deflection probable error.

(AAP-6)

Feb 04 H-3

Intentional blank page

H-4 Feb 04

I

Ideal Trajectory. The ideal trajectory is the mean trajectory which would be obtained by firing an infinite number of projectiles or shells through consistent delivery conditions (platform, firing data, meteorological and ballistic) using the same propelling charge configured with a uniform propellant.

Identified Angle. The identified angle is the angle of projection which achieves maximum range for each associated propelling charge.

Impact Action Fuze (see Fuze)

Impact Area/Zone. An impact area/zone is a space authorised and applied permanently, or at the time of firing, in which specified weapons may impact, detonate, break up or operate. The space must be large enough to contain ricochet but have its edge no closer to the Danger Area/Zone (DA/Z) boundary than the authorised fragment Burst Safety Distance (BSD) or other weapon hazard distance (for example: Gas). Access to the impact area/zone must be physically controlled as directed by the Range Authorising HQ and/or the Range Administering Unit.

Note: See also Closed Impact Area/Zone and Controlled Impact Area/Zone.

Incident. An incident is any unplanned occurrence which does not fall within the definition of accident.

Training Incident. A training incident is any unplanned occurrence which does not fall within the definition of training accident. (also see definitions of Accident and Training Accident).

Indirect Fire. Indirect fire is an engagement in which the target cannot normally be seen by the firer; the delivery means is laid mechanically or electronically using data derived from tables or computation. (AAP-6)

Indirect Laying. Indirect laying is the aiming of the gun, either by sighting on a fixed object (an aiming point), or by means of orientation with a reference point other than a sight (such as a gun director), when the target cannot be seen through the gun sight by the aimer. (AAP-6)

Individual Risk (see Risk)

Indoor Range (see Range Area/Zone)

Infantry Weapon Range (see Range)

Initiation (Non Nuclear). Initiation is the action of a device used as the first

Feb 04 I-1

element of an explosive train which, upon receipt of the proper impulse, causes the detonation or burning of the explosive item. (AAP-6)

Insensitive Munitions. Insensitive Munitions (IM) are munitions that reliably fulfil performance, readiness and operational requirements on demand, but minimise both the probability of inadvertent initiation and the severity of subsequent collateral damage to the weapon platform, logistic system and personnel when subjected to unplanned stimuli. (AOP - 15)

Integrated Weapon System (see Rotary Wing Integrated Weapon Systems)

Intermediate Ballistics (see Ballistics)

Internal Ballistics (see Ballistics)

I-2 Feb 04

J

Jump. Jump is the vertical component of the acute angle between the muzzle axis before firing and the line of departure. It can be positive or negative.

Feb 04 J-1

Intentional blank page

J-2 Feb 04

Κ

Kinetic Energy Projectile. (See Projectile)

Feb 04 K-1

Intentional Blank Page

K-2 Feb 04

L

Land Range. A land range is a range where the Danger Area/Zone (DA/Z) falls wholly or partially on or over land.

Lands. Lands are the set of twisting ribs raised along the interior of the bore which are separated by cut grooves.

Laser (Light Amplification by Stimulated Emission of Radiation). A laser is a device that generates an intense beam of coherent monochromatic radiation in the infra red, visible or ultraviolet region of the electromagnetic spectrum, by stimulated emission of photons from an excited source. (The Concise Oxford Dictionary)

Laser Accessible Emission Limit. The Laser Accessible Emission Limit (AEL) is the maximum accessible emission safe level to the eye within a particular class of laser. (also see the definition of Accessible Emission Limit).

Laser Designator. A laser designator is a device that emits a beam of laser energy which is used to mark a specific place or object. (AAP-6)

Laser Extended Nominal Ocular (Eye) Hazard Distance. The laser Extended Nominal Ocular Hazard Distance (ENOHD) is equivalent to the Nominal Ocular Hazard Distance (NOHD) when magnifying optics are used.

Laser Guided Weapon. A laser guided weapon is a weapon which utilizes a seeker to detect laser energy reflected from a laser marked/designated target and through signal processing provides guidance commands to a control system which guides the weapon to the point from which the laser energy is being reflected.

(AAP-6)

Laser Hazard Area. The Laser Hazard Area (LHA) is the area bounded by the Laser Hazard Area Trace (LHAT) within which there is a risk of injury.

Laser Hazard Hemisphere. The Laser Hazard Hemisphere (LHH) is a hemisphere centred on a Laser the radius of which is equal to the Ocular Hazard Distance (OHD).

Laser Maximum Permissible Exposure (NATO Protection Standard). The laser Maximum Permissible Exposure (MPE) is the level of laser radiation to which a person may be exposed without suffering adverse effects. The NATO Protection Standard is the STANAG equivalent of MPE.

Laser Nominal Ocular (Eye) Hazard Distance. Listed below are the STANAG 3606 and the UK definitions for the laser Nominal Ocular Hazard Distance (NOHD):

Full Definition as laid down in STANAG 3606. The NOHD is the

Apr 06 L-1

distance along the axis of the beam from the laser beyond which the irradiance or radiant exposure would not be expected to exceed the NATO Protection Standard for the unaided eye. This assumes a gaussian beam profile and takes no account of atmospheric effects.

User UK Definition. The NOHD is the minimum distance from an active laser where there is improbable risk of eye damage to unprotected unwarned personnel.

Laser Ocular (Eye) Hazard Distance. The laser Ocular Hazard Distance (OHD) is the intra beam safe viewing distance in an actual case, taking into account all the corrections that need to be applied to the Nominal Ocular Hazard Distance (NOHD) or the Extended Nominal Ocular Hazard Distance (ENOHD).

Laser Range Finder. A laser range finder is a device which uses laser energy for determining the distance from the device to a place or object. (AAP-6)

Launch. To launch is the intentional and irreversible discharging, firing, ejecting or releasing of a missile from its launcher.

Lateral Plane of Sight. The lateral plane of sight is the plane which is at right angles to the vertical plane of sight and contains the line of sight.

Note: When the line of sight is horizontal the lateral plane of sight is in the horizontal plane.

Launch Box. A launch box is a space in which a missile may be fired from a moving launcher without requiring an adjustment to the prescribed danger zone.

Launch Danger Area/Zone. The launch danger area/zone is the space around a guided weapon or rocket launcher in which personnel are at risk from weapon system hazards.

Launcher. A launcher is a structural device designed to support and hold a missile in position for firing. (AAP-6)

Launching Site. The launching site is any location or installation with the capability of dispatching missiles from surface to air or surface to surface. (AAP-6)

Limit of Fire (Ground Limits). The limit of fire is the boundary marking off the area into which projectiles can be fired. (AAP-6)

Limit of Fire (Angular Limits). The limit of fire is the safe angular limit for firing at aerial targets.

(AAP-6)

Limited (Weapon) Danger Area Range (see Range (Zone))

Line of Arrival. The line of arrival is the direction of motion of the weapon at any specified point on the trajectory and is the tangent to the trajectory at that point.

Line of Departure. The line of departure is the tangent to the trajectory at the commencement of free flight.

Note: In general this line should be deduced from elements measured at convenient points on the trajectory. (STANAG 4119)

Line of Fire. The Line of Fire (LofF) is an imaginary straight line from the barrel of the weapon delivery system to the target. Known as the line Gun to Target (GT). The firer need not be able to see the target he is engaging.

Line Gun to Target (see Line of Fire)

Line of Impact. The line of impact is a line tangent to the trajectory at the point of impact or burst projected onto the horizontal plane. (AAP-6)

Line Observer to Target. The line Observer to Target (OT) is an imaginary straight line from the observer to the target.

Line of Sight. The Line of Sight (LofS) is a straight line passing through the aiming device (sight) of the delivery system and the aim point on the target so that the firer can see the target he is engaging. (STANAG 4119)

Live Firing Tactical Training. The infantry term for the final stage of training the battle shot which brings together and practises tactical groups under realistic operational shooting conditions at levels set by the chain of command.

Live Firing Tactical Training Area. An area of ground contained within a range danger area boundary that is used for live firing tactical training.

Low Angle Fire. Low angle fire is the firing of shells or kinetic energy projectiles at angles of elevation lower than that which corresponds to the maximum range of the weapon fired with a specified propelling charge. The maximum range of the weapon decreases as the identified angle is changed (up or down). (AAP-6)

LUMAT (Volume 1&2). LUMAT (Limitation in the Use of Missiles and Ammunition for Training) is the UK publication detailing the limitations in the

Apr 06 L-3

use of ammunition for training imposed by the Ministry of Defence (Weapons or Staff Branches). It does not include limitations in the use of Air Defence (AD) missiles, or ammunition designed for ceremonial guns, or for ammunition which has been authorised for local or temporary use. The following volumes are available:

Volume 1: Field Artillery Natures of Ammunition.

Volume 2: Natures of Ammunition other than Field Artillery.

M

Map Range. The map range is the horizontal distance as measured on a map.

Map Bearing. A map bearing is the bearing as measured on the map or obtained by computation.

Maximum Effective Range. The maximum effective range is the maximum distance at which a weapon may be expected to be sufficiently accurate to achieve the desired result. (AAP-6)

Maximum Range. The maximum range is the greatest distance a weapon can travel under standard weather conditions without consideration of dispersion or fragmentation. (AAP-6)

Maximum Ricochet Range. The Maximum Ricochet Range (MRR) is the range corresponding to the angle of descent which produces the Critical Angle of Impact (CAI) for the projectile.

Mean Point of Impact. The Mean Point of Impact (MPI) is the location which is the arithmetic mean of the co-ordinates of the separate points of impact or burst of a finite number of weapons (projectiles or sub-munitions) fired or released at the same aiming point, under a given set of parameters. (AAP-6)

Mean Area of Effect The Mean Area of Effect (MAE) of a weapon to a target is not an area in the physical sense, but a quantity having the dimensions of area, which, when multiplied by the area density of targets gives the expected number of casualties.

Minimum Safe Fuze Setting. The minimum safe fuze setting is the setting, which, having allowed for the hazard zone of the fuze, non-standard conditions and muzzle velocity spread, will ensure that no fuze operates before the weapon reaches the impact zone.

Misfire. A misfire is the failure of a weapon delivery system to fire or function. (AAP-6)

Missile. A missile is a self propelled unmanned weapon which is internally propelled along a pre-planned trajectory towards a selected point usually to cause damage.

Mortar. A mortar is a mobile (mounted or portable), muzzle loading, generally smooth-bore delivery means designed to fire fin-stabilised bombs at subsonic velocities, predominantly in the high angles.

Munition (see Ammunition).

Feb 04 M-1

Muzzle Axis. The muzzle axis is the straight line axis of the bore at the muzzle.

Muzzle Danger Area. The muzzle danger area is the area immediately in front and to the side of the delivery system (weapon firing platform) into which entry should be restricted during firing.

Muzzle Energy. The Muzzle Energy (ME) is the kinetic energy of a projectile at the muzzle of the delivery means. The ME (joules) = $\frac{1}{2}$ mV² (m = Projectile mass in kg, V = MV in m/s).

Muzzle Velocity (Instrumental Muzzle Velocity). The instrumental Muzzle Velocity (MV) is the apparent velocity of projectile at shot exist, generally computed by backward extrapolating velocity measurements to the muzzle of the delivery means.

Ν

Negligent Discharge. A Negligent Discharge (ND) is a shot that may be fired in any direction, and not necessarily from an approved firing point.

Notes

- 1. ND's most commonly occur when a Small Arm (SA)is being unloaded. However, current drills require the SA, during the unload, to be pointed down the Range towards the targets and in depression. A discharge under these conditions is thus unlikely to produce any greater hazard than that attributed to firing errors.
- **2.** Occasionally a SA is fired in a random direction the 'wild shot'. When that happens the shot may fall outside the Range Danger Area (RDA). However, the occurrence of such shots has been deemed to be very rare, and the Ordnance Board (OB) agreed that they should not be allowed for in the determination of a WDA or RDA. (OB Proc 42577)

Net Explosive Quantity (Content). The Net Explosive Quantity (NEQ) is the quantity of the explosive substance in the munition.

No Danger Area Range (see Range (Zone))

Nominal Ocular Hazard Distance (see Laser NOHD)

Normal Burst Safety Distance (see Burst Safety Distances)

Normal Burst Height. The normal burst height is the intended height of burst at which the fuze, when set proximity or mechanical time, initiates the shell. (OHSWG Overhead Safety Working Group)

Normal Environment. The normal environment is that which will occur during the routine processing and operation of the system in the manufacture to Target or Disposal Sequence (MTDS). It will comprise the aggregate, at a given moment, of all conditions and influences in which, by design, the system will be safe and serviceable.

Non-Standard Ammunition. Non standard ammunition is a round other than the standard combination (projectile and propelling charge) for which the main body of the firing table was compiled. Non-standard projectiles, normally shells include; smoke, illuminating, marker and bomblet which are often ballistically matched to a standard variant.

Feb 04 N-1

Intentional blank page

N-2 Feb 04



Officer in Charge of Practice. The Commanding Officer or Head of the unit or organisation firing on the area who has the overall personal responsibility for the safe conduct of the field artillery practice.

Note: There are a number of artillery safety officer appointments subordinate to the Officer in Charge of Practice (OIC Practice). For a description of the Forward Indirect Fire Safety Officer (FIFSO), the Gun Position Safety Officer (GPSO), the Gun Line Safety Officer (GLSO), the Range Safety Instructor (RSI), the Launch Safety Officer (LSO) and the Command Post Safety Officer (CPSO) see Reference M.

Open Range (see Range)

Open Impact Area/Zone (see also Impact Area/Zone). An open impact area is an impact area where, after firing has ceased and all blinds have been cleared, uncontrolled access is permitted.

Operational Theatre Range. An Operational Theatre Range (OTR) is a range established, usually for a limited period of time, for troops deployed on operations or emergency tours. It is a training facility set up for troops to test and/or familiarise themselves with weapons systems, ammunition and explosive stores during their operational or emergency tour of duty. Responsibility for authorising use of an OTR lies with the deployed commander as directed by the appropriate level operational commander.

One Probable Error (see Probable Error)

Overpressure. The pressure resulting from the blast wave of an explosion. It is referred to as positive when it exceeds atmospheric pressure and negative during the passage of the wave when resulting pressures are less than atmospheric pressure.

(AAP-6)

Overhead Firing Area. The overhead firing area is the area under the trajectory of the weapon between the firing position danger area and the boundary to the impact area.

Apr 06 O-1

Intentional Blank Page

O-2 Apr 06

P

Percussion Cap. A percussion cap is a small container (normally metal) containing a flame producing explosive composition.

Personal Weapon (see Small Arm)

Planning Officer (see also Senior Planning Officer). The Planning Officer is the qualified, current and competent person who is appointed by the Exercise Director to be responsible for the design of the live firing exercise including the definition of the firing area, arcs of fire, permitted ammunition natures, target siting, safe location of all weapon firing positions and the production of a written instruction, including safety trace, after a risk assessment.

Plastic Explosive (see also Explosive). Explosive which is malleable at normal temperatures. (AAP-6)

Point of Aim. The point of aim or aiming point is the grid reference, or spot on the ground or object, at which the weapon is aimed or above which it is intended to function.

Point of Impact. The point of impact is the point at which a projectile, missile or bomb impacts. (AAP-6)

Point Target. A point target is a target which requires the accurate placement of weapons. It is normally a single entity like a vehicle or bunker. (AAP-6)

Practical 100% Area/Zone (see Safe 100% Area/Zone)

Premature (Weapon Function). A premature is the complete or partial function of a weapon before the completion of the required arming delay of the fuzing system. (AC310 Glossary) The follow types of premature are defined:

Note: For reporting purposes the following terms are often used when defining the premature functioning of a conventional weapon:

- (1) **Bore Premature**. A premature occurring in the barrel.
- (2) **Muzzle Premature**. A premature occurring in flight after muzzle exit but before arming.
- (3) Flight Premature.
- (4) **Point Detonating.** A flight premature occurs if the fuze, when set to point detonating, initiates the shell beyond primary arming but before impact.

Feb 04 P-1

(5) **Proximity.** A flight premature occurs when the fuze set to proximity initiates the shell beyond primary arming but before secondary arming.

Note: There are other definitions which may apply.

Primary Arming (see Arming)

Principal Warfare Officer. The officer responsible to the Captain for the planning and safe conduct of Naval guided weapon and gunnery practices and for ensuring that all internal and external safety requirements are satisfied before, during and on completion of all practice firings.

Probable. Probable refers to an event that is likely to be, or to happen, but not necessarily so.

Probability. Probability is the condition of being probable. A probability is the chance that something might occur, often expressed as chance or probability per operation or event.

Probable Error. The probable error of a random variable is that deviation from the mean which is as likely to be exceeded as not. (STANAG 4119)

Note: By convention the probable error is based on the normal distributions (uncorrelated and centred at the mean point of impact), and is approximately 0.6745 (rounded to 0.67) times the Standard Deviation.

One Probable Error. One probable error is the unit of measurement of the horizontal error lying wholly on one side of the mean point of impact both in range and deflection, ie, plus, minus, left or right.

Note: Defined here for ease of reference.

Probabilistic Safety Analysis. Probabilistic Safety Analysis is the assessment of the probability, the consequence of failure and other events that could lead to an incident or accident.

Probability of Damage. The probability of damage is the chance that damage might occur, often stated as chance or probability per operation or event, expressed as a percentage or decimal. (AAP-6)

Probability of Escapement. The probability of escapement is the chance of a weapon, a fragment or propelled debris leaving a defined space, often stated as chance or probability per operation or event, expressed as a percentage or as a decimal.

Projectile. A projectile is an object, capable of being propelled by a force, normally from a gun and continuing in motion by virtue of its kinetic energy. Projectiles are divided into Kinetic Energy Projectiles and Shells. (AAP-6)

P-2 Feb 04

Kinetic Energy Projectile. A kinetic energy projectile is an inert weapon which produces effect on a target through its mass and velocity.

Shell. A shell is a hollow projectile, filled with high explosives or other material and fired from ordnance. The shell has its primary effect through the detonation or dispersion of its contents rather than through its mass or velocity.

Proof. A test process that involves the initiation of an explosive, propellant or pyrotechnic charge to check the safety and functioning of an ordnance or a component, sub assembly or complete round of ammunition. (P128(3))

Protection levels. Three levels of protection are used for calculating safety distances: Unprotected, protected by armour and dug in with Over Head Protection (OHP). Each term is defined as follows:

Unprotected. Unprotected troops are those troops with some part of their body exposed to the effects of direct or indirect fire. This will range from a standing man to a man 'head - up' in an Armoured Fighting Vehicle (AFV) or a trench.

Notes:

- (1) For training the standing man is taken as the basis for unprotected safety calculations, irrespective of how much of his body is actually exposed.
- (2) For operations the standing man is also used unless he is classed as dug in with OHP.

Protected by Armour. Troops are defined as protected by armour if they are in a closed down AFV. It may be necessary to further sub-divide this level.

Dug in with Over Head Protection. Dug in with OHP is defined as troops wholly below level ground in correctly constructed trenches under 0.45 metres of OHP (sand or soil).

Proximity Arming (see Arming)

Proximity Fuze (see Fuze)

Pyrotechnic. A pyrotechnic is a mixture of chemicals, which when ignited, is capable of reacting exothermically to produce light, heat, smoke, sound or gas, and may also be used to introduce a delay into an explosive train because of its known burning time. The term excludes propellants and explosives. (AAP-6)

Feb 04 P-3

Pyrotechnic Delay. A pyrotechnic delay is a pyrotechnic device, added into an explosive train, which because of its known burning time transmits the ignition flame after a predetermined delay. (AAP-6)

P-4 Feb 04

Q

Quadrant Elevation. The Quadrant Elevation (QE) is the angle between the level base of the trajectory in the horizontal plane and the axis of the bore when laid (sighted). (AAP-6)

Feb 04 Q-1

Intentional blank page

Q-2 Feb 04

R

Range (Distance). The range is the distance between any given point and an object or target. (AAP 6)

Range (Zone). The range is a space reserved, authorised and normally equipped for hazardous firing (weapon/laser). The following types of Indoor and Open (Outdoor) ranges are defined: (AAP 6)

Indoor Range. An Indoor Range is one which is fully contained in a building or other structure.

Open (Outdoor) Range. An Open Range is one which is exposed to the natural effects of light, wind and weather. The range may be completely open or contained partially by a structure.

No Danger Area Range. A No Danger Area (NDA) Range is a range where for all practical purposes the design precludes risk of injury to persons or damage to property beyond the range floor caused by shot, direct or ricochet, fired in accordance with authorised procedures and aimed within the bounds of accepted aimer error.

Limited Danger Area Range. A Limited Danger Area (LDA) Range is an open range which is designed to ensure that no direct and correctly aimed shot fired within the bounds of acceptable aimer error will go beyond the range floor. However, ricochet is expected to create a hazard over a wider limited danger area.

Full Danger Area Range. A Full Danger Area (FDA) Range is an open range where hazard is only limited by the elevation of the delivery system and the skill of the firer.

Notes:

- (1) The combination of maximum range, BSD, aimer error and worst case ricochet enables an appropriate FDA template to be produced for each weapon.
- (2) The amalgamation of two or more FDA Range templates produces a FDA Range trace.
- (3) For definitions of the three categories of range see Standard Range, Approved Range and Dispensation Range.
- (4) Several types of range or several ranges of the same type can be grouped together for administrative and operating purposes (See Range Complex).

Apr 08 R-1

Range Allocating Authority. The Range Allocating Authority (RAA) is the headquarters, unit or establishment which decides who is to use a range or group of ranges and allocates time to user units accordingly. The RAA usually has control of the real estate and can often be the Range Administering Unit as well.

Range Authorising Officer. The Range Authorising Officer (RAO) is the officer responsible for personally certifying on the MOD Form 904 the weapon systems, munitions and explosive stores which can be used on the range, and for setting any limitations or restrictions on their use.

Range Administering Unit. The Range Administering Unit (RAU) is the unit or establishment tasked with administering and operating a particular range and is responsible for ensuring the production and upkeep of Range Orders. The RAU is accountable to the Range Authorising Officer.

Range Boundary. The range boundary is the delineation of the edge of the range area or zone.

Range Clear to Fire (see also Clear Range Procedure). Range Clear to Fire is a report from Range Control which confirms to the Range Conducting Officer (RCO) that the range staff are satisfied that all safety measures are in place, the area is controlled and clear of personnel and that firing may commence.

Note: Some countries use other terminology (Range Red, Live, Hot, etc). The only stipulation is that all personnel (military and civilian) fully understand the appropriate term and its relevance.

Range Conducting Officer (see also Senior Range Conducting Officer). The qualified or authorised, current and competent person who is appointed by the Exercise Director/Commanding Officer/Head of unit or organisation to be responsible for the safe conduct of firing in accordance with the relevant Service range instructions.

Range Control. Range Control is the term used to describe the focal point on a range or range complex whose staff are responsible for range management and safety on behalf of the Range Administering Unit (RAU) and/or the Range Authorising Officer (RAO).

Range Complex. Two or more ranges operating independently within a common range boundary and administered by the same unit or establishment.

Range Danger Area Template (see Template)

Range Danger Area Trace (see Trace)

Range Danger Area/Zone. The Range Danger Area/Zone (RDA/Z) is the space within a range in which there may be a risk to personnel, equipment or property from firing authorised weapons. The RDA/Z must be wholly contained within the range or training area boundary. Access to, and movement within the RDA/Z must be

R-2 Apr 08

controlled. The measures taken to monitor and control access must be detailed in Range Standing Orders (SO).

Note: The boundaries on land are always marked, signed, flagged and often fenced to warn the public and to deter access; at sea, buoys may have to be provided.

Range Event. A range event is an activity taking place on a range.

Range Floor. The range floor comprises the ground from the furthest firing point to the target including any range construction intended for or capable of capturing correctly aimed shots or preventing ricochet. The term only applies to constructed ranges.

Range Liaison Officer. The Range Liaison Officer (RLO) is the competent person on the Range Staff of the Range Administering Unit (RAU) who is responsible to the CO/Head of the RAU for liaison with user units/organisations. He may also hold the appointment of Range Officer, Range Manager and/or Range Safety Officer.

Notes:

(1) In the RAF this function is carried out by the Unit Ranges Specialist Officer (URSO).

Range Officer. The Range Officer is the person appointed by the Commanding Officer/Head of the Range Administering Unit, or in the case of the Defence Training Estate in conjunction with the Landmarc Support Services Area Manager, for the daily management and operation of the range. He may also hold the appointment of Range Liaison Officer and/or Range Safety Officer.

Range Safe for Movement. Range safe for movement means that firing is prohibited and that the area is open for authorised entry.

Note: Some countries use other terminology (Range Green, Dry, Cold, etc). The only stipulation is that all personnel (military and civilian) fully understand the appropriate term and its relevance.

Range Safety Dispensation. A range safety dispensation for a firing practice or for a particular range is a written authorisation, at 2 Star level or above, to permit a practice and/or use of a range when it does not meet currently prescribed safety criteria and live firing regulations.

Range Safety Officer. The Range Safety Officer is the competent person on the range staff of the Range Administering Unit who is responsible to the Commanding Officer/Head of the Range Administering Unit for the day to day safe operation of a particular live firing area or range complex and for range clearance.

Notes:

(1) Responsibility for the safe conduct of individual firing practices lies with

Apr 08 R-3

the Range Conducting Officer or Trial Conducting Officer and not the Range Safety Officer. However, the latter does have the authority of the Commanding Officer/Head of the Range Administering Unit to stop an unsafe practice.

Range Safety Officer (Air Traffic Control). The Range Safety Officer (Air Traffic Control) (RSO(ATC)) for RAF Academic Air Weapons Ranges (AWR) is an officer or senior NCO of the Air Traffic Control Branch who holds a minimum endorsement of TC(AWR)L. The RSO(ATC) has overall responsibility for the safe execution of a particular range detail and for the co-ordination of the practice should more than one user be on the range.

Range Safety Officer (Naval Gunfire Support). The officer responsible for safety on land during Naval Gunfire Support practices.

Range Standing Orders. The set of orders, derived from a site specific risk assessment, which specify the control measures and procedures for the safe operation and use of the range. The Range Standing Orders (Range SO) are binding on all persons authorised to be on the range. For training ranges they are written and maintained by the Range Administering Unit. For test, evaluation, research and proof ranges they can be written and maintained by a contractor operating the ranges as long as they are approved by the representative of the Range Authorising Officer.

Ready. The term ready is to indicate that the delivery means is loaded, aimed, prepared and available to fire. (AAP-6)

Rearward Danger Area/Zone. The rearward danger area/zone is the space immediately behind the delivery system in which there may be a risk to personnel, equipment or property.

Rebated Rimless. Rebated rimless is a type of cartridge case in which the extraction rim is smaller than the base of the case.

Reduced Burst Safety Distance (see Burst Safety Distances)

Reliability. Reliability is the ability of an item to perform a required function under stated conditions for a specified period of time. (AAP 6)

Remaining Velocity. The remaining velocity is the speed of the projectile at any specified point along the trajectory.

Note: When the contrary is not specified, or implied by the context, remaining velocity refers to velocity as the projectile passes through the point of graze.

Remotely Piloted Vehicle. A Remotely Piloted Vehicle (RPV) is an unmanned air vehicle capable of being controlled by a person from a distant location through a communications link. It is normally designed to be recoverable. (See also UAV). (AAP-6)

R-4 Apr 08

Representative Fragment (see Fragment)

Render Safe Procedures. Render Safe Procedures (RSP) are the Explosive Ordnance Disposal (EOD) procedures involving the application of explosive ordnance disposal methods and tools to interrupt the functions of, or separate, the essential components of, unexploded ordnance in order to prevent an unacceptable detonation.

Ricochet. Ricochet is the change of velocity, and hence speed and direction, induced in a projectile, missile or fragment caused by its impact with a surface.

Ricochet Danger Area. The ricochet danger area is an area into which a projectile, missile or fragment is liable to ricochet.

Ricochet Template. The ricochet template is a technical drawing which defines the boundary of prescribed ricochet hazard on a specified line of fire. The ricochet template does not take into account local variables such as topography and climate. The following definitions are agreed:

Maximum Ricochet Range. The maximum ricochet range corresponding to the angle of descent which produces the critical angle of impact for the projectile, missile or fragment (normally assumed to be 533 mils), beyond which it is not expected to ricochet and within which all ricochets are expected to be constrained.

Ricochet Width Distance. The ricochet width distance is the distance either side of the line of fire beyond which a projectile, missile or fragment would not be expected to ricochet and within which all ricochets are expected to be constrained. The distance for hard targets is a 1/4 of the Maximum Range to Ricochet (MRR). For ground targets a 1/8 of the MRR is applied.

Ricochet Height. The ricochet height is the upper height limits of ricochet for a projectile, missile or fragment striking hard and ground targets. The height for hard and ground targets is regarded as substantially the same as the vertex height of the normal trajectories that would be achieved by firing at an elevation of 620 mils (hard target) and 360 mils (ground target).

Ricochet Trajectory. The ricochet trajectory is the trajectory that begins at the point of impact and continues until the projectile, missile or fragment comes to a final rest.

Rifling. Rifling is the set of spiral grooves cut along the interior of the bore, leaving raised ribs or 'lands' between them.

Twist of Rifling. Twist of rifling is the distance along the bore, measured in calibres, in which the grooves make one complete circuit.

Rimfire. A type of small arms ammunition in which the initiating compound is contained within the rim of the cartridge case.

Apr 08 R-5

Rimless. Rimless refers to a cartridge case with a deep groove in the rear end, so providing an extraction rim of the same diameter as the body.

Rimmed. Rimmed refers to a cartridge case with a prominently raised rim at the rear end, which positively locates the case in the chamber and affords purchase for the extractor.

Risk (Concept). A general concept of risk is the chance, in quantitative terms, of a defined hazard occurring. It therefore combines a probabilistic measure of the occurrence of the primary event(s) with a measure of the consequences of that/those event(s). Criteria for acceptability of some predicted risk or measured risk can be set voluntarily by the organisation responsible and/or subjected to the hazard, or be set as a mandatory requirement by some regulatory organisation.

Risk (Definition and Key Terms). Risk is the combination of the probability of occurrence of harm and the severity of that harm. The following are key terms:

Risk Analysis. Risk analysis is the systematic use of available information to identify hazards and to estimate the risk to individuals or population, property or the environment.

Risk Assessment. Risk assessment is the overall process of risk analysis and risk evaluation.

Risk Estimation. Risk estimation is the process used to produce a measure of the level of risks being analysed. Risk estimation consists of frequency and consequence analysis and interpretation.

Risk Evaluation. Risk evaluation is the process in which judgements are made on the tolerability of the risk on the basis of risk analysis.

Note: Risk evaluation takes into account socio-economic and environmental factors.

Risk Management. Risk management is systematic application of management policies, procedures and practices to the tasks of analysing, evaluating and controlling risk.

Risk Reduction. Actions taken to lessen the probability, negative consequences or both, associated with a particular risk.

Individual Risk. Individual risk is the risk to an individual resulting from an involvement in a specified environment or event.

Cumulative Risk. The cumulative risk is the risk to an individual over a specified period of time from repeated exposure to a recurring event or a range of different events.

R-6 Apr 08

Societal Risk. Societal risk is the relationship between the frequency of occurrence and the number of people in a given population suffering a specific level of harm from the realisation of specific hazards.

or

Societal risk is the risk to society from an accident that could result in a number of casualties or damage to property or the infrastructure.

Tolerable Risk. Tolerable risk is the level of risk with which society is prepared to accept so as to secure certain benefits, provided the risk is properly controlled.

Note: To tolerate a risk means that it is not to be regarded as something that might be ignored, but rather as something that should be reviewed and reduced whenever possible. (Def Stan 00-56 & P118(2))

Rocket. A rocket is a self propelled vehicle whose trajectory and course, while in flight, cannot be controlled. (AAP 6)

Rotary Wing Integrated Weapon Systems. Rotary Wing Integrated Weapon Systems (RWIWS) are weapon systems that are either permanently attached or appended to a helicopter and are operated remotely by the pilots or observer.

Round. Round is the name loosely used to define a combination of some or all of the following:

Weapon (missile or projectile) with or without fuze.

Propelling charge.

Cartridge case.

Apr 08 R-7

S

Sabot. A sabot is a lightweight carrier in which a sub calibre projectile is centred, to permit firing and projection from within the larger calibre barrel of the delivery means. The carrier fills the bore from which the weapon is fired and is normally discarded a short distance from the muzzle. (AAP-6)

Safe. The absence of risk or danger.

Safety (Concept). Safety relates to the freedom from risks that are harmful to a person, or groups of persons, either local to the hazard, nationally or even throughout the world. It is implied that for the consequences of an event to be defined as a hazard, i.e. a potential for causing harm, there is some risk to the human population and therefore safety could not be guaranteed, even if the risk is accepted when judged against some criterion of acceptability.

Safety (Definition). Safety is the quality of being free from danger or risk of injury. (Def Stan 00-56)

Safety Angle Reduction (200 mils rule). A reduction in the standard ricochet safety angle of 533 mils to 200 mils may be applied on a Gallery Range only, in certain circumstances, to permit the simultaneous use of different firing points on adjacent ranges. It is determined by measuring the angle formed between the flank of the firing point to be used and the nearest flank firer on the adjacent range.

Safety Distance. (See Burst Safety Distance and Explosive Safety Distance).

Safe System. A safe system is one which, under defined conditions, is not expected, through a malfunction, to lead to harm.

Safe 100% Area/Zone. The 100% area or zone is an Artillery term which defines space around the intended point of impact, measured in Probable Errors (PE) for range, deflection, height and fuze length within which all weapons are expected to impact or function. The size of the safety zone indicates the accuracy and consistency of the weapon system. Two 100% zones of safety are identified, the Practical 100% Safe Zone and the Safe 100% Zone. The 100% Zones do not account for fragmentation, earth throw or ricochet.

Practical 100% Safe Zone. The practical 100% safe zone is the space around the intended point of impact in which all weapons, fired by single propellant lot propelling charges through barrels in the first quarter of life, are expected to impact or function. It extends 4 PE around the intended point of impact and mathematically contains 98.6% of all weapons within an area of 8 PE. The practical 100% safe zone is authorised for use during operations and with specific dispensations.

Safe 100% Zone. The safe 100% zone is the space around the intended point of impact into which weapons are expected to impact or function. The zone takes account of variations in weapon performance due to barrel wear,

Apr 08 S-1

manufacturing tolerances and uncertainties in determining the point of impact. The safe 100% zone for weapons fired by single propellant lot propelling charges is 8 PE around the intended point of impact (an area of 16 PE) and for mixed propellant lots 10 PE (an area of 20 PE). The safe 100% zones are authorised for use during peacetime training and expected to be used operationally when weapons are fired in close proximity to own troops.

Safety Assessment Process. Safety Assessment Process is the evaluation of a munition life cycle to determine the hazards to which the munition may be exposed. The assessment includes identification and examination of hazards posed by friendly munitions, enemy munitions, lasers and accidents during storage, handling and transportation (the assessment is based on analytical, empirical, experimental and historical data).

Safe Separation Distance. The safe separation distance is the minimum distance between the delivery system and the weapon beyond which the hazards associated with functioning (detonation) are acceptable. (AAP 6)

Safe Target Area. The safe target area is the restricted impact area in which targets for a particular practice and nature of weapon must lie.

Safety and Arming Unit/Mechanism. A Safety and Arming Unit (SAU) or mechanism is a dual function device which prevents the unintended activation of a main charge or propulsion unit prior to arming, but allows activation thereafter upon receipt of the appropriate stimuli. (AAP 6)

Safety Critical. Safety Critical is a term applied to a condition, event, operation, process or item of whose proper recognition, control, performance or tolerance is essential to safe system operation or use. For Example: Safety critical function, path or component. (AOP-15)

Safety Device. A safety device is a device which prevents unintentional functioning or enhances safety. (AAP 6)

Safety Fuze. Pyrotechnics contained in a flexible and weatherproof sheath burning at a constant rate, used to transmit a flame to the detonator, with a predetermined delay. (AAP-6)

Safety Supervisor. The competent person with the appropriate and current qualification/authorisation appointed to be responsible for the safe conduct of firing as directed by the Range Conducting Officer/Trials Conducting Officer in accordance with relevant Service/Agency instructions and Range Standing Orders.

S-2 Apr 08

Sea Danger Area/Zone. The Sea Danger Area/Zone (SDA/Z) is that part of the total energy zone on or over water in which there may be a risk to personnel, equipment or property.

Secondary Ballistics (see Ballistics)

Secondary Trajectories. Secondary trajectories are trajectories of staging rounds (submunitions) once they are ejected from a carrier shell in flight. (STANAG 4355)

Note: The external ballistics of a staging round is called secondary ballistics.

Semi-fixed Ammunition (see Ammunition Natures)

Senior Planning Officer (see also Planning Officer). The Senior Planning Officer is the qualified, current and competent person appointed by the Exercise Director to co-ordinate the overall plan whenever there is more than one Planning Officer involved and whenever Joint and/or Combined live firing is to take place on a range.

Senior Range Conducting Officer (see also Range Conducting Officer). The Senior Range Conducting Officer (SRCO) is the qualified or authorised, current and competent person appointed by the Exercise Director to conduct live firing training when more than one Range Conducting Officer is involved and whenever Joint and/or Combined live firing is to take place on a range.

Severe Injury. Severe injury is that which disables a person for more than one day. Severe damage is that which renders an asset non-functional or unavailable to perform the dedicated mission for more than one day. (AOP-15)

Shaped Charge (see also Charge). A charge shaped so as to concentrate its explosive force in a particular direction. (AAP-6)

Sheet Explosive. Plastic explosive provided in a sheet form. (AAP-6)

Shell (see Projectile)

Shell Splinter (see Fragment)

Shock Wave (see also Blast Wave). The continuously propagated pressure pulse formed by the blast from an explosion in air, underwater or underground. (AAP-6)

Slant Distance. The slant distance is the distance between two points not at the same level relative to a specific datum. (AAP-6

Apr 08 S-3

Small Arms. Small Arms (SA) is a general term for small calibre (normally < 20 mm) weapon systems. The following categories are defined:

Personal Defence Weapon. Personal Defence Weapons (PDW) are SA which have been primarily designed for personal defence (PDW includes revolvers, pistols and sub machine guns (SMG)).

Individual Combat Weapon. Individual Combat Weapons (ICW) are SA which have been primarily designed for initiating combat (ICW includes rifles, shotguns, Light Machine Guns (LMG)).

Crew Served Weapon. Crew Served Weapon (CSW) are SA which have been primarily designed to provide sustained fire in support of Infantry Operations where more than one operator is required to maintain the required rate of fire (CSW includes Medium Machine Guns (MMG), Heavy Machine Guns (HMG), Vehicle Mounted Machine Guns (VMMG) and Grenade Machine Guns (GMG)).

Area Target Weapon. Area Target Weapons (ATW) are SA which are designed to provide hazardous fragmentation over a defined target area (ATW includes hand grenades and underslung grenade launchers).

Note: Mortars and anti-tank weapons are Infantry Support Weapon (ISW) systems but are not defined as a SA.

Anti Riot Weapon. Anti Riot Weapons (ARW) are SA which are primarily designed for use during the control of riots (ARW includes baton guns, stunguns and grenade launchers (gas and special effect)).

Special Weapon. Special Weapons (SW) are SA which are primarily designed for use by Special Forces, which, because of their unusual role require specific considerations. The weapon systems may be intended for personal defence or individual/team combat (SW includes PDW, ICW, CSW and ARW).

Miscellaneous. The miscellaneous category of SA includes weapon systems not already defined (sub-calibre weapon systems, spotting rifles, signal pistols, line throwers, explosively operated tools or devices (such as nail guns)) to which the design safety principles of SA would be applicable.

Societal Risk (see Risk)

Soft Target (see Ground Target)

Special Burst Safety Distance (see Burst Safety Distance)

Special Weapons (see Small Arm)

Splinter (Shell) (see Fragment)

S-4 Apr 08

Stagnation Pressure. Stagnation pressure is the pressure produced by bringing the air to a stop (see Dynamic Pressure).

Standard Atmosphere (International & British). The standard International Civil Aviation Organisation (ICAO) atmosphere and the British Standard Ballistic Atmosphere provide standard references for the variable physical properties of atmosphere.

Note: The speed of sound in half saturated air at 60 oF is 1120 ft/s.

Standard Deviation. Standard deviation is a measure of dispersion around the mean.

Stop Butt. A Stop Butt is a structure built around or behind a bullet catcher to capture wide or high shot and ricochet off the range floor.

Stray Ammunition. Any item of ammunition found which is reported by military or civilian authorities.

Sustained Rate of Fire. The sustained rate of fire is the rate of fire a delivery system can continue to deliver for an indefinite length of time. (AAP 6)

System Safety. System safety is the application of engineering and management principles, criteria and techniques to identify hazards and either eliminate them or reduce the associated risks to a tolerable level.

Apr 08 S-5

Intentional blank page

S-6 Apr 08

Т

Tamping. The covering of the explosive ordnance and charge with a material or substance designed to mitigate the effects of blast and fragmentation on the surrounding environment.

Tangent Elevation. Tangent elevation is the angle between the line of sight to the target and the axis of the bore.

Target. The target is a specific point at which fire is directed and may be defined as Ground (Soft) or Hard. Types of target are defined as follows:

Ground Target (also called Soft). Ground target refers to all surfaces (including water) which, when impacted at low angle, will deform or break up.

Hard Target. Hard target refers to all material which possesses sufficient strength and surface hardness in relation to a given projectile that at low angles of impact the target suffers little or no deformity.

Target Area. Target areas are grouped according to intended use. Definitions are as follows:

Aircraft or Air Defence Target Area. For aircraft or Air Defence (AD) weapons the target array is suspended, fired, guided or flown through a target space above a defined target area. No weapon is to impact with a target outside the target space.

Demolitions Target Area. For demolitions, the target area is the point or location within the surface impact area where explosive charges are emplaced.

Direct or Indirect Fire Target Area. For direct or indirect fire ground, air or sea to ground weapons the target area is the location within the surface impact area where targets (static or moving, point or array) are positioned for engagement.

Targetry. Targetry is the general description which covers all the various types of target used on training ranges.

Template. A template is a technical drawing worked to a given scale and produced on appropriate material for convenient application. A Danger Area (DA) Template can be produced for a single Weapon type (WDA Template) or a Range (RDA Template) built to a specific type drawing/standard which has been authorised for specific weapons. The following terms are defined:

Range Danger Area Template. A Range Danger Area Template (RDA Template) is a technical drawing which defines the boundary of prescribed risk from firing authorised weapons on a specified bearing line of fire, on a range built to an approved type drawing/standard. The RDA Template is to

Apr 08 T-1

be worked to a given scale and produced on appropriate material for convenient application to a map.

Notes:

- (1) Elements of construction will affect hazard contours and hence change the shape of specific Weapon Danger Areas (WDA).
- (2) The RDA Template will only apply to a range built to the specifications laid down on the type drawing/standard.
- (3) The RDA Template is type drawing/standard and weapon(s) specific.

Weapon Danger Area Template. A Weapon Danger Area Template (WDA Template) is a technical drawing of an approved danger area for a single delivery means and a single target, projected on a specified bearing line of fire, worked to a given scale and produced on appropriate material for convenient application to a map.

Notes:

- (1) On a Full Danger Area (FDA) Field Firing Area (FFA) the WDA Template can be used to deduce a variable safe area by swinging the template within agreed arcs. The deduced safe area becomes a trace for the single weapon system.
- (2) The combining of more than one WDA Template produces a trace.

Temporary Exercise Range. A Temporary Exercise Range (TER) is a temporary range taken into use for a limited period of time for a particular training purpose. A TER can be set up on a piece of land not previously used for training, on an existing training area or on an existing Field Firing Area (FFA). In the latter circumstance, no additional authorisation is required for its construction or use for weapons, ammunition, explosive stores and practices already authorised for the FFA.

Terminal Ballistics (see Ballistics)

Throw-off. Throw-off is the horizontal component of the acute angle between the line of departure and the weapon axis.

Time of Flight. The time of flight is the time in seconds from the instant a weapon is fired, launched, or released from the delivery vehicle or weapon system, to the instant it strikes, detonates or functions. (AAP-6)

Time Fuze (see Fuzes)

Tolerable Risk (see Risk)

T-2 Apr 08

Total Energy Area/Zone. The Total Energy Area/Zone (TEA/Z) is the maximum two or three dimensional space around a firing point within which all weapon system effects are contained.

Trials Specification. A trial may typically be defined as the evaluation or installation of a material or item of equipment away from the laboratory/workshop, where the results are either deliverable to the customer (e.g. report, letter or verbal communication), or where they directly support a deliverable (e.g. hardware). A trials specification details the method for planning, defining, conducting and reporting on formal/informal trials undertaken at both internal and external trials sites. The specification is divided into:

Trials Planning. The management element of trials and includes resourcing, interfacing with the Project Manager, milestone reporting etc.

Trials Personnel. This identifies individual responsibilities, titles etc.

Trials Plan. The technical definition statement that specifies the work to be undertaken and associated activities.

Trials Safety. This identifies the safety requirements and any major legislation applicable to trials work.

Trials Conduct. Details those activities that occur between formal approval of the Trials Plan and publication of the Trials Report.

Trials Reporting. Details the method/format for producing Trials Reports.

Trial Conducting Officer. The competent person responsible for the safe preparation and conduct of all trials and firings carried out on a range under his/her control in accordance with a Trials Specification.

Type Standard. A document containing the technical elements of a design brief for a range and detailing the ballistic and functional requirements to be incorporated in the design.

Apr 08 T-3

Intentional blank page

T-4 Apr 08

U

Underwater Demolition. The destruction or neutralisation of underwater obstacles; this is normally accomplished by underwater demolition teams. (AAP-6)

Unexploded Ordnance (or Unexploded Explosive Ordnance). Ordnance which has been primed, fused, armed or otherwise prepared for action, and which has been fired, dropped, launched, projected or placed in such a manner as to constitute a hazard to operations, installations, personnel or material and remains unexploded either by malfunction or design or for any other cause. (AAP-6)

Unmanned Aerial Vehicle. An Unmanned Aerial Vehicle (UAV) is an unmanned aircraft. It is aerodynamically supported, capable of being controlled and usually recoverable. (See also Remotely Piloted Vehicle).

User Demolition Instruction. A User Demolition Instruction (UDI) gives a detailed forecast of events and may include information extracted from the Range SO. It will be produced by the user unit and signed by the RCO.

V

Velocity. Velocity is speed in a given direction.

Notes:

- (1) **General**. The air in front of a moving projectile undergoes compression. Sound waves are set up by the nose, shoulders and driving band, since sound itself involves a compression of the air.
- (2) **Subsonic** (< Mach 0.8). If the projectile is travelling at less than the speed of sound the compression at the nose is transmitted away from the projectile in all directions and the resistance due to the compression waves is negligible.
- (3) **Transonic** (Mach 0.8 1.2). When a projectile has a transonic velocity it is travelling at about the speed of sound, the compression waves and the projectile are travelling at the same speed. Small variations in velocity cause very marked changes in resistance, this leads to unreliable ballistic properties.
- (4) **Supersonic** (Mach 1.2 5.0). At velocities above the speed of sound, the compression waves can no longer escape and consequently the projectile will outstrip the sound waves. Resistance at supersonic speed is mostly due to wave drag.
- (5) **Hypersonic** (> Mach 5.0). At velocities above Mach 5.0 resistance is mostly due to the effects of the shock wave, at such speeds a vacuum is expected behind a projectile.

(6) **Speed of Sound**. Mach 1 is the local speed of sound. It is a function of material and temperature. For dry air at 15 oC Mach 1 is 340 m/s.

Remaining Velocity. The remaining velocity is the speed of the projectile at any specified point along the trajectory.

Note: When the contrary is not specified, or implied by the context, remaining velocity refers to that at the point of graze.

Vertex. The vertex is the highest point that a projectile reaches in its flight from the gun to the target, it is where the vertical component of the velocity equals zero. (STANAG 4119)

Vertical Plane of Fire. The vertical plane of fire is the vertical plane containing the weapon axis before firing. (STANAG 4119)

Vertical Plane of Sight. The vertical plane of sight is the vertical plane containing the line of sight. (STANAG 4119)

W

Weapon. A weapon is an object designed, used or capable of being used as an instrument for inflicting harm to health, property or the environment. (The Concise Oxford Dictionary)

Note:

Within the military discipline of range safety, the weapon is normally regarded as being the projectile or missile hence the term Weapon Danger Area (WDA). The rifle, barrel, tank, gun or launcher is referred to as the delivery means. The combination of the weapon with the delivery means produces part of the weapon system.

Weapon Danger Area/Zone. The Weapon Danger Area/Zone (WDA/Z) is the space into which specified weapons or their fragments may travel, impact or function, given normal firing conditions. Normal firing conditions are those specified in the relevant weapon system support publications.

Weapon Danger Area/Zone Boundary. The Weapon Danger Area/Zone (WDA/Z) boundary is the line depicting the outer edge of a WDA/Z.

Weapon Danger Area Template (see Template)

Weapon Deviation (Small Arm). Weapon deviation around the intended point of impact is caused by a combination of 'Acceptable' or 'Unacceptable' errors.

Acceptable Error. An acceptable error is one which has been identified, quantified and subsequently allowed for procedurally or through the design, construction or layout of the range.

Unacceptable Error. An unacceptable error is one which has not been allowed for procedurally or through the design, construction or layout of the range. Unacceptable errors may result in levels of hazard and risk beyond the Range Danger Area (RDA) that are intolerable and must be reduced to a level as low as is reasonably practicable. Such errors are the result of a shot, fired unintentionally or in contravention of range orders, deviating outside the scope of acceptable error.

Weapon System. A weapon system is the combination of the weapon, the delivery means and all related equipment, material, services, personnel and means of delivery and deployment (if applicable) which is required so that the weapon system becomes self-sufficient in its intended operational environment. (AAP 6)

Weapon System Classifications. Each element in the overall weapon system should be given a classification, using such factors as criticality of the element to the task, element availability and life cycle cost. The following general guidelines may be used

- Class A Major facility, ship, submarine, aircraft or helicopter.
- **Class B** Minor facility, boat, armoured fighting vehicle or a major system.
- **Class C** Major component or support equipment.

Weapon Free. Weapon free is an operational term to define a weapon control status used to indicate that naval, surface to air and air to air weapon systems may be fired at any target not positively identified as being friendly.

Weapon Hold. Weapon hold is an operational term to define a weapon control status used to indicate that naval, surface to air and air to air weapon systems may be fired only in self defence or in response to a formal order.

Weapon HOLDFIRE. Weapon HOLDFIRE is an operational safety control order, normally used in an emergency to protect friendly aircraft. It will be lifted as soon as possible.

Weapon Tight. Weapon tight is an operational term to define a control status used to indicate that naval, surface to air and air to air weapon systems may be fired only at targets visually identified as being hostile.

Wound Ballistics (see Ballistics)

X/Y/Z

Zone. Zone is the extent of a three dimensional space enclosed within a specified boundary.

GLOSSARY OF ABBREVIATIONS

Α

AAC Army Air Corps

AAP-6 NATO Glossary of Terms and Definitions

ABRO Army Base Repair Organisation

AC Alternating Current

ACDS Assistant Chief of Defence Staff

ACF Army Cadet Force

ACGS Assistant Chief of the General Staff
ACLOS Automated Command to Line Of Sight

ACN Air Co-ordination Notice

ACOP Approved Code Of Practice

ACOS Assistant Chief of Staff

ACPO Association of Chief Police Officers

ACEATM Aimed Controlled Effect Anti--Tank Mine

A&ER Ammunition and Explosives Regulations

AD Air Defence
ADA Air Danger Area
ADH Air Danger Height

adj adjustment

ADP Automatic Data Processing

ADZ Air Danger Zone

AEL Accessible Emission Limit

AESP Army Equipment Support Publication

AF Army Form

AFA Area Firearms Adviser

AFB Air Force Board

AFV Armoured Fighting Vehicle

AGL Adjutant General
ABL Above Ground Level

AGL

AIFV Armoured Infantry Fighting Vehicle
AIS Aeronautical Information Service

ALARP As Low As is Reasonably Practicable

ALDP Airborne Laser Designator Pod

Apr 08 Abbrev - 1

ammo ammunition

AMS Automatic Marking System

AMSL Above Mean Sea Level

AofD Angle of Departure

Angle of Projection

Angle of Sight

AOC Air Officer Commanding

AOC & Comdt RAF Air Officer Commanding & Commandant RAF

College Cranwell

AOP Allied Ordnance Publication

AOSP Army Operational Shooting Policy

AP Ammunition Point, Armour Piercing or Air

Publication

APDS Armour Piercing Discarding Sabot

APEP Armour Piercing Enhanced Performance

Apers Anti--personnel

APFSDS Armour Piercing Fin Stabilised Discarding Sabot

APHEI Armour Piercing High Explosive Incendiary

APIHC Armour Piercing Incendiary Hard Core

APMI Armour Piercing Marker Incendiary

APSE Armour Piercing Special Effect
APWT Annual Personal Weapon Test

ARA Army Rifle Association

ARM Armament armr armour

ARW Anti--Riot Weapon

ASSAWP Air to Surface/Surface to Air Working Party

ASW Area Suppression Weapon
AT Ammunition Technician

ATC Air Training Corps
ATC Air Traffic Control

Atk Anti--tank

ATGW Anti--Tank Guided Weapon
ATO Ammunition Technical Officer

ATW Area Target Weapons

AWE Atomic Weapons Establishment

AWR Air Weapons Range

Abbrev - 2 Apr 08

В

BATUS British Army Training Unit Suffield

BDO Bomb Disposal Officer

bdry boundary

BE Base Ejection

BHN Brinnel Hardness Number

BS British Standard

BSD Burst Safety Distance

BSI British Standards Institution

BSL Basic Safety Limit

BSO Basic Safety Objective

BZ Beaten Zone

C

°C Celsius

C Ballistic Coefficient

Co Standard Ballistic Coefficient
C3TR Charm 3 Training Round
CAA Civil Aviation Authority

CALFEX Combined Arms Live Firing Exercise
CBD Chemical and Biological Defence

CCF Combined Cadet Force

CCMDP Chief Constable Ministry of Defence Police

CCTV Close Circuit Television
CDM Chief of Defence Materiel

Cd Coefficient of Drag (also referred to as dC)

CE(RAF) Chief Engineer (Royal Air Force)

CE Chemical Energy

CE Chief Executive (title used by ABRO, DE &

DSTL)

CEP Circular Error Probable

CES Complete Equipment Schedule

CESO(A) Chief Environmental and Safety Officer (Army)
CESO(MOD) Chief Environmental and Safety Officer (Ministry

of Defence)

CESO(N) Chief Environmental and Safety Officer (Navy)
CESO(RAF) Chief Environmental and Safety Officer (Royal

Air Force)

CEWP Combat Engineer Working Party

CFP NIG Crown, Fire and Police National Interest Group

CGR Converted Gallery Range

CGRM Commandant General Royal Marines

CGS Chief of the General Staff

ch charge

CIA Critical Impact Angle

CIE(MOD) Chief Inspector of Explosives (Ministry of

Defence)

CNH CINCNAVHOME

CinC Commander in Chief

CINCNAVHOME Commander in Chief Naval Home Command

CL Centre Line

CLAW Control of Lead at Work
CO Commanding Officer
CofC Chain of Command

CofF Cone of Fire

CofM Correction of the Moment
CofR Commencement of Rifling

COS Chief of Staff

COSHH Control Of Substances Hazardous to Health

CP Command Post

CPE Circular Probable Error

CPSA Clay Pigeon Shooting Association

CQB Close Quarter Battle

CQBR(R) Close Quarter Battle Range (Rural)
CQBR(U) Close Quarter Battle Range (Urban)

Crit Elev Critical Elevation

CSO--chlorobenzolmalonitrile. Chemical irritant agent (name comes from the

names of the inventors Carson and Stoughton)

CSW Crew Served Weapon

CTA Cased Telescopic Ammunition
CTPS Cine Target Projection System
CTTE Cine Target Trainer Equipmen

Abbrev - 4 Apr 08

D

DA Direct Action (Fuze)

DA Double Action (Revolvers)

DA Danger Area

DACOS Deputy Assistant Chief of Staff

DART Disappearing Automatic Retaliatory Target

DAP Directorate of Airspace Policy

DAS Defensive Aid Suite
DA/Z Danger Area/Zone

db decibels

dC Drag Coefficient (also referred to as Cd)

DC Direct Current

DCC IPT Dismounted Close Combat Integrated Project

Team

DCDS Deputy Chief of the Defence Staff

DCI Defence Council Instruction

DCO Demolitions Conducting Officer

DDA Demolition Danger Area

Def Stan Defence Standard

DE Defence Estates (formerly DEO)

DE&SDefence Equipment and Support

DERA Defence Evaluation and Research Agency

(from1 Jul 01 split into DSTL and QinetiQ)

DESB Defence Environmental and Safety Board

DESC Defence Environmental and Safety Committee

DFWES Direct Fire Weapon Effect Simulator

DG Director General

DGTS(L) Director General Training Support (Land)

DIN Defence Information Notice

dia diameter

DLR Defence Land Range

DLRSC Defence Land Ranges Safety Committee

DODABSWP Demolitions, Ordnance Disposal and Battle

Simulation Working Party

DM Defence Munitions

DOSB Defence Ordnance Safety Board
DOSG Defence Ordnance Safety Group

DRA Director Royal Artillery

DRAC Director Royal Armoured Corps

DS&C Director Safety and Claims (formerly Director

Safety, Environmental and Fire Policy

DSRR(TR) Discarding Sabot Reduced Range (Training

Round)

DS/T (120mm Practice) Discarding Sabot, Tracered **DSTL** Defence Science and Technology Laboratory

(formerly part of DERA)

DTE Defence Training Estate (part of DE)

DU Depleted Uranium

DUS(DP) Deputy Under Secretary (Defence Procurement)

Ε

EASI Estate Adviser (formerly DLA in the DEO)
EASI Electronic Automatic Sequencing Initiato

ECW Equivalent Constant Wind
EinC(A) Engineer in Chief (Army)
EFS Enemy Fire Simulator

EHO Environmental Health Organisation

EHT Environmental Health Team

EM Electro--Magnetic

EMP Electro--Magnetic Phenomenon

EMAS Employment Medical Advisory Service

EMT Environmental Monitoring Team

ENOHD Extended Nominal Ocular Hazard Distance

ENO Environmental Noise Officer

EO Explosive Ordnance

EOC Explosive Ordnance Clearance
EOD Explosive Ordnance Disposal

ER Explosive Regulation
ESA Explosive Safety Adviser

ET(CG)R Electric Target (Converted Gallery) Range

ETR Electric Target Range

ET(LDA)R Electric Target (Limited Danger Area) Range

EU European Union

EWC Establishment Works Consultant

Abbrev - 6 Apr 08

EWG Expert Working Group

F

°F Fahrenheit

FAC Forward Air Controller

FAPDS Frangible Armour Piercing Discarding Sabot

FDA Full Danger Area

FET Fixed Electrical Target

FFA Field Firing Area

FFE Free From Explosives

FFE Fire For Effect

FFTO Force Firearms Training Officer
FIBUA Fighting In a Built Up Area

fig figure

FITOW Further Improved Tube launched Optical

tracked Wire guided

FMR Field Miniature Range

FO Flag Officer

FOSM Flag Officer Submarines

FOSNNI Flag Officer Scotland, Northern England and

Northern Ireland

FOST Flag Officer Sea Training

FP Firing Point

FPSO Firing Point Safety Officer

FPO Firing Point Officer

ft foot/feet

ft/sfeet per secondFTAField Training Areaft lbffoot pound forceFUPForming Up Point

FW Fixed Wing

G

g gram(s)
gr grain(s)

GM Gilding Metal

GMG Grenade Machine Gun
GMCS Gilding Metal Clad Steel

GOC General Officer Commanding
GPF General Purpose Flechette
GPS Global Positioning System

GPMG(SF) General Purpose Machine Gun (Sustained Fire)

GR Gallery Range

GRP Glass Reinforced Plastic

GT Gun to Target

G&Z Grouping and Zeroing

GW Guided Weapon

Н

Ha Hectare(s)

HD NV Div Head of Department Noise and Vibration

Division

HE High Explosive

HEAT High Explosive Anti--Tank
HEDP High Explosive Dual Purpose

HEF High Elevation Fire

HEISAP High Explosive Incendiary Semi--Armour

Piercing

HEMPSM High Explosive Multi--Purpose Sub--Munition

HIAT High Explosive Squash Head
Hazardous Impact Area Trace

HITP High Ignition Temperature Propellant

HMG Heavy Machine Gun

HMT(RAF) Health Monitoring Team (Royal Air Force)

HQ Headquarters

HQAC Headquarters Air Cadets

HQ AGHeadquarters Adjutant GeneralHQ AIRHeadquarters Air Command

HQ Inf Headquarters Infantry

HQ LAND Headquarters Land Command

H&S Health and Safety

HSC Health and Safety Commission
HSE Health and Safety Executive

Abbrev - 8 Apr 08

HSW Health and Safety at Work

HSW Act Health and Safety at Work etc Act 1974

ht height

HV High Velocity

ı

IBSR Individual Battle Shooting Range

ICAO International Civil Aviation Organisation

ICM Improved Conventional Munitions

ICW Individual Combat Weapon
IDS Interim Defence Standard

IDT Indoor Trainer

IE Inspector of Explosives

IED Improvised Explosive Device

IEDD Improvised Explosive Device Disposal

illum illuminating

IM Insensitive Munition

IMAS International Mine Action Standards

in inch(es)

INM Institute of Naval Medicine
IPT Integrated Project Team

IRSAG International Range Safety Advisory Group

IR Infra--Red

IRSI Independent Range Safety Inspector
ISO International Standards Organisation

ISW Infantry Support Weapon

ITDU Infantry Trials and Development Unit
ITOP International Test Operating Procedures

ITOW Improved Tube launched Optical tracked Wire

guided

ITT Indoor Training Theatre

ITTR Indoor Training Theatre Range

J

J joules

K

KE Kinetic Energykg Kilogram(s)

kt Knot(s)(aeronautical navigation)kn Knot(s)(maritime navigation)kphKilometres per hourkVAKilovolt Amperes

L

Laser Alignment Device

Land Accident and Investigation Team

LASO
Launch Area Safety Officer
LAW
Light Anti--Tank Weapon

Ib pound(s)

LDA Limited Danger Area

LFTT Live Firing Tactical Training

LH Left Hand

LHA Laser Hazard Area

LHAT Laser Hazard Area Trace
LHH Laser Hazard Hemisphere

LMG Light Machine Gun
Light Mortar Munitions

LNOHD Laser Nominal Ocular Hazard Distance

LofD Limit of Night Vision
LofD Line of Departure

LofF Line of Fire
LofS Line of Sight

LRF Laser Range Finder
LNR Long Range Rifle
LSO Laser Safety Officer
LSO Launch Safety Officer

LRWP Land Ranges Working Party

LSW Light Support Weapon

LTAR Land Training Areas & Ranges

Abbrev - 10 Apr 08

LTC Long Term Costing
LTM Laser Target Marker

LUMAT Limitations in the Use of Missiles and

Ammunition at Training

LWC Land Warfare Centre (formerly Combined Arms

Training Centre)

M

m metre(s)

MAE Mean Area of Effect

max maximum

MBSD Multi Barrel Smoke Discharger
MCLOS Manual Command to Line Of Sight
MCT/S Milan Compact Turret/Spartan

md Mean Deviation

MDP Ministry of Defence Police

ME Muzzle Energy (in joules) (j)

ME(d) Muzzle Energy (distance)

MFC Mortar Fire Control

MFDC Mortar Fire Data Computer

mg milligram(s)

MG Machine Gun

MHE Materials Handling Equipment

MICV Mechanised Infantry Combat Vehicle

MIRA MILAN Infra--Red Adapter

minminimummkmarkmlmillilitre(s)

ML Member's Letter (Ordnance Board)

MLAGB Muzzle Loaders Association of Great Britain

mm millimetre(s)

MMG Medium Machine Gun

MMTTR Mechanised Moving Target Trainer Range

MOD Ministry of Defence

MOIC Missile Ordnance Inhibiting Circuit

MP Multi--Purpose

mpb mean point of burst

MPE Maximum Permissible Exposure

MPF Map Predicted Fire
MPF Multi--Purpose Fuze
MRF Multi--Role Fuze
mph miles per hour

mpi mean point of impact

MRATGW Medium Range Anti--Tank Guided Weapon

MRR Maximum Range to Ricochet

m/s metres per second

MS Mild Steel

MSER Manufacture and Storage of Explosives

Regulations

MSL Mean Sea Level

MSS Multi--Spectral Smoke

MTDS Manufacture to Target or Disposal Sequence

MTS(R) Moving Target System (Rural)

MV Muzzle Velocity (in metres per second (m/s))

Ν

N newton(s)

NATO North Atlantic Treaty Organisation

NBSA Naval Bases and Supply Agency (part of the

DLO)

NBSD Normal Burst Safety Distance
NCO Non--Commissioned Officer

NDA No Danger Area

NEQ Net Explosive Quantity

NHSG
Naval Health and Safety Group
NOHD
Nominal Ocular Hazard Distance

NOTAM Notice to Airmen

NPA National Pistol Association
NRA National Rifle Association

NRSWG NATO Range Safety Working Group

NSD Normal Safety Distance
NSN NATO Stock Number

NSRA National Small--bore Rifle Association

Abbrev - 12 Apr 08

0

OB Ordnance Board (incorporated into DOSG)

OB Proc Ordnance Board Proceeding
OBUA Operations in Built Up Area

OC Officer Commanding
ODT Outdoor Trainer

OEL Occupational Exposure Limit

OIC Officer In Charge

OIC Practice Officer In Charge of the Practice (used for field

artillery only)

OHD Ocular Hazard Distance
OHP Overhead Protection

OOB Out Of Bounds
OP Observation Post

ops operations

OS Ordnance Survey
OT Observer to Target

OTR Operational Theatre Range

P

PA Public Address

PATO Principal Ammunition Technical Officer

PDW Personal Defence Weapon

PE Probable Error

pers personnel

PEXA Practice and Exercise Area
PHR Predicted Horizontal Range

P Info Public Information

PLC 180 A Plastic coated concrete post 1.8 m high

(B=heavy duty wire)

PLS 120 A Steel post 1.2 m high (A = medium duty wire)

PLW 140 Wooded post 1.4 m high
PLO Project Liaison Officer

PLSD Protection and Life Science Division (Dstl

Porton Down)

PM Project Manager

PMG Property Management Group (term used by DE)

PMO Principal Medical Officer

POA Point of Aim

POD Protected Observation Down--range

PPE Personal Protection Equipment

PROM Property Manager

prac practice

Proc Proceeding (Ordnance Board)

proj projectile

PR Predicted Range

PSA Probabilistic Safety Analysis
PTA Permanent Training Range
PUS Permanent Under Secretary
PWO Principal Warfare Officer

Q

QE Quadrant Elevation

QF Quick Fire

QRA Quantified Risk Assessment

R

RAA Range Allocating Authority

RAF Royal Air Force

RAF IIR Royal Air Force Independent Inspector of

Ranges

RAF IHMT RAF Institute of Health and Medical Training

RAU Range Administering Unit
RAO Range Authorising Officer

RBSD Reduced Burst Safety Distance

RCO Range Conducting Officer

RDA Range Danger Area

RDX Research Department Formula X

RE Royal Engineers

rf Rimfire

RF Radio Frequency

Abbrev - 14 Apr 08

RFCA Reserve Forces and Cadets Associations

(formerly TAVRA)

r/g (min) Rounds per gun (per minute)

Rg to Tgt Range to Target

RGGS Rifle Grenade General Service

RH Right Hand

RLG Rifle Launched Grenade
RLO Range Liaison Officer

RM Royal Marines

RMR Royal Marine Reserve

RMCC Royal Marine Cadet Corps

RMCS Royal Military College of Science r/mor (per min) Rounds per mortar (per minute)

RN Royal Navy

RN EOD Royal Navy Explosive Ordnance Disposal

RN RSO Royal Naval Range Safety Officer

RPC Regional Prime Contract

RPE Respiratory Protective Equipment

RPV Remotely Piloted Vehicle

RRTP Reduced Range Training Projectile
RSBP Range Siting Board Proceedings

RSD Reduced Safety Distance

RSIT(A) Range Safety Inspection Team (Army)

RSO Range Safety Officer

RSO(ATC)

Range Safety Officer (Air Traffic Control)

RSO(NGS)

Range Safety Officer (Naval Gunfire Support)

RSP Render Safe Procedure

RSPSC Range Safety Policy Sub--Committee
RSRWG Range Safety Review Working Group

RTAAB Range and Training Area Audit Board (formerly

RTADB)

RTADB Range and Training Area Development Board

RW Rotary Wing

RW(CSW) Rotary Wing (Crew Served Weapons)

RW(IWS) Rotary Wing (Integrated Weapon Systems)

S

SA Small Arm(s)

SAA Small Arms Ammunition

SACLOS Semi--Automatic Command to Line Of Sight
SAME Safety Assessment and Monitoring Equipment

SASC Small Arms School Corps

SAT Small Arms Trainer

SATO Senior Ammunition Technical Officer

SAU Safety and Arming Unit

SAWG Surface to Air Working Group
SBSD Special Burst Safety Distance

SCAMBL Simulator Chemical Attack Multi--Barrelled

Launcher

SCC Sea Cadet Corps

SC105A Type of concrete post

SCG Specialist Construction Group

SCOTS(A) Standing Committee On Training Safety (Army)

SD Standard Deviation

SDA/Z Sea Danger Area/Zone

SDD Self Destruct Device

SDR Site Directors Representative

Sea WIFS Sea Viewing Wide Field of View Sensor

SF Sustained Fire
SF Security Force
SF Special Forces

SID Significant Injury or Damage

SLR Self Loading Rifle
SME Subject Matter Expert
SMG Sub--Machine Gun

smk smoke

SNCO Senior Non--Commissioned Officer

SO Standing Order

SOR Statement Of Requirement

SPHR Standard Predicted Horizontal Range
SRCO Senior Range Conducting Officer

SS105A Type of steel post

Abbrev - 16 Apr 08

SSA Senior Safety Advisor
SSD Special Safety Distance

STANAG Standardised NATO Agreement

STA&SPSS Surveillance, Target Acquisition and Special

Project Support Systems

STC Strike Command (now Air Command)

STPS Static Target Projection System

SW105A
 SW
 Special Weapons
 SWO
 Staff Warfare Officer
 SWS
 Signals Works Services

2SL Second Sea Lord

2SL/CNH Second Sea Lord Commander in Chief Naval

Home Command

2 PUS Second Permanent Under Secretary

T

TA Training Area

TAG Training Advisory Group

TAG (SASC) TAG Small Arm School Corps

tan tangent (trigonometric)

TAS(RE) Technical Advisory Section (Royal Engineers) **TAVRA** Territorial Auxiliary and Volunteer Reserve

Association (now RFCA)

TB Technical Bulletin

TBSR Team Battle Shooting Range

TCO Trial Conducting Officer

TE Tangent Elevation

TEA/Z Total Energy Area/Zone

TER Temporary Exercise Range

TERP Test, Evaluation, Research and Proof

T&E Test & Evaluation

TES Tactical Engagement Simulation

TESD Test and Evaluation Support Division

TEST Trials, Evaluation Services and Targets

(formerly Defence Test and Evaluation Group)

TI Thermal Imaging
TM Training Manual

TM Target Marking
TNT Tri Nitro Toluene
TO Technical Officer
TO Training Objective

TOPL Training On Private Land

TOW Tube launched Optical tracked Wire guided

TP&N Triple Phase & Neutral
TP/T Training Projectile /Traced
TSM Trials Safety Manager

TSC(L) Training Support Command (Land)

TSO Technical Staff Officer

TV Television

TVE Tube Vent Electric

TWA Time Weighted Average

U

UAS Unmanned Aircraft System
UAV Unmanned Aerial Vehicle

UAVS Unmanned Aerial Vehicle System
UCAV Unmanned Combat Aerial Vehicle

UDI User Demolition Instruction

UGL Under slung Grenade Launcher

UK United Kingdom
ULC Unit Load Carrier

ULS Unit Load Specification

URSO Unit Ranges Specialist Officer

UK DAUGUnited Kingdom Danger Area User Group

UN United Nations

USA United States of America

UXO Unexploded Explosive Ordnance

٧

v volt(s)

VDU Visual Display Unit

VFSO Visual Flight Safety Officer

Abbrev - 18 Apr 08

VHI Visual Hit Indicator

VLSMS Vehicle Launched Scatterable Mine System

VMMG Vehicle Mounted Machine Gun

VT Variable Time

VTT Video Target Trainer

W

WBP Water and Boil Proof grade plywood

WDA Weapon Danger Area

WDAAPS Weapon Danger Area Assessment and

Prediction System

WDA/Z Weapon Danger Area/Zone

WP White Phosphorous

WR War Reserve
WS Weapon System

WSM Works Service Manager
WUF Weapon Unloading Facility

X

Y

yd(s) yard(s)

Ζ

Apr 08 Abbrev - 19