LowFER

LowFER (**Low-F**requency **E**xperimental **R**adio) refers to experimental radio communication practiced by hobbyists on <u>frequencies</u> below 300 kHz, a part of the <u>radio spectrum</u> known as <u>low frequency</u>. The practitioners are known as "*LowFERs*".

Contents

Practices

Equipment

Similar activities

LF amateur radio allocation

MedFER

HIFER

See also

References

External links

Practices

LowFER operation is practiced in the <u>United States</u> and <u>Canada</u> on <u>radio frequencies</u> between 160 <u>kHz</u> and 190 kHz $^{[1]}$ which is sometimes referred to as the **1750-meter band**. $^{[2]}$ and in the past as the **1875 Meters band** $^{[3]}$ In much of the world, including the U.S. there is an adjacent <u>amateur radio</u> band <u>at 136–138 kHz</u> with a number of U.S. <u>amateur radio operators</u> authorized to transmit on that frequency (notification and lack of objection from power utilities is required). Radio operators who conduct low-frequency experimental operations on the LowFER band are known as LowFERs (pronounced "loafers"). Many LowFERs are also licensed <u>radio amateurs</u>, although an amateur radio license is not required for LowFER communications in those countries in Region 2, as long as the power is below a nationally prescribed limit, often 1 <u>W</u>. $^{[4][5]}$

Equipment

Practical antennas at these frequencies are much shorter than the wavelength, making it difficult to efficiently radiate much useful power. By current U.S. and Canadian regulations, LowFER transmitters may not use antennas longer than 50 feet or final RF stage input powers that exceeds 1 watt. Telegraphy and digital modes are the most commonly used for communications, but speech transmission via amplitude modulation (AM) or single-sideband modulation (SSB) is also allowed. Even with such short antennas and low transmit power, LowFER stations have been heard at distances approaching 1,000 miles by listeners using sophisticated receiving setups. [4]

Similar activities

LF amateur radio allocation

In Europe, and generally in ITU Region 1, the LowFER frequency range (160–190 kHz) is used for broadcasting and is unavailable for two-way communications use. In the <u>United Kingdom</u> there was an allocation for radio amateurs at 73 kHz from 1998–2002. The <u>International Telecommunication Union</u>'s 2007 <u>World Radiocommunication Conference</u> (WRC-07) in <u>Geneva</u> agreed a secondary allocation 135.7–137.8 kHz (the so-named 2200 meter band) to the Amateur Service on 9 November 2007, marking the first time since amateur allocations began that there has been an amateur band below the <u>Medium Wave</u> broadcast band. Transmitter power is limited to one watt <u>ERP</u> (meaning an inefficient antenna can be fed a higher power).

MedFER

In the U.S., license-free operation is also allowed on the medium frequency band, also known as the AM Broadcast Band. Similar to LowFER, MedFER is medium-frequency experimental radio. MedFER enthusiasts operate under FCC Part 15 rules using 0.1 W (a tenth of a watt) and a three-meter-long antenna between 510 kHz and 1705 kHz, coinciding with the U.S. <u>AM radio</u> band. [4]

HIFER

HiFER is high frequency experimental radio operating within a 14 kHz-wide band centered at 13.56 MHz. This frequency range is allocated to <u>industrial</u>, <u>scientific and medical</u> uses as well as Low Power Communication devices under <u>FCC Part 15</u> rules where a small level of radio frequency radiation is allowed without licensing. (See <u>RFID</u> for other uses of this frequency).

See also

- 630-meter band
- 2200-meter band

References

- 1. "VE3OT Low Bands" (http://www.larc.ca/PDF/meetings/VE3OTLowBands.pdf) (PDF). larc.ca. London (Ontario Canada) Amateur Radio Club. Retrieved 23 October 2021.
- 2. White, G.E. (April 1968). "1750 meters Some data on an undiscovered experimental band". *CQ*: 31–32, 120.
- 3. Ellen White, W1YL, ed. (1976). *ARRL Ham Radio Operating Guide*. Newington, CT: American Radio Relay League. pp. 36–37.
- 4. "(LF) Low frequency" (http://www.arrl.org/lf-low-frequency). ARRL.
- 5. Graf, Rudolf F.; Sheets, William (2001). <u>Build Your Own Low-power Transmitters: Projects for the electronics experimenter</u> (https://books.google.com/books?id=Tc_ACUbCqqQC&pg=PA 267). Newnes. p. 267. <u>ISBN</u> 978-0-7506-7244-3.
- 6. "What is 'Part 15' ?" (http://www.lwca.org/sitepage/part15/index-what.htm). Longwave Club Of America.

External links

Longwave Club of America (http://www.lwca.org/)

Medfer site (http://ka7oei.com/)

Retrieved from "https://en.wikipedia.org/w/index.php?title=LowFER&oldid=1090308077"

This page was last edited on 28 May 2022, at 19:32 (UTC).

Text is available under the Creative Commons Attribution-ShareAlike License 3.0; additional terms may apply. By using this site, you agree to the Terms of Use and Privacy Policy. Wikipedia® is a registered trademark of the Wikimedia Foundation, Inc., a non-profit organization.