

Totally Integrated Automation Portal

FC_Input_Interface [FC1]

FC_Input_Interface Properties

General

Name	FC_Input_Interface	Number	1	Type	FC	Language	SCL
Numbering	Manual						

Information

Title		Author		Comment		Family	
Version	0.1	User-defined ID					

Name	Data type	Default value	Comment
Input			
Output			
InOut			
Temp			
Constant			
▼ Return			
FC_Input_Interface	Void		

```
0001 // Input interface connection
0002
0003 "Transfer_DB".Safety.SafetyOk := "SafetyOk";
0004 "Transfer_DB".Safety.Emergency := "Emergency";
0005 "Transfer_DB".Safety.Door1 := "Door_1";
0006 "Transfer_DB".Safety.Door2 := "Door_2";
0007 "Transfer_DB".Safety.Barrier1 := "Barrier_1";
0008 "Transfer_DB".Safety.Barrier2 := "Barrier_2";
0009 "Transfer_DB".Comands.ACK := "ACK";
0010 "Transfer_DB".ComandsAutomatic := "Automatic";
0011 "Transfer_DB".ComandsConfirmAuto := "ConfirmAuto";
0012 "Transfer_DB".ComandsManualMaintenance := "ManualMaintenance";
0013 "Transfer_DB".ComandsManualQ1 := "ManualQ1";
0014 "Transfer_DB".ComandsResetFault := "ResetFault";
0015
0016 "Transfer_DB".Tab1.SNS_Presence1 := "TAB1_SNS_Presence1";
0017 "Transfer_DB".Tab1.SNS_Presence2 := "TAB1_SNS_Presence2";
0018 "Transfer_DB".Tab1.SNS_TableDown := "TAB1_SNS_TableDown";
0019 "Transfer_DB".Tab1.SNS_TableMiddle := "TAB1_SNS_TableMiddle";
0020 "Transfer_DB".Tab1.SNS_TableTop := "TAB1_SNS_TableTop";
0021 "Transfer_DB".Tab1.SNS_TermicShoutdownElevation := "TAB1_SNS_TermicShoutdownElevation";
0022 "Transfer_DB".Tab1.SNS_TermicShoutdownTransport := "TAB1_SNS_TermicShoutdownTransport";
0023
0024 "Transfer_DB".Tab2.SNS_Presence1 := "TAB2_SNS_Presence1";
0025 "Transfer_DB".Tab2.SNS_Presence2 := "TAB2_SNS_Presence2";
0026 "Transfer_DB".Tab2.SNS_TableDown := "TAB2_SNS_TableDown";
0027 "Transfer_DB".Tab2.SNS_TableMiddle := "TAB2_SNS_TableMiddle";
0028 "Transfer_DB".Tab2.SNS_TableTop := "TAB2_SNS_TableTop";
0029 "Transfer_DB".ChainTransfer.SNS_MaseratiTab2 := "TAB2_SNS_Maserati";
0030 "Transfer_DB".Tab2.SNS_TermicShoutdownElevation := "TAB2_SNS_TermicShoutdownElevation";
0031 "Transfer_DB".Tab2.SNS_TermicShoutdownTransport := "TAB2_SNS_TermicShoutdownTransport";
0032
0033 "Transfer_DB".Tab3.SNS_Presence1 := "TAB3_SNS_Presence1";
0034 "Transfer_DB".Tab3.SNS_Presence2 := "TAB3_SNS_Presence2";
0035 "Transfer_DB".Tab3.SNS_TableDown := "TAB3_SNS_TableDown";
0036 "Transfer_DB".Tab3.SNS_TableMiddle := "TAB3_SNS_TableMiddle";
0037 "Transfer_DB".Tab3.SNS_TableTop := "TAB3_SNS_TableTop";
0038 "Transfer_DB".Tab3.SNS_TermicShoutdownElevation := "TAB3_SNS_TermicShoutdownElevation";
0039 "Transfer_DB".Tab3.SNS_TermicShoutdownTransport := "TAB3_SNS_TermicShoutdownTransport";
0040
0041 "Transfer_DB".Tab4.SNS_Presence1 := "TAB4_SNS_Presence1";
0042 "Transfer_DB".Tab4.SNS_Presence2 := "TAB4_SNS_Presence2";
0043 "Transfer_DB".Tab4.SNS_TableDown := "TAB4_SNS_TableDown";
0044 "Transfer_DB".Tab4.SNS_TableMiddle := "TAB4_SNS_TableMiddle";
0045 "Transfer_DB".Tab4.SNS_TableTop := "TAB4_SNS_TableTop";
0046 "Transfer_DB".Tab4.SNS_TermicShoutdownElevation := "TAB4_SNS_TermicShoutdownElevation";
0047 "Transfer_DB".Tab4.SNS_TermicShoutdownTransport := "TAB4_SNS_TermicShoutdownTransport";
0048
0049 "Transfer_DB".Tab5.SNS_Presence1 := "TAB5_SNS_Presence1";
0050 "Transfer_DB".Tab5.SNS_Presence2 := "TAB5_SNS_Presence2";
0051 "Transfer_DB".Tab5.SNS_TableDown := "TAB5_SNS_TableDown";
0052 "Transfer_DB".Tab5.SNS_TableMiddle := "TAB5_SNS_TableMiddle";
0053 "Transfer_DB".Tab5.SNS_TableTop := "TAB5_SNS_TableTop";
0054 "Transfer_DB".Tab5.SNS_TermicShoutdownElevation := "TAB5_SNS_TermicShoutdownElevation";
0055 "Transfer_DB".Tab5.SNS_TermicShoutdownTransport := "TAB5_SNS_TermicShoutdownTransport";
```

Symbol	Address	Type	Comment
"ACK"	%I1.3	Bool	
"Automatic"	%I1.0	Bool	
"Barrier_1"	%IO.4	Bool	
"Barrier_2"	%IO.5	Bool	
"ConfirmAuto"	%I1.1	Bool	
"Door_1"	%IO.2	Bool	
"Door_2"	%IO.3	Bool	
"Emergency"	%IO.1	Bool	
"ManualMaintenance"	%IO.7	Bool	

Totally Integrated Automation Portal			
Symbol	Address	Type	Comment
"ManualQ1"	%I0.6	Bool	
"ResetFault"	%I1.2	Bool	
"SafetyOk"	%I0.0	Bool	
"TAB1_SNS_Presence1"	%I8.0	Bool	
"TAB1_SNS_Presence2"	%I8.1	Bool	
"TAB1_SNS_TableDown"	%I8.4	Bool	
"TAB1_SNS_TableMiddle"	%I8.3	Bool	
"TAB1_SNS_TableTop"	%I8.2	Bool	
"TAB1_SNS_TermicShoutdownElevation"	%I8.5	Bool	
"TAB1_SNS_TermicShoutdownTransport"	%I8.6	Bool	
"TAB2_SNS_Maserati"	%I12.7	Bool	
"TAB2_SNS_Presence1"	%I12.0	Bool	
"TAB2_SNS_Presence2"	%I12.1	Bool	
"TAB2_SNS_TableDown"	%I12.4	Bool	
"TAB2_SNS_TableMiddle"	%I12.3	Bool	
"TAB2_SNS_TableTop"	%I12.2	Bool	
"TAB2_SNS_TermicShoutdownElevation"	%I12.5	Bool	
"TAB2_SNS_TermicShoutdownTransport"	%I12.6	Bool	
"TAB3_SNS_Presence1"	%I16.0	Bool	
"TAB3_SNS_Presence2"	%I16.1	Bool	
"TAB3_SNS_TableDown"	%I16.4	Bool	
"TAB3_SNS_TableMiddle"	%I16.3	Bool	
"TAB3_SNS_TableTop"	%I16.2	Bool	
"TAB3_SNS_TermicShoutdownElevation"	%I16.5	Bool	
"TAB3_SNS_TermicShoutdownTransport"	%I16.6	Bool	
"TAB4_SNS_Presence1"	%I20.0	Bool	
"TAB4_SNS_Presence2"	%I20.1	Bool	
"TAB4_SNS_TableDown"	%I20.4	Bool	
"TAB4_SNS_TableMiddle"	%I20.3	Bool	
"TAB4_SNS_TableTop"	%I20.2	Bool	
"TAB4_SNS_TermicShoutdownElevation"	%I20.5	Bool	
"TAB4_SNS_TermicShoutdownTransport"	%I20.6	Bool	
"TAB5_SNS_Presence1"	%I24.0	Bool	
"TAB5_SNS_Presence2"	%I24.1	Bool	
"TAB5_SNS_TableDown"	%I24.4	Bool	
"TAB5_SNS_TableMiddle"	%I24.3	Bool	
"TAB5_SNS_TableTop"	%I24.2	Bool	
"TAB5_SNS_TermicShoutdownElevation"	%I24.5	Bool	
"TAB5_SNS_TermicShoutdownTransport"	%I24.6	Bool	
"Transfer_DB".ChainTransfer.SNS_MaseratiTab2		Bool	
"Transfer_DB".Comands.ACK		Bool	
"Transfer_DB".ComandsAutomatic		Bool	
"Transfer_DB".Comands.ConfirmAuto		Bool	
"Transfer_DB".Comands.ManualMaintenance		Bool	
"Transfer_DB".Comands.ManualQ1		Bool	
"Transfer_DB".Comands.ResetFault		Bool	
"Transfer_DB".Safety.Barrier1		Bool	
"Transfer_DB".Safety.Barrier2		Bool	
"Transfer_DB".Safety.Door1		Bool	
"Transfer_DB".Safety.Door2		Bool	
"Transfer_DB".Safety.Emergency		Bool	
"Transfer_DB".Safety.SafetyOk		Bool	
"Transfer_DB".Tab1.SNS_Presence1		Bool	
"Transfer_DB".Tab1.SNS_Presence2		Bool	
"Transfer_DB".Tab1.SNS_TableDown		Bool	
"Transfer_DB".Tab1.SNS_TableMiddle		Bool	
"Transfer_DB".Tab1.SNS_TableTop		Bool	
"Transfer_DB".Tab1.SNS_TermicShoutdownElevation		Bool	
"Transfer_DB".Tab1.SNS_TermicShoutdownTransport		Bool	
"Transfer_DB".Tab2.SNS_Presence1		Bool	
"Transfer_DB".Tab2.SNS_Presence2		Bool	
"Transfer_DB".Tab2.SNS_TableDown		Bool	
"Transfer_DB".Tab2.SNS_TableMiddle		Bool	
"Transfer_DB".Tab2.SNS_TableTop		Bool	
"Transfer_DB".Tab2.SNS_TermicShoutdownElevation		Bool	
"Transfer_DB".Tab2.SNS_TermicShoutdownTransport		Bool	
"Transfer_DB".Tab3.SNS_Presence1		Bool	
"Transfer_DB".Tab3.SNS_Presence2		Bool	
"Transfer_DB".Tab3.SNS_TableDown		Bool	
"Transfer_DB".Tab3.SNS_TableMiddle		Bool	
"Transfer_DB".Tab3.SNS_TableTop		Bool	

Totally Integrated Automation Portal			
Symbol	Address	Type	Comment
"Transfer_DB".Tab3.SNS_Termic-ShutdownElevation		Bool	
"Transfer_DB".Tab3.SNS_Termic-ShutdownTransport		Bool	
"Transfer_DB".Tab4.SNS_Presence1		Bool	
"Transfer_DB".Tab4.SNS_Presence2		Bool	
"Transfer_DB".Tab4.SNS_TableDown		Bool	
"Transfer_DB".Tab4.SNS_TableMiddle		Bool	
"Transfer_DB".Tab4.SNS_TableTop		Bool	
"Transfer_DB".Tab4.SNS_Termic-ShutdownElevation		Bool	
"Transfer_DB".Tab4.SNS_Termic-ShutdownTransport		Bool	
"Transfer_DB".Tab5.SNS_Presence1		Bool	
"Transfer_DB".Tab5.SNS_Presence2		Bool	
"Transfer_DB".Tab5.SNS_TableDown		Bool	
"Transfer_DB".Tab5.SNS_TableMiddle		Bool	
"Transfer_DB".Tab5.SNS_TableTop		Bool	
"Transfer_DB".Tab5.SNS_Termic-ShutdownElevation		Bool	
"Transfer_DB".Tab5.SNS_Termic-ShutdownTransport		Bool	