

Totally Integrated Automation Portal

FC_Output_Interface [FC2]

FC_Output_Interface Properties

General

Name	FC_Output_Interface	Number	2	Type	FC	Language	SCL
Numbering	Manual						

Information

Title		Author		Comment		Family	
Version	0.1	User-defined ID					

Name	Data type	Default value	Comment
Input			
Output			
InOut			
Temp			
Constant			
▼ Return			
FC_Output_Interface	Void		

```
0001 // Output interface connection
0002
0003 "Transfer_DB".Comands.LightsAutomatic := "Automatic_Light";
0004 "Transfer_DB".Comands.Lights.Fault := "Fault_Light";
0005 "Transfer_DB".Comands.Lights.Manuale := "Manual_Light";
0006 "Transfer_DB".Comands.Lights.Warning := "Warning_Light";
0007 "Transfer_DB".Comands.Lights.Siren := "Siren";
0008
0009 "Transfer_DB".ChainTransfer.ACT_MotorBackward := "Chain_Motor_Backward";
0010 "Transfer_DB".ChainTransfer.ACT_MotorForward := "Chain_Motor_Fordward";
0011
0012 "Transfer_DB".Tab1.ACT_MotorBackward := "TAB1_Backward";
0013 "Transfer_DB".Tab1.ACT_MotorFordward := "TAB1_Fordward";
0014 "Transfer_DB".Tab1.ACT_MotorLevel := "TAB1_Elevation";
0015
0016 "Transfer_DB".Tab2.ACT_MotorBackward := "TAB2_Backward";
0017 "Transfer_DB".Tab2.ACT_MotorFordward := "TAB2_Fordward";
0018 "Transfer_DB".Tab2.ACT_MotorLevel := "TAB2_Elevation";
0019
0020 "Transfer_DB".Tab3.ACT_MotorBackward := "TAB3_Backward";
0021 "Transfer_DB".Tab3.ACT_MotorFordward := "TAB3_Fordward";
0022 "Transfer_DB".Tab3.ACT_MotorLevel := "TAB3_Elevation";
0023
0024 "Transfer_DB".Tab4.ACT_MotorBackward := "TAB4_Backward";
0025 "Transfer_DB".Tab4.ACT_MotorFordward := "TAB4_Fordward";
0026 "Transfer_DB".Tab4.ACT_MotorLevel := "TAB4_Elevation";
0027
0028 "Transfer_DB".Tab5.ACT_MotorBackward := "TAB5_Backward";
0029 "Transfer_DB".Tab5.ACT_MotorFordward := "TAB5_Fordward";
0030 "Transfer_DB".Tab5.ACT_MotorLevel := "TAB5_Elevation";
```

Symbol	Address	Type	Comment
"Automatic_Light"	%Q0.1	Bool	
"Chain_Motor_Backward"	%Q0.6	Bool	
"Chain_Motor_Fordward"	%Q0.5	Bool	
"Fault_Light"	%Q0.3	Bool	
"Manual_Light"	%Q0.0	Bool	
"Siren"	%Q0.4	Bool	
"TAB1_Backward"	%Q32.2	Bool	
"TAB1_Elevation"	%Q32.0	Bool	
"TAB1_Fordward"	%Q32.1	Bool	
"TAB2_Backward"	%Q32.5	Bool	
"TAB2_Elevation"	%Q32.3	Bool	
"TAB2_Fordward"	%Q32.4	Bool	
"TAB3_Backward"	%Q36.0	Bool	
"TAB3_Elevation"	%Q32.6	Bool	
"TAB3_Fordward"	%Q32.7	Bool	
"TAB4_Backward"	%Q36.3	Bool	
"TAB4_Elevation"	%Q36.1	Bool	
"TAB4_Fordward"	%Q36.2	Bool	
"TAB5_Backward"	%Q36.6	Bool	
"TAB5_Elevation"	%Q36.4	Bool	
"TAB5_Fordward"	%Q36.5	Bool	
"Transfer_DB".ChainTrans-fer.ACT_MotorBackward		Bool	
"Transfer_DB".ChainTrans-fer.ACT_MotorForward		Bool	
"Transfer_DB".Comands.Lights.Auto-matic		Bool	
"Transfer_DB".Comands.Lights.Fault		Bool	
"Transfer_DB".Comands.Lights.Man-uale		Bool	
"Transfer_DB".Comands.Lights.Siren		Bool	
"Transfer_DB".Comands.Lights.Warn-ing		Bool	
"Transfer_DB".Tab1.ACT_MotorBack-ward		Bool	

Totally Integrated Automation Portal			
Symbol	Address	Type	Comment
"Transfer_DB".Tab1.ACT_MotorFord-ward		Bool	
"Transfer_DB".Tab1.ACT_MotorLevel		Bool	
"Transfer_DB".Tab2.ACT_MotorBack-ward		Bool	
"Transfer_DB".Tab2.ACT_MotorFord-ward		Bool	
"Transfer_DB".Tab2.ACT_MotorLevel		Bool	
"Transfer_DB".Tab3.ACT_MotorBack-ward		Bool	
"Transfer_DB".Tab3.ACT_MotorFord-ward		Bool	
"Transfer_DB".Tab3.ACT_MotorLevel		Bool	
"Transfer_DB".Tab4.ACT_MotorBack-ward		Bool	
"Transfer_DB".Tab4.ACT_MotorFord-ward		Bool	
"Transfer_DB".Tab4.ACT_MotorLevel		Bool	
"Transfer_DB".Tab5.ACT_MotorBack-ward		Bool	
"Transfer_DB".Tab5.ACT_MotorFord-ward		Bool	
"Transfer_DB".Tab5.ACT_MotorLevel		Bool	
"Warning_Light"	%Q0.2	Bool	