

Based on the Atlantis system application list in your image, I can give **practical starting values**, but not true “optimum” values without knowing the water quality, UVT, target log reduction, lamp type, chamber model, and required contact/flow constraints. The best I can do from the application names alone is a **typical engineering setpoint range** for each use case.[image.jpg](#)

Recommended starting ranges

Application	Dose	UVT	Power	Flow
AOP (Advanced Oxidation Processes)	800–2,000 mJ/cm ²	80–95%	High	Low–Medium
Biofouling Protection	30–100 mJ/cm ²	85–95%	Low–Medium	Medium–High
Boiler Feed Water Treatment	40–120 mJ/cm ²	90–98%	Low–Medium	Medium
Bound Chlorine Removal	200–600 mJ/cm ²	85–98%	Medium	Medium
Contaminant Removal	100–300 mJ/cm ²	80–95%	Medium	Medium
Cooling Water Treatment	30–100 mJ/cm ²	70–90%	Low–Medium	High
Dechlorination	200–800 mJ/cm ²	85–98%	Medium	Medium
Drinking Water	30–40 mJ/cm ²	90–98%	Low	Low–Medium
Effluent Water	100–300 mJ/cm ²	50–80%	Medium–High	Medium
Effluent / Reuse Water Treatment	100–400 mJ/cm ²	50–80%	Medium–High	Medium
Intake Water	40–120 mJ/cm ²	70–95%	Low–Medium	High
Intake/Service Water Treatment	40–120 mJ/cm ²	70–95%	Low–Medium	High
Open Channel	40–120 mJ/cm ²	60–90%	Medium	High

Application	Dose	UVT	Power	Flow
Ozone Destruction	500–2,000 mJ/cm ²	70– 95%	High	Low– Medium
Pasteurized Water Equivalent	180–400 mJ/cm ²	90– 98%	Medium	Low– Medium
Post-Granular Activated Carbon Treatment	30–100 mJ/cm ²	90– 98%	Low	Medium
Process Water Treatment	60–200 mJ/cm ²	80– 98%	Medium	Medium
Product Water Treatment	40–120 mJ/cm ²	90– 98%	Low– Medium	Medium
Purified Water (PW) Loop Disinfection	150–400 mJ/cm ²	90– 98%	Medium	Low– Medium
Recirculation	100–300 mJ/cm ²	80– 98%	Medium	Medium
Reuse	100–400 mJ/cm ²	50– 80%	Medium– High	Medium
RO Protection	40–120 mJ/cm ²	85– 98%	Low– Medium	High
Simple Syrup	200–800 mJ/cm ²	90– 98%	Medium	Low
Wastewater Treatment	100–400 mJ/cm ²	40– 80%	Medium– High	Medium
Water for Injection (WFI) Loop Disinfection	250–500 mJ/cm ²	90– 98%	Medium– High	Low– Medium
Well-Boat	100–300 mJ/cm ²	70– 95%	Medium	Medium– High

How to read these values

- **Dose** is the UV energy delivered, usually the main target for disinfection or oxidation.[image.jpg](#)
- **UVT** is UV transmittance; lower UVT means the water absorbs more UV, so you usually need more power or lower flow.[image.jpg](#)
- **Power** and **flow** are tradeoffs: higher flow needs more power or more reactors in parallel to keep the same dose.[image.jpg](#)

Important note

These are **starting design ranges**, not final validated settings. The real optimum depends on:

- inlet UVT,
- turbidity and color,
- target microorganism or contaminant,
- lamp technology,
- reactor geometry,
- required compliance standard.

For Atlantis setup work, the safest approach is to use these as **template values** and then fine-tune per site water analysis and validation testing.[image.jpg](#)

Would you like me to turn this into a clean Excel-style table with **exact suggested setpoints** for each application, including separate columns for **low / medium / high UVT cases**?