PRE-PURCHASE INSPECTION CHECKLIST

# Mercedes-Benz G 63 AMG 6×6

2013–2015 · W463 · 6×6 portal axles · 5 locking diffs

BOXYTRUCKS

## CHECK BEFORE YOU BUY

- [ ] **Factory truck or conversion?**
  Aftermarket 6×6 conversions of ordinary G 550s, G 63s and G 65s exist and have sold on Bring a Trailer. Factory trucks sold there carry chassis numbers such as WDB4632721X..., plus overhead tyre-pressure controls and a VDO auxiliary fuel gauge. Ask for Mercedes build paperwork.

- [ ] **US paperwork**
  In the US, check the NHTSA Show or Display exemption letter, the EPA conversion label and whether NHTSA has approved the transfer. A clean title alone doesn't make it legal to drive.

- [ ] **Tyre inflation system**
  Run the pressures down and back up. Mercedes quotes under 20 seconds from 0.5 to 1.8 bar. Slow inflation or a pressure drop overnight points to rotary seals or lines; one Bring a Trailer truck had its CTIS seals and lines replaced.

- [ ] **Portal hubs and seals**
  Look for gear oil at each of the six hubs and the pinion seals. Ask when the hubs, differentials and transfer case were last serviced. Bring a Trailer service records mention a replaced centre-axle planetary gear and pinion seal on one truck.

- [ ] **All five lockers**
  Engage all three stages and confirm every indicator. The locks are supposed to engage quickly, even in high range, and slow or partial engagement needs investigating.

- [ ] **The G 63 engine underneath**
  It's an M157, so check the same things as on a G 63: oil consumption, coolant at the turbo lines, oil in the cam-magnet connectors and plug or coil misfires.

- [ ] **Modifications and tunes**
  Brabus, Weistec and other tuners have modified these trucks. Find out exactly what has changed, including engine, exhaust, suspension and tyre size, and whether the original parts come with the truck.

- [ ] **Tyre age**
  37-inch beadlock tyres in the right size are a special order. Read the date codes; a low-mileage truck can easily have tyres ten years old.

## IS IT THE REAL THING?

- [ ] **Chassis number**
  Factory trucks on Bring a Trailer carry chassis numbers such as WDB4632721X.... Ask for Mercedes build paperwork, and treat a standard G 550/G 63/G 65 VIN on a six-wheeler as a conversion.

- [ ] **Overhead console**
  Factory trucks have tyre-pressure switches, twin air-pressure gauges and an auxiliary fuel gauge in the overhead console.
- [ ] **Running gear**
  Three portal axles, 18-inch two-piece beadlocks, carbon-fibre arch extensions, a stainless roll bar in the bed and compressor tanks in the rear arches.
- [ ] **Lockers**
  Three locker switches that operate five differential locks in stages; MotorTrend notes they engage even in high range.
- [ ] **US import paperwork**
  US trucks should carry an EPA conversion label (G&K Automotive Conversion) and an NHTSA Show or Display exemption letter.

## NOTES

From the full guide at https://boxytrucks.com/models/g-class/g63-6×6/, with sources. Recalls follow the VIN: check at nhtsa.gov/recalls. General information only, not a professional inspection; see boxytrucks.com/about/disclaimer/. © BoxyTrucks