

The Hidden Art Of SMART PRODUCT DESIGN And MANUFACTURING

In electronics manufacturing, even a perfect prototype can fail without a robust Bill of Materials. Smart BoM optimisation, disciplined design-for-manufacturing, and close attention to often-overlooked assembly details can turn fragile plans into market-ready successes.



SRINIVAS
PARIKSHITH is
CEO, Auckam
Technologies

Success in electronics manufacturing is not defined solely by a flawless schematic or a working prototype. It depends on the resilience of every stage of the process. The Bill of Materials (BoM) may appear to be a dry inventory list, but it is the heartbeat of production. A single overlooked component can derail a product launch, erase months of work, and drain budgets faster than a reflow oven at peak load. Supply chain volatility, moisture sensitivity, compliance pitfalls, and subtle PCB assembly details—such as fiducials and apertures—can quietly determine whether a product succeeds or fails.

At times, a BoM is merely a cost list. At others, it becomes a ticking time BoM waiting to explode at the worst possible moment.

Consider a common scenario. A promising IoT product is ready. The prototype works flawlessly, performance meets expectations, and the first small batch ships without a single hiccup. Everything appears perfect. Then the twist appears.

Hidden in the BoM is a small off-the-shelf, no-brand switch—picked up online with little scrutiny. When a 10,000-piece order arrives, sourcing that exact switch becomes impossible. The supplier has vanished. The closest available alternative carries an eight-month lead time.

The only option is a redesign. By the time the redesign is completed and sourcing stabilises, the order is gone. The result: a ₹2.2 million loss—triggered by a single overlooked component.

The four pillars of BoM optimisation

BoM optimisation is far more than a procurement exercise. It combines risk management, quality assurance, and long-term product strategy. A single overlooked component can derail months of work and cost millions. In practice, BoM optimisation is not just about cost control—it is about product survivability. Some tips:

- 1. Financial.** Reduce product cost without compromising quality
- 2. Compliance.** Ensure components meet required standards such as RoHS, lead-free, medical, defence, and export certifications
- 3. Technical.** Monitor end-of-life parts, shelf-life issues, and NRND (Not Recommended for New Design) components
- 4. Manufacturability.** Avoid parts that are difficult or expensive to assemble

Let's break those down. When sourcing components, always keep a cost-effective and reliable alternative in mind. High-volume microcontrollers such as the ATmega2560 are more likely to appear in grey markets, where counterfeit, remarked, or QC-rejected parts can circulate through secondary channels; so buying outside authorised channels is a gamble. Never rely on a single supplier—having two or even three can save you from this kind of supply nightmare. If you are developing multiple products, standardise part numbers for common components such as resistors, capacitors, and microcontrollers; this not




Fig. 1: Smart sourcing strategies for a resilient electronics BoM