

```

Code1(7) = &H00
Code1(8) = &H1E
On Int0 Int0_int
Enable Interrupts
Enable Int0
'enable the interrupt
E = 0
'flag for number of attempts
W = 65000
Do
Set Portd.4
'initially the relay is off
Loop
Int0_int:
Disable Interrupts
Disable Int0
Flag = 0
Wait 1
Iwreset
'reset the device
Print "Button Access Code:";
If Err = 0 And E <= 6 Then
'check DS1990A is present
Iwrite &H33
'present, read code
'read ROM command
Ar(1) = Iwread(8)
For I = 1 To 8
Print Hex(ar(i));
'print output

```

```

Next
Print
For I = 1 To 8
If Ar(i) <> Code1(i) Then
Set Portd.4
Flag = 0
'access not allowed
For A = 10 To 1000
Sound Portd.6 ,
4 , A
Next
Print "Access Code Not
Match:Access Denied";
Print
E = E + 1
Print E;
Print ":";
Exit For
Else
Flag = 1
End If
Next
If Flag = 1 Then
E = 0
Print Err;
Reset Portd.4
'access allowed
Sound Portd.6 , 10 , 50000
'siren on port PD6
Print "--Access Allowed";

```

```

Print
Wait 2
End If
Else
Set Portd.4
'access not allowed
For A = 50 To 500
Sound Portd.6 ,
1 , A
Next
Print "Rejected";
Print
If E = 5 Then
'5 attempts of correctness
Do
Sound Portd.6 , 4 , W
'SOUND pin, duration, pulses
W = W + 1
If W > 1000 Then
W = 10
End If
Loop
End If
End If
'End If
Enable Int0
Enable Interrupts
Return

```

●

support@  
efyindia.com

Do you have a query,  
suggestion or a complaint?

You can e-mail it to  
**support@efyindia.com** and we  
will take care of the rest.

**ElectronicsForYou**

www.electronicsforu.com

**ELECTRONICS**  
BAZAAR

www.efyindia.com

**LINUX**  
forum

www.linuxforu.com

**BenefIT**  
Tech

www.benefitmag.com

**FACTS**  
FOR YOU

www.flymag.com

**EFY**  
UNIVERSITY

www.efyindia.com