Summary Information

File name : test
Version : 6.5.0
Date : 27/05/2026
Serial number of the Dash that this configuration was last sent to : 0

Configuration Comments

*** None ***

Used Channels

Comms RS232-2 Diag
GPS Time
GPS Latitude
GPS Longitude
GPS Speed
GPS Heading
GPS Date
GPS Sats Used
GPS Altitude
CAN Comms Diag 0x640
Engine Speed
Inlet Manifold Pressure
Inlet Air Temperature
Throttle Position
Fuel Volume
Fuel Mixture Aim
Fuel Pressure Sensor
Fuel Inj Primary Duty Cycle
Engine Efficiency
Throttle Pedal
Engine Load
Ignition Timing
Fuel Timing Primary
Ignition Cyl 1 Knock Level
Ignition Cyl 2 Knock Level
Ignition Cyl 3 Knock Level
Ignition Cyl 4 Knock Level
Ignition Cyl 5 Knock Level
Ignition Cyl 6 Knock Level
Ignition Cyl 7 Knock Level
Ignition Cyl 8 Knock Level
Ignition Output Cut Count
Fuel Output Cut Count
Ignition Output Cut Average
Fuel Output Cut Average
Fuel Cyl1 Prim Pulse Width 1
Ignition Timing State
Ignition Cut State
Engine Oil Pressure
Boost Pressure
Boost Aim
Boost Actuator Duty Cycle
Gear Lever Force Sensor
Inlet Camshaft Aim
Inlet Camshaft Bank1 Position
Inlet Camshaft Bank2 Position
Inlet Cam Bank1 Duty Cycle
Inlet Cam Bank2 Duty Cycle
Exhaust Camshaft Aim
Exhaust Camshaft Bank1 Pos
Exhaust Camshaft Bank2 Pos
Exhaust Cam Bank1 Duty Cycle
Exhaust Cam Bank2 Duty Cycle
Wheel Speed FL

Wheel Speed FR
Wheel Speed RL
Wheel Speed RR
Coolant Temperature
Engine Oil Temperature
Fuel Temperature
Ambient Temperature
Airbox Temperature
Bat Volts ECU
Fuel Used M1
Exhaust Temperature
Engine Load Average
Engine Speed Limit
Ambient Pressure
Ignition Cyl 1 Trim Knock
Ignition Cyl 2 Trim Knock
Ignition Cyl 3 Trim Knock
Ignition Cyl 4 Trim Knock
Ignition Cyl 5 Trim Knock
Ignition Cyl 6 Trim Knock
Ignition Cyl 7 Trim Knock
Ignition Cyl 8 Trim Knock
Engine Run Time
ECU Uptime
Warning Source
Coolant Temperature Warning
Coolant Pressure Warning
Engine Speed Warning
Engine Oil Temp Warning
Engine Oil Pressure Warning
Crankcase Pressure Warning
Fuel Pressure Warning
Knock Warning
Engine State
Fuel Pump State
Anti Lag State
Launch State
Boost Aim State
Engine Overrun State
Fuel State
Fuel Purge State
Knock State
Throttle Aim State
Fuel Closed Loop State
Engine Speed Reference State
Gear
Engine Speed Limit State
Anti Lag Diagnostic
Launch Diagnostic
Boost Control Diagnostic
Fuel Cut State
Fuel Closed Loop Diagnostic
Engine OilPressure Low Switch
Pit Switch
Launch Switch
Traction Switch
Brake State
Anti Lag Switch
Engine Run Switch
Gear Neutral Switch
Boost Limit Disable Switch
Throttle Pedal Translation Sw
Race Time Reset Switch
Engine Run Hours Total
Fuel Closed Loop Ctrl B1 Trim

Fuel Closed Loop Ctrl B2 Trim
Transmission Temperature
Fuel Tank Level
M1 General 0x640 Version No
CAN Comms Diag 0x650
Driver Rotary Switch 1
Driver Rotary Switch 2
Driver Rotary Switch 3
Driver Rotary Switch 4
Driver Rotary Switch 5
Driver Rotary Switch 6
Driver Switch 1
Driver Switch 2
Driver Switch 3
Driver Switch 4
Driver Switch 5
Driver Switch 6
Driver Switch 7
Driver Switch 8
Exhaust Lambda
Exhaust Lambda Bank 1
Exhaust Lambda Bank 2
Exhaust Temp Bank 1
Exhaust Temp Bank 2
Fuel Inj Sec Contribution
Fuel Timing Secondary
Fuel Inj Secondary Duty Cycle
Fuel Pres Direct
Fuel Pres Direct Aim
Fuel Pres Direct Ctrl
Fuel Pres Direct Ctrl FF
Fuel Pres Direct Ctrl Prop
Fuel Pres Direct Ctrl Int
Fuel Pres Direct B2
Fuel Pres Direct B2 Aim
Fuel Pres Direct B2 Ctrl
Fuel Pres Direct B2 Ctrl FF
Fuel Pres Direct B2 Ctrl Prop
Fuel Pres Direct B2 Ctrl Int
Brake Pressure Front
Brake Pressure Rear
Coolant Pressure
Steering Pressure
Steering Angle
Inlet Mass Flow
Airbox Mass Flow
Fuel Flow
Fuel Inj Primary Press
Fuel Inj Secondary Press
Gear Input Shaft Speed
Gear Output Shaft Speed
Vehicle Accel Lateral
Vehicle Accel Long
Vehicle Accel Vert
Vehicle Yaw Rate
Ignition Cyl 9 Knock Level
Ignition Cyl 10 Knock Level
Ignition Cyl 11 Knock Level
Ignition Cyl 12 Knock Level
Vehicle Speed
Ignition Cyl 9 Trim Knock
Ignition Cyl 10 Trim Knock
Ignition Cyl 11 Trim Knock
Ignition Cyl 12 Trim Knock
M1 General 0x650 Version No

Lap Time
Running Lap Time
Lap Number
Lap Distance
Differential Temperature
Driver Rotary Switch 7
Driver Rotary Switch 8
Brake Temp FL
Brake Temp FR
Brake Temp RL
Brake Temp RR
Exhaust Pressure Bank 1
Exhaust Pressure Bank 2
Engine Crankcase Pressure
Alternator Current
Knock Threshold
Logging System 1 Used
Vehicle Speed Limit Pit Limit
Alt Fuel Mode
Fuel Comp Sensor Diag
Alt Fuel Timing Prim Blend
Alt Fuel Timing Sec Blend
Alt Fuel Ign Timing Blend
Alt Fuel Mix Aim Blend
Fuel Composition
Alt Fuel Ign Timing
Alt Fuel Timing Prim
Alt Fuel Timing Sec
Alt Fuel Mix Aim
Alt Fuel Pressure Sensor
Alt Fuel Temperature
Alt Fuel Cont Efficiency
Alt Fuel Pump State
Alt Fuel Press Warning
Alt Fuel Pump Active
CAN Comms Diag 0x6A0
Aux Output 1 Duty Cycle
Aux Output 2 Duty Cycle
Aux Output 3 Duty Cycle
Aux Output 4 Duty Cycle
Aux Output 5 Duty Cycle
M1 General 0x6A0 Version No
Turbo Bank 1 Speed
Turbo Bank 1 Temp Inlet
Turbo Bank 1 Temp Outlet
Turbo Bank 1 Pressure Inlet
Turbo Bank 2 Speed
Turbo Bank 2 Temp Inlet
Turbo Bank 2 Temp Outlet
5V Aux Supply
8V Aux Supply
Bat Volts Dash
Dash Temp
G Force Lat
G Force Long
G Force Vert
Reset Button
Next Button
Mode Button
Brightness Switch
Beacon
Ground Speed
Drive Speed
Odometer
Lap Gain/Loss Running

Lap Gain/Loss Final
Lap Time Predicted
Reference Lap Time
Reference Lap Time Reset
Gear Detect Value
Session Time
Session Reset
Min Corner Speed
Max Straight Speed
Display Mode Change
Display Next Line
Alarm Acknowledge
Log Time Remaining
Log Data Available
Log Unloading
Logging Running
Log Memory Busy
CPU Usage
Device Up Time
Warning Light
Up Shift Light 1
Up Shift Light 2
Up Shift Light 3

Channels By Function

Connections

Communications

RS232

2 RX GPS - Standard RMC GGA

Generates Channels	From
Comms RS232-2 Diag	Diagnostic

Received Channels

Generates Channels	From
GPS Time	Id[1] var: 1, mul: 1, div: 1, add: 0, mod: 0
GPS Latitude	Id[1] var: 3, mul: 1, div: 1, add: 0, mod: 0
GPS Longitude	Id[1] var: 5, mul: 1, div: 1, add: 0, mod: 0
GPS Speed	Id[1] var: 7, mul:1852, div:1000, add: 0 , mod: 0
GPS Heading	Id[1] var: 8, mul: 1, div: 1, add: 0, mod: 0
GPS Date	Id[1] var: 9, mul: 1, div: 1, add: 0, mod: 0
GPS Sats Used	Id[2] var: 7, mul: 1, div: 1, add: 0, mod: 0
GPS Altitude	Id[2] var: 9, mul: 1, div: 1, add: 0, mod: 0

CAN

Bus 2 (1) M1_General_0x640_Version 5

Generates Channels	From
CAN Comms Diag 0x640	Diagnostic

Received Channels

Generates Channels	From
Coolant Temperature	Id[10] off: 0, len: 1, mul: 10, div: 1, add:-400, mask:0x FF
Engine Oil Temperature	Id[10] off: 1, len: 1, mul: 10, div: 1, add:-400, mask:0x FF

```
Fuel Temperature                   Id[10] off:  2, len:  1, mul: 10, div:  1,
 add:-400, mask:0x  FF
Ambient Temperature                Id[10] off:  3, len:  1, mul: 10, div:  1,
 add:-400, mask:0x  FF
Airbox Temperature                 Id[10] off:  4, len:  1, mul: 10, div:  1,
 add:-400, mask:0x  FF
Bat Volts ECU                      Id[10] off:  5, len:  1, mul: 10, div:  1,
 add:  0, mask:0x  FF
Fuel Used M1                       Id[10] off:  6, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Exhaust Temperature                Id[11] off:  0, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Engine Load Average                Id[11] off:  2, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Engine Speed Limit                 Id[11] off:  4, len:  2, mul:  1, div:  6,
 add:  0, mask:0xFFFF
Ambient Pressure                   Id[11] off:  6, len:  2, mul: 10, div:  1,
 add:  0, mask:0xFFFF
Ignition Cyl 1 Trim Knock          Id[12] off:  0, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 2 Trim Knock          Id[12] off:  1, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 3 Trim Knock          Id[12] off:  2, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 4 Trim Knock          Id[12] off:  3, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 5 Trim Knock          Id[12] off:  4, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 6 Trim Knock          Id[12] off:  5, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 7 Trim Knock          Id[12] off:  6, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 8 Trim Knock          Id[12] off:  7, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Engine Run Time                    Id[13] off:  0, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
ECU Uptime                         Id[13] off:  2, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Warning Source                     Id[13] off:  4, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Fuel Pressure Warning              Id[13] off:  5, len:  1, mul:  1, div:  1,
 add:  0, mask:0x   1
Crankcase Pressure Warning         Id[13] off:  5, len:  1, mul:  1, div:  2,
 add:  0, mask:0x   2
Engine Oil Pressure Warning        Id[13] off:  5, len:  1, mul:  1, div:  8,
 add:  0, mask:0x   8
Engine Oil Temp Warning            Id[13] off:  5, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  10
Engine Speed Warning               Id[13] off:  5, len:  1, mul:  1, div: 32,
 add:  0, mask:0x  20
Coolant Pressure Warning           Id[13] off:  5, len:  1, mul:  1, div: 64,
 add:  0, mask:0x  40
Coolant Temperature Warning        Id[13] off:  5, len:  1, mul:  1, div:128,
 add:  0, mask:0x  80
Knock Warning                      Id[13] off:  6, len:  1, mul:  1, div:128,
 add:  0, mask:0x  80
Fuel Pump State                    Id[14] off:  0, len:  1, mul:  1, div:  1,
 add:  0, mask:0x   F
Engine State                       Id[14] off:  0, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  F0
Launch State                       Id[14] off:  1, len:  1, mul:  1, div:  1,
 add:  0, mask:0x   F
Anti Lag State                     Id[14] off:  1, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  F0
Boost Aim State                    Id[14] off:  2, len:  1, mul:  1, div: 16,
```

```
 add:  0, mask:0x  F0
Fuel State                         Id[14] off:  3, len:  1, mul:  1, div:  1,
 add:  0, mask:0x   F
Engine Overrun State               Id[14] off:  3, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  F0
Knock State                        Id[14] off:  4, len:  1, mul:  1, div:  1,
 add:  0, mask:0x   F
Fuel Purge State                   Id[14] off:  4, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  F0
Fuel Closed Loop State             Id[14] off:  5, len:  1, mul:  1, div:  1,
 add:  0, mask:0x   F
Throttle Aim State                 Id[14] off:  5, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  F0
Gear                               Id[14] off:  6, len:  1, mul:  1, div:  1,
 add:  0, mask:0x   F
Engine Speed Reference State       Id[14] off:  6, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  F0
Engine Speed Limit State           Id[14] off:  7, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Launch Diagnostic                  Id[15] off:  0, len:  1, mul:  1, div:  1,
 add:  0, mask:0x   F
Anti Lag Diagnostic                Id[15] off:  0, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  F0
Fuel Cut State                     Id[15] off:  1, len:  1, mul:  1, div:  1,
 add:  0, mask:0x   F
Boost Control Diagnostic           Id[15] off:  1, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  F0
Fuel Closed Loop Diagnostic        Id[15] off:  2, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  F0
Gear Neutral Switch                Id[15] off:  3, len:  1, mul:  1, div:  1,
 add:  0, mask:0x   1
Engine Run Switch                  Id[15] off:  3, len:  1, mul:  1, div:  2,
 add:  0, mask:0x   2
Anti Lag Switch                    Id[15] off:  3, len:  1, mul:  1, div:  4,
 add:  0, mask:0x   4
Brake State                        Id[15] off:  3, len:  1, mul:  1, div:  8,
 add:  0, mask:0x   8
Traction Switch                    Id[15] off:  3, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  10
Launch Switch                      Id[15] off:  3, len:  1, mul:  1, div: 32,
 add:  0, mask:0x  20
Pit Switch                         Id[15] off:  3, len:  1, mul:  1, div: 64,
 add:  0, mask:0x  40
Engine OilPressure Low Switch      Id[15] off:  3, len:  1, mul:  1, div:128,
 add:  0, mask:0x  80
Boost Limit Disable Switch         Id[15] off:  4, len:  1, mul:  1, div: 16,
 add:  0, mask:0x  10
Throttle Pedal Translation Sw      Id[15] off:  5, len:  1, mul:  1, div: 32,
 add:  0, mask:0x  20
Race Time Reset Switch             Id[15] off:  5, len:  1, mul:  1, div: 64,
 add:  0, mask:0x  40
Engine Run Hours Total             Id[16] off:  0, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Fuel Closed Loop Ctrl B1 Trim      Id[16] off:  2, len:  1, mul:  5, div:  1,
 add:-1000, mask:0x  FF
Fuel Closed Loop Ctrl B2 Trim      Id[16] off:  3, len:  1, mul:  5, div:  1,
 add:-1000, mask:0x  FF
Transmission Temperature           Id[16] off:  4, len:  1, mul: 10, div:  1,
 add:-400, mask:0x  FF
Fuel Tank Level                    Id[16] off:  5, len:  1, mul: 10, div:  1,
 add:  0, mask:0x  FF
M1 General 0x640 Version No        Id[16] off:  7, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Engine Speed                       Id[1] off:  0, len:  2, mul:  1, div:  6,
add:  0, mask:0xFFFF
```

```
Inlet Manifold Pressure            Id[1] off:  2, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Inlet Air Temperature              Id[1] off:  4, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Throttle Position                  Id[1] off:  6, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Fuel Volume                        Id[2] off:  0, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Fuel Mixture Aim                   Id[2] off:  2, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Fuel Pressure Sensor               Id[2] off:  4, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Fuel Inj Primary Duty Cycle        Id[2] off:  6, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Engine Efficiency                  Id[2] off:  7, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Throttle Pedal                     Id[3] off:  0, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Engine Load                        Id[3] off:  2, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Ignition Timing                    Id[3] off:  4, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Fuel Timing Primary                Id[3] off:  6, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Ignition Cyl 1 Knock Level         Id[4] off:  0, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Ignition Cyl 2 Knock Level         Id[4] off:  1, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Ignition Cyl 3 Knock Level         Id[4] off:  2, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Ignition Cyl 4 Knock Level         Id[4] off:  3, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Ignition Cyl 5 Knock Level         Id[4] off:  4, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Ignition Cyl 6 Knock Level         Id[4] off:  5, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Ignition Cyl 7 Knock Level         Id[4] off:  6, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Ignition Cyl 8 Knock Level         Id[4] off:  7, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Ignition Output Cut Count          Id[5] off:  0, len:  1, mul:  1, div:  1,
add:  0, mask:0x  FF
Fuel Output Cut Count              Id[5] off:  1, len:  1, mul:  1, div:  1,
add:  0, mask:0x  FF
Ignition Output Cut Average        Id[5] off:  2, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Fuel Output Cut Average            Id[5] off:  3, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Fuel Cyl1 Prim Pulse Width 1       Id[5] off:  4, len:  1, mul:100, div:  1,
add:  0, mask:0x  FF
Ignition Cut State                 Id[5] off:  5, len:  1, mul:  1, div:  1,
add:  0, mask:0x   F
Ignition Timing State              Id[5] off:  5, len:  1, mul:  1, div: 16,
add:  0, mask:0x  F0
Engine Oil Pressure                Id[5] off:  6, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Boost Pressure                     Id[6] off:  0, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Boost Aim                          Id[6] off:  2, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Boost Actuator Duty Cycle          Id[6] off:  6, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Gear Lever Force Sensor            Id[6] off:  7, len:  1, mul:5000, div: 98,
 add:  0, mask:0x  FF
Inlet Camshaft Aim                 Id[7] off:  0, len:  2, mul:  1, div:  1,
```

```
add:  0, mask:0xFFFF
Inlet Camshaft Bank1 Position      Id[7] off:  2, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Inlet Camshaft Bank2 Position      Id[7] off:  4, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Inlet Cam Bank1 Duty Cycle         Id[7] off:  6, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Inlet Cam Bank2 Duty Cycle         Id[7] off:  7, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Exhaust Camshaft Aim               Id[8] off:  0, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Exhaust Camshaft Bank1 Pos         Id[8] off:  2, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Exhaust Camshaft Bank2 Pos         Id[8] off:  4, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Exhaust Cam Bank1 Duty Cycle       Id[8] off:  6, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Exhaust Cam Bank2 Duty Cycle       Id[8] off:  7, len:  1, mul: 10, div:  1,
add:  0, mask:0x  FF
Wheel Speed FL                     Id[9] off:  0, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Wheel Speed FR                     Id[9] off:  2, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Wheel Speed RL                     Id[9] off:  4, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Wheel Speed RR                     Id[9] off:  6, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
```

Bus 2 (2) M1_General_0x650_Version 5

Generates Channels	From
CAN Comms Diag 0x650	Diagnostic

Received Channels

```
Generates Channels                 From
Ignition Cyl 9 Knock Level         Id[10] off:  0, len:  1, mul: 10, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 10 Knock Level        Id[10] off:  1, len:  1, mul: 10, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 11 Knock Level        Id[10] off:  2, len:  1, mul: 10, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 12 Knock Level        Id[10] off:  3, len:  1, mul: 10, div:  1,
 add:  0, mask:0x  FF
Vehicle Speed                      Id[10] off:  4, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Ignition Cyl 9 Trim Knock          Id[11] off:  0, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 10 Trim Knock         Id[11] off:  1, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 11 Trim Knock         Id[11] off:  2, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Ignition Cyl 12 Trim Knock         Id[11] off:  3, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
M1 General 0x650 Version No        Id[11] off:  4, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Lap Time                           Id[12] off:  0, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Running Lap Time                   Id[12] off:  2, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Lap Number                         Id[12] off:  4, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Lap Distance                       Id[12] off:  6, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Differential Temperature           Id[13] off:  0, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
```

```
Driver Rotary Switch 7            Id[13] off:  2, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Driver Rotary Switch 8            Id[13] off:  3, len:  1, mul:  1, div:  1,
 add:  0, mask:0x  FF
Brake Temp FL                     Id[14] off:  0, len:  2, mul:  1, div: 10,
 add:  0, mask:0xFFFF
Brake Temp FR                     Id[14] off:  2, len:  2, mul:  1, div: 10,
 add:  0, mask:0xFFFF
Brake Temp RL                     Id[14] off:  4, len:  2, mul:  1, div: 10,
 add:  0, mask:0xFFFF
Brake Temp RR                     Id[14] off:  6, len:  2, mul:  1, div: 10,
 add:  0, mask:0xFFFF
Exhaust Pressure Bank 1           Id[15] off:  0, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Exhaust Pressure Bank 2           Id[15] off:  2, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Engine Crankcase Pressure         Id[15] off:  4, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Alternator Current                Id[15] off:  6, len:  2, mul:  1, div: 10,
 add:  0, mask:0xFFFF
Knock Threshold                   Id[16] off:  0, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Logging System 1 Used             Id[16] off:  2, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Vehicle Speed Limit Pit Limit     Id[16] off:  4, len:  2, mul:  1, div:  1,
 add:  0, mask:0xFFFF
Driver Rotary Switch 1            Id[1] off:  0, len:  1, mul:  1, div:  1,
add:  0, mask:0x  FF
Driver Rotary Switch 2            Id[1] off:  1, len:  1, mul:  1, div:  1,
add:  0, mask:0x  FF
Driver Rotary Switch 3            Id[1] off:  2, len:  1, mul:  1, div:  1,
add:  0, mask:0x  FF
Driver Rotary Switch 4            Id[1] off:  3, len:  1, mul:  1, div:  1,
add:  0, mask:0x  FF
Driver Rotary Switch 5            Id[1] off:  4, len:  1, mul:  1, div:  1,
add:  0, mask:0x  FF
Driver Rotary Switch 6            Id[1] off:  5, len:  1, mul:  1, div:  1,
add:  0, mask:0x  FF
Driver Switch 8                   Id[1] off:  7, len:  1, mul:  1, div:  1,
add:  0, mask:0x   1
Driver Switch 7                   Id[1] off:  7, len:  1, mul:  1, div:  2,
add:  0, mask:0x   2
Driver Switch 6                   Id[1] off:  7, len:  1, mul:  1, div:  4,
add:  0, mask:0x   4
Driver Switch 5                   Id[1] off:  7, len:  1, mul:  1, div:  8,
add:  0, mask:0x   8
Driver Switch 4                   Id[1] off:  7, len:  1, mul:  1, div: 16,
add:  0, mask:0x  10
Driver Switch 3                   Id[1] off:  7, len:  1, mul:  1, div: 32,
add:  0, mask:0x  20
Driver Switch 2                   Id[1] off:  7, len:  1, mul:  1, div: 64,
add:  0, mask:0x  40
Driver Switch 1                   Id[1] off:  7, len:  1, mul:  1, div:128,
add:  0, mask:0x  80
Exhaust Lambda                    Id[2] off:  0, len:  1, mul:  1, div:  1,
add:  0, mask:0x  FF
Exhaust Lambda Bank 1             Id[2] off:  2, len:  1, mul:  1, div:  1,
add:  0, mask:0x  FF
Exhaust Lambda Bank 2             Id[2] off:  3, len:  1, mul:  1, div:  1,
add:  0, mask:0x  FF
Exhaust Temp Bank 1               Id[2] off:  4, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Exhaust Temp Bank 2               Id[2] off:  6, len:  2, mul:  1, div:  1,
add:  0, mask:0xFFFF
Fuel Inj Sec Contribution         Id[3] off:  0, len:  2, mul:  1, div:  1,
```

```
    add:  0, mask:0xFFFF
    Fuel Timing Secondary              Id[3] off:  2, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Fuel Inj Secondary Duty Cycle      Id[3] off:  4, len:  1, mul: 10, div:  1,
    add:  0, mask:0x  FF
    Fuel Pres Direct                   Id[4] off:  0, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Fuel Pres Direct Aim               Id[4] off:  2, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Fuel Pres Direct Ctrl              Id[4] off:  4, len:  1, mul:  5, div:  1,
    add:  0, mask:0x  FF
    Fuel Pres Direct Ctrl FF           Id[4] off:  5, len:  1, mul: 10, div:  1,
    add:  0, mask:0x  FF
    Fuel Pres Direct Ctrl Prop         Id[4] off:  6, len:  1, mul: 10, div:  1,
    add:  0, mask:0x  FF
    Fuel Pres Direct Ctrl Int          Id[4] off:  7, len:  1, mul: 10, div:  1,
    add:  0, mask:0x  FF
    Fuel Pres Direct B2                Id[5] off:  0, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Fuel Pres Direct B2 Aim            Id[5] off:  2, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Fuel Pres Direct B2 Ctrl           Id[5] off:  4, len:  1, mul:  5, div:  1,
    add:  0, mask:0x  FF
    Fuel Pres Direct B2 Ctrl FF        Id[5] off:  5, len:  1, mul: 10, div:  1,
    add:  0, mask:0x  FF
    Fuel Pres Direct B2 Ctrl Prop      Id[5] off:  6, len:  1, mul: 10, div:  1,
    add:  0, mask:0x  FF
    Fuel Pres Direct B2 Ctrl Int       Id[5] off:  7, len:  1, mul: 10, div:  1,
    add:  0, mask:0x  FF
    Brake Pressure Front               Id[6] off:  0, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Brake Pressure Rear                Id[6] off:  2, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Coolant Pressure                   Id[6] off:  4, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Steering Pressure                  Id[6] off:  6, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Steering Angle                     Id[7] off:  0, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Inlet Mass Flow                    Id[7] off:  2, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Airbox Mass Flow                   Id[7] off:  4, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Fuel Flow                          Id[7] off:  6, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Fuel Inj Primary Press             Id[8] off:  0, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Fuel Inj Secondary Press           Id[8] off:  2, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Gear Input Shaft Speed             Id[8] off:  4, len:  2, mul:  1, div:  6,
    add:  0, mask:0xFFFF
    Gear Output Shaft Speed            Id[8] off:  6, len:  2, mul:  1, div:  6,
    add:  0, mask:0xFFFF
    Vehicle Accel Lateral              Id[9] off:  0, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Vehicle Accel Long                 Id[9] off:  2, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Vehicle Accel Vert                 Id[9] off:  4, len:  2, mul:  1, div:  1,
    add:  0, mask:0xFFFF
    Vehicle Yaw Rate                   Id[9] off:  6, len:  2, mul: 50, div: 18,
    add:  0, mask:0xFFFF
```

Bus 2 (3) M1_General_0x670_Version 1

Received Channels

Generates Channels	From
Fuel Comp Sensor Diag	Id[1] off: 0, len: 1, mul: 1, div: 1, add: 0, mask:0x F
Alt Fuel Mode	Id[1] off: 0, len: 1, mul: 1, div: 16, add: 0, mask:0x F0
Alt Fuel Timing Prim Blend	Id[1] off: 1, len: 1, mul: 10, div: 1, add: 0, mask:0x FF
Alt Fuel Timing Sec Blend	Id[1] off: 2, len: 1, mul: 10, div: 1, add: 0, mask:0x FF
Alt Fuel Ign Timing Blend	Id[1] off: 3, len: 1, mul: 10, div: 1, add: 0, mask:0x FF
Alt Fuel Mix Aim Blend	Id[1] off: 4, len: 1, mul: 10, div: 1, add: 0, mask:0x FF
Fuel Composition	Id[1] off: 5, len: 1, mul: 10, div: 1, add: 0, mask:0x FF
Alt Fuel Ign Timing	Id[1] off: 6, len: 1, mul:-10, div: 2, add: 0, mask:0x FF
Alt Fuel Timing Prim	Id[2] off: 0, len: 2, mul: -1, div: 1, add: 0, mask:0xFFFF
Alt Fuel Timing Sec	Id[2] off: 2, len: 2, mul: -1, div: 1, add: 0, mask:0xFFFF
Alt Fuel Mix Aim	Id[2] off: 4, len: 2, mul: 1, div: 1, add: 0, mask:0xFFFF
Alt Fuel Pressure Sensor	Id[3] off: 0, len: 2, mul: 1, div: 1, add: 0, mask:0xFFFF
Alt Fuel Temperature	Id[3] off: 2, len: 1, mul: 10, div: 1, add:-400, mask:0x FF
Alt Fuel Cont Efficiency	Id[3] off: 3, len: 1, mul: 10, div: 1, add: 0, mask:0x FF
Alt Fuel Pump Active	Id[3] off: 4, len: 1, mul: 1, div: 1, add: 0, mask:0x 1
Alt Fuel Press Warning	Id[3] off: 4, len: 1, mul: 1, div: 2, add: 0, mask:0x 2
Alt Fuel Pump State	Id[3] off: 4, len: 1, mul: 1, div: 16, add: 0, mask:0x F0

Bus 2 (4) M1_General_0x6A0_Version 1

Generates Channels	From
CAN Comms Diag 0x6A0	Diagnostic

Received Channels

Generates Channels	From
Aux Output 1 Duty Cycle	Id[1] off: 0, len: 2, mul: 1, div: 1, add: 0, mask:0xFFFF
Aux Output 2 Duty Cycle	Id[1] off: 2, len: 2, mul: 1, div: 1, add: 0, mask:0xFFFF
Aux Output 3 Duty Cycle	Id[1] off: 4, len: 2, mul: 1, div: 1, add: 0, mask:0xFFFF
Aux Output 4 Duty Cycle	Id[1] off: 6, len: 2, mul: 1, div: 1, add: 0, mask:0xFFFF
Aux Output 5 Duty Cycle	Id[2] off: 0, len: 2, mul: 1, div: 1, add: 0, mask:0xFFFF
M1 General 0x6A0 Version No	Id[6] off: 0, len: 1, mul: 1, div: 1, add: 0, mask:0x FF
Turbo Bank 1 Speed	Id[7] off: 0, len: 2, mul: 10, div: 6, add: 0, mask:0xFFFF
Turbo Bank 1 Temp Inlet	Id[7] off: 2, len: 1, mul: 1, div: 1, add:-40, mask:0x FF
Turbo Bank 1 Temp Outlet	Id[7] off: 3, len: 1, mul: 1, div: 1, add:-40, mask:0x FF
Turbo Bank 1 Pressure Inlet	Id[7] off: 4, len: 2, mul: 1, div: 1, add: 0, mask:0xFFFF
Turbo Bank 2 Speed	Id[8] off: 0, len: 2, mul: 10, div: 6, add: 0, mask:0xFFFF

Turbo Bank 2 Temp Inlet Id[8] off: 2, len: 1, mul: 1, div: 1, add:-40, mask:0x FF
Turbo Bank 2 Temp Outlet Id[8] off: 3, len: 1, mul: 1, div: 1, add:-40, mask:0x FF

CoC125r

Co

Generates Channels	From
5V Aux Supply	Pin 5VSEN Pinout Internal
8V Aux Supply	Pin 8VSEN Pinout Internal
Reset Button	Pin DIG1 Pinout 14
Next Button	Pin DIG2 Pinout 15
Bat Volts Dash	Pin INT BAT Pinout Internal
G Force Lat	Pin INT LAT G Pinout Internal
G Force Long	Pin INT LONG G Pinout Internal
Dash Temp	Pin INT TEMP Pinout Internal
G Force Vert	Pin INT VERT G Pinout Internal
Mode Button	Pin SPD1 Pinout 21
Brightness Switch	Pin SPD3 Pinout 23

Calculations

Lap Time & Number

Generates Channels	From
Beacon	GPS beacon

Speed/Distance

Ground Speed

Uses Channels	For
GPS Speed	Input 1

Generates Channels	From
Ground Speed	Output

Drive Speed

Uses Channels	For
GPS Speed	Input 1

Generates Channels	From
Drive Speed	Output

Co

Uses Channels	For
Ground Speed	Ground speed

Generates Channels	From
Odometer	Odometer

Lap Gain/Loss

Uses Channels	For
Lap Distance	Lap distance
Running Lap Time	Running lap time
Reference Lap Time Reset	Running lap time reset

Generates Channels	From
Lap Time Predicted	Estimated lap time
Lap Gain/Loss Final	Final difference
Reference Lap Time	Reference lap time
Lap Gain/Loss Running	Running difference

Tables

3D

1. Gear Detect Value

Uses Channels	For
Drive Speed	X axis input
Engine Speed	Y axis input

Generates Channels	From
Gear Detect Value	Output

Timers

1. Session Time

Uses Channels	For
Session Time	Start condition 1 first input
Session Reset	Stop condition 1 first input

Generates Channels	From
Session Time	Count

Co

Uses Channels	For
Ground Speed	Input speed

Generates Channels	From
Max Straight Speed	Maximum straight speed
Min Corner Speed	Minimum corner speed

User Conditions

1. Display Mode Change

Uses Channels	For
Next Button	Condition 1 first input
Mode Button	Condition 2 first input

Generates Channels	From
Display Mode Change	Condition result

2. Display Next Line

Uses Channels	For
Next Button	Condition 1 first input
Next Button	Condition 2 first input
Display Mode Change	Condition 3 first input

Generates Channels	From
Display Next Line	Condition result

3. Reference Lap Time Reset

Uses Channels	For
Reset Button	Condition 1 first input

Generates Channels	From
Reference Lap Time Reset	Condition result

4. Session Reset

Uses Channels	For
Reset Button	Condition 1 first input

Generates Channels	From
Session Reset	Condition result

5. Alarm Acknowledge

Uses Channels	For
Reset Button	Condition 1 first input
Reset Button	Condition 2 first input
Session Reset	Condition 3 first input

Generates Channels	From
Alarm Acknowledge	Condition result

CoCo

Uses Channels	For
Engine Speed	Start condition 1 first input
Engine Speed	Stop condition 1 first input

Generates Channels	From
Log Memory Busy	Busy
CPU Usage	CPU usage
Log Data Available	Data available
Logging Running	Running
Log Time Remaining	Time remaining
Log Unloading	Unloading
Device Up Time	Uptime

Normal

Uses Channels	For
G Force Lat	item 1, 25 times/second
Running Lap Time	item 10, once/second
Lap Time Predicted	item 11, once/second
GPS Sats Used	item 12, 20 times/second
GPS Altitude	item 13, 20 times/second
GPS Latitude	item 14, 20 times/second
GPS Longitude	item 15, 20 times/second
GPS Heading	item 16, 20 times/second
GPS Time	item 17, 20 times/second
GPS Date	item 18, 20 times/second
GPS Speed	item 19, 20 times/second
G Force Long	item 2, 25 times/second
Reference Lap Time	item 20, once/second
Device Up Time	item 21, once/second
Odometer	item 22, once/second
Boost Pressure	item 23, 10 times/second
Comms RS232-2 Diag	item 24, 20 times/second
Airbox Temperature	item 25, 10 times/second
Bat Volts ECU	item 26, 20 times/second
Engine Oil Pressure	item 27, 10 times/second
Engine Oil Temperature	item 28, 10 times/second
Engine Speed	item 29, 10 times/second
G Force Vert	item 3, 25 times/second
Coolant Temperature	item 30, 10 times/second
Fuel Pressure Sensor	item 31, 10 times/second
Fuel Temperature	item 32, 10 times/second
Fuel Used M1	item 33, 10 times/second
Ignition Timing	item 34, 10 times/second
Inlet Manifold Pressure	item 35, 10 times/second
Throttle Position	item 36, 10 times/second
Gear	item 37, 10 times/second
Inlet Air Temperature	item 38, 10 times/second
Throttle Pedal	item 39, 10 times/second
Beacon	item 4, once/second
Gear Detect Value	item 40, 5 times/second
Dash Temp	item 41, once/second
Bat Volts Dash	item 42, 25 times/second
Fuel Inj Primary Duty Cycle	item 43, 10 times/second
Ground Speed	item 5, 20 times/second
Lap Distance	item 6, once/second
Lap Time	item 7, once/second
Lap Gain/Loss Running	item 8, once/second
Lap Number	item 9, once/second

CoCo

Uses Channels	For
Display Mode Change	mode
Display Next Line	next

RACE

Uses Channels	For
Lap Gain/Loss Running	Bar 1
Bat Volts Dash	Bar 2
Running Lap Time	Bottom line 1 value 1
Lap Gain/Loss Running	Bottom line 1 value 2
Lap Time	Bottom line 1 value 3
Min Corner Speed	Bottom line 2 value 1
Lap Gain/Loss Running	Bottom line 2 value 2
Max Straight Speed	Bottom line 2 value 3
Inlet Manifold Pressure	Bottom line 3 value 1
Engine Oil Temperature	Bottom line 3 value 2
Airbox Temperature	Bottom line 3 value 3
Gear Detect Value	Bottom line 4 value 2
Reference Lap Time	Bottom override line 1 value 1
Lap Gain/Loss Final	Bottom override line 1 value 2
Lap Time	Bottom override line 1 value 3
Engine Speed	Gauge input
Gear	Gear
Coolant Temperature	Number 1 numeric Default
Engine Oil Pressure	Number 2 numeric Default
Ground Speed	Number 3 numeric Default
Session Time	Number 4 numeric Default
Lap Number	Number 5 numeric Default
Bat Volts Dash	Number 6 numeric Default

Co

Uses Channels	For
Lap Gain/Loss Running	Bar 1
Bat Volts Dash	Bar 2
Running Lap Time	Bottom line 1 value 1
Lap Gain/Loss Running	Bottom line 1 value 2
Lap Time	Bottom line 1 value 3
Min Corner Speed	Bottom line 2 value 1
Lap Gain/Loss Running	Bottom line 2 value 2
Max Straight Speed	Bottom line 2 value 3
Inlet Manifold Pressure	Bottom line 3 value 1
Engine Oil Temperature	Bottom line 3 value 2
Airbox Temperature	Bottom line 3 value 3
Gear Detect Value	Bottom line 4 value 2
Reference Lap Time	Bottom override line 1 value 1
Lap Gain/Loss Final	Bottom override line 1 value 2
Lap Time	Bottom override line 1 value 3
Engine Speed	Gauge input
Gear	Gear
Coolant Temperature	Number 1 numeric Default
Engine Oil Pressure	Number 2 numeric Default
Ground Speed	Number 3 numeric Default
Session Time	Number 4 numeric Default
Lap Number	Number 5 numeric Default
Bat Volts Dash	Number 6 numeric Default

WARMUP

Uses Channels	For
Coolant Temperature	Bar 1
Bat Volts Dash	Bar 2
Coolant Temperature	Bottom line 1 value 1
Engine Speed	Bottom line 1 value 2
Bat Volts Dash	Bottom line 1 value 3
Throttle Position	Bottom line 2 value 1
Engine Oil Pressure	Bottom line 2 value 2

Ignition Timing	Bottom line 2 value 3
Inlet Manifold Pressure	Bottom line 3 value 1
Engine Oil Temperature	Bottom line 3 value 2
Airbox Temperature	Bottom line 3 value 3
GPS Sats Used	Bottom line 4 value 1
GPS Time	Bottom line 4 value 3
G Force Lat	Bottom line 5 value 1
G Force Long	Bottom line 5 value 2
G Force Vert	Bottom line 5 value 3
Dash Temp	Bottom line 6 value 1
Reference Lap Time	Bottom line 6 value 3
Engine Speed	Gauge input
Gear	Gear

Co

Uses Channels	For
Brightness Switch	brightness input

Alarms

Uses Channels	For
Alarm Acknowledge	Acknowledge button

Generates Channels	From
Warning Light	Warning

1. Ref Lap Reset

Uses Channels	For
Reference Lap Time Reset	Condition 1 first input

2. Session Reset

Uses Channels	For
Session Reset	Condition 1 first input

3. OVER RPM

Uses Channels	For
Engine Speed	Condition 1 first input

4. ENGINE HOT

Uses Channels	For
Coolant Temperature	Condition 1 first input
Coolant Temperature	Message value

5. BATTERY LOW

Uses Channels	For
Bat Volts Dash	Condition 1 first input
Engine Speed	Condition 2 first input
Bat Volts Dash	Message value

Shift Lights

Uses Channels	For
Engine Speed	Input RPM

Up

Generates Channels	From
Up Shift Light 1	Upshift light 1
Up Shift Light 2	Upshift light 2
Up Shift Light 3	Upshift light 3

Shift Light Modules

Shift Light Module 1

Uses Channels	For
Brightness Switch	Brightness

Co Uses Channels	For
Warning Light	Input

Co Uses Channels	For
Up Shift Light 3	Input

Co Uses Channels	For
Up Shift Light 2	Input

Co Uses Channels	For
Up Shift Light 1	Input

Incomplete Channels

*** None ***

Unused Channels

CAN Comms Diag 0x640
Fuel Volume
Fuel Mixture Aim
Engine Efficiency
Engine Load
Fuel Timing Primary
Ignition Cyl 1 Knock Level
Ignition Cyl 2 Knock Level
Ignition Cyl 3 Knock Level
Ignition Cyl 4 Knock Level
Ignition Cyl 5 Knock Level
Ignition Cyl 6 Knock Level
Ignition Cyl 7 Knock Level
Ignition Cyl 8 Knock Level
Ignition Output Cut Count
Fuel Output Cut Count
Ignition Output Cut Average
Fuel Output Cut Average
Fuel Cyl1 Prim Pulse Width 1
Ignition Timing State
Ignition Cut State
Boost Aim
Boost Actuator Duty Cycle
Gear Lever Force Sensor
Inlet Camshaft Aim
Inlet Camshaft Bank1 Position
Inlet Camshaft Bank2 Position
Inlet Cam Bank1 Duty Cycle
Inlet Cam Bank2 Duty Cycle
Exhaust Camshaft Aim
Exhaust Camshaft Bank1 Pos
Exhaust Camshaft Bank2 Pos
Exhaust Cam Bank1 Duty Cycle
Exhaust Cam Bank2 Duty Cycle
Wheel Speed FL
Wheel Speed FR
Wheel Speed RL
Wheel Speed RR
Ambient Temperature
Exhaust Temperature
Engine Load Average
Engine Speed Limit
Ambient Pressure
Ignition Cyl 1 Trim Knock
Ignition Cyl 2 Trim Knock
Ignition Cyl 3 Trim Knock

Ignition Cyl 4 Trim Knock
Ignition Cyl 5 Trim Knock
Ignition Cyl 6 Trim Knock
Ignition Cyl 7 Trim Knock
Ignition Cyl 8 Trim Knock
Engine Run Time
ECU Uptime
Warning Source
Coolant Temperature Warning
Coolant Pressure Warning
Engine Speed Warning
Engine Oil Temp Warning
Engine Oil Pressure Warning
Crankcase Pressure Warning
Fuel Pressure Warning
Knock Warning
Engine State
Fuel Pump State
Anti Lag State
Launch State
Boost Aim State
Engine Overrun State
Fuel State
Fuel Purge State
Knock State
Throttle Aim State
Fuel Closed Loop State
Engine Speed Reference State
Engine Speed Limit State
Anti Lag Diagnostic
Launch Diagnostic
Boost Control Diagnostic
Fuel Cut State
Fuel Closed Loop Diagnostic
Engine OilPressure Low Switch
Pit Switch
Launch Switch
Traction Switch
Brake State
Anti Lag Switch
Engine Run Switch
Gear Neutral Switch
Boost Limit Disable Switch
Throttle Pedal Translation Sw
Race Time Reset Switch
Engine Run Hours Total
Fuel Closed Loop Ctrl B1 Trim
Fuel Closed Loop Ctrl B2 Trim
Transmission Temperature
Fuel Tank Level
M1 General 0x640 Version No
CAN Comms Diag 0x650
Driver Rotary Switch 1
Driver Rotary Switch 2
Driver Rotary Switch 3
Driver Rotary Switch 4
Driver Rotary Switch 5
Driver Rotary Switch 6
Driver Switch 1
Driver Switch 2
Driver Switch 3
Driver Switch 4
Driver Switch 5
Driver Switch 6
Driver Switch 7

Driver Switch 8
Exhaust Lambda
Exhaust Lambda Bank 1
Exhaust Lambda Bank 2
Exhaust Temp Bank 1
Exhaust Temp Bank 2
Fuel Inj Sec Contribution
Fuel Timing Secondary
Fuel Inj Secondary Duty Cycle
Fuel Pres Direct
Fuel Pres Direct Aim
Fuel Pres Direct Ctrl
Fuel Pres Direct Ctrl FF
Fuel Pres Direct Ctrl Prop
Fuel Pres Direct Ctrl Int
Fuel Pres Direct B2
Fuel Pres Direct B2 Aim
Fuel Pres Direct B2 Ctrl
Fuel Pres Direct B2 Ctrl FF
Fuel Pres Direct B2 Ctrl Prop
Fuel Pres Direct B2 Ctrl Int
Brake Pressure Front
Brake Pressure Rear
Coolant Pressure
Steering Pressure
Steering Angle
Inlet Mass Flow
Airbox Mass Flow
Fuel Flow
Fuel Inj Primary Press
Fuel Inj Secondary Press
Gear Input Shaft Speed
Gear Output Shaft Speed
Vehicle Accel Lateral
Vehicle Accel Long
Vehicle Accel Vert
Vehicle Yaw Rate
Ignition Cyl 9 Knock Level
Ignition Cyl 10 Knock Level
Ignition Cyl 11 Knock Level
Ignition Cyl 12 Knock Level
Vehicle Speed
Ignition Cyl 9 Trim Knock
Ignition Cyl 10 Trim Knock
Ignition Cyl 11 Trim Knock
Ignition Cyl 12 Trim Knock
M1 General 0x650 Version No
Differential Temperature
Driver Rotary Switch 7
Driver Rotary Switch 8
Brake Temp FL
Brake Temp FR
Brake Temp RL
Brake Temp RR
Exhaust Pressure Bank 1
Exhaust Pressure Bank 2
Engine Crankcase Pressure
Alternator Current
Knock Threshold
Logging System 1 Used
Vehicle Speed Limit Pit Limit
Alt Fuel Mode
Fuel Comp Sensor Diag
Alt Fuel Timing Prim Blend
Alt Fuel Timing Sec Blend

Alt Fuel Ign Timing Blend
Alt Fuel Mix Aim Blend
Fuel Composition
Alt Fuel Ign Timing
Alt Fuel Timing Prim
Alt Fuel Timing Sec
Alt Fuel Mix Aim
Alt Fuel Pressure Sensor
Alt Fuel Temperature
Alt Fuel Cont Efficiency
Alt Fuel Pump State
Alt Fuel Press Warning
Alt Fuel Pump Active
CAN Comms Diag 0x6A0
Aux Output 1 Duty Cycle
Aux Output 2 Duty Cycle
Aux Output 3 Duty Cycle
Aux Output 4 Duty Cycle
Aux Output 5 Duty Cycle
M1 General 0x6A0 Version No
Turbo Bank 1 Speed
Turbo Bank 1 Temp Inlet
Turbo Bank 1 Temp Outlet
Turbo Bank 1 Pressure Inlet
Turbo Bank 2 Speed
Turbo Bank 2 Temp Inlet
Turbo Bank 2 Temp Outlet
5V Aux Supply
8V Aux Supply
Log Time Remaining
Log Data Available
Log Unloading
Logging Running
Log Memory Busy
CPU Usage