Report Topic Outline

Compliant Mechanisms, Load Cells, and 3D Printing - Oh My!

J. Lefebvre jayden.lefebvre@mail.utoronto.ca UTorID: lefebv69

Engineering Science Faculty of Applied Science and Engineering University of Toronto Sunday March 14th, 2021

1 Polymer for Compliant Mechanism Hinges

1.1 Introduction

Compliant mechanisms are a category of simple mechanical devices used to transform force and motion via **elastic deformation and deflection** (thus, "complying" to the stimuli imparted onto it). They have become increasingly popular as an alternative to more traditional rigid and jointed systems for a variety of reasons, dependent on the use case [1]. Their potential use cases are immensely broad, ranging from sensitive surgical instrumentation (that must respond and react to subtle muscle movements and deflect so as to not cause tissue damage) to emergency safety mechanisms designed to prevent the accidental firing of nuclear weapons[2]. Although typically made from **plastics** and other polymers, they may also be made from ductile metals (or even paper in the case of "action origami", which I think is pretty cool)[2]. For the purposes of this report, only plastics will be considered.

FIGURE: Examples of compliant mechanism use cases

1.2 Hinge Fatigue via Repetitive Stress

Just as any typical hardware mechanism must be designed to withstand many, *many* uses (often on the order of hundreds of thousands, or more), compliant mechanisms aiming to solve similar problems must be designed to "comply" just as many times. However, where traditional hardware mechanisms experience very gradual (often unnoticeable) surface wear as a result of *sliding friction*, compliant mechanisms experience permanent deformation over time as a result of **repeated** *elastic* stress (further explained below). This difference is best exemplified in "hinge" components (those transferring work rotationally). Where traditional hardware mechanisms have joints (pins fastening two or more bodies about which they rotate), compliant mechanisms **bend** at specific locations with thinner cross-sectional area (relative to the bending moment)[1].

FIGURE: Example of a compliant "hinge"

1.3 Fatigue: Origins, Propagation, and Parameters

Invisible to the naked eye, under repetitive elastic deformation, "faults are introduced at the molecular level ... After many deformations, cracks will begin to appear, followed soon after by a fracture, with no apparent plastic deformation in between"[3]. The fatigue process begins with dislocation movements, which eventually form **persistent slip bands** (PSBs) that ultimately become the origin of larger-order failure.

FIGURE: Plastic fatigue at the microstructure

Fatigue life (number of cycles before fatigue) is influenced by a variety of factors, including environment (temperature, humidity, etc.), surface finish, metallurgical microstructure, presence of oxidizing or inert chemicals, residual stresses, and (most importantly) the magnitude of the repetitively applied stress (proximity to the plastic region). Unfortunately, the fatigue process is also (to a degree) random, often displaying considerable scatter even in seemingly identical samples in well controlled environments[3].

1.4 Conclusion

In order for critical compliant mechanisms to be reliable over long lifetimes, they must be made of materials resilient to high-cycle fatigue. Polymers intended for these applications must be resistent to dislocation movements while maintaining suitable flexibility AND stiffness for the design application (with a specific focus on "hinges").

2 Metal Alloy for Low-Load, Long-Term Load Cells

2.1 Introduction

Load cells are sensors that change in resistance directly proportionate to the applied load. Used primarily in scales (and other digital weighing devices), they are often made of metals, due to their high strength (thus, ability to weigh large loads)[4]. These load cells perform extremely well under short-term loading, in which an object is loaded on the cell and the reading is allowed to "creep" towards the final value as they metal deforms elastically and changes in internal resistance 1 However, in very specific and/or novel applications (such as one that I am currently personally working on, a scale system for hydroponically-grown crops that suspends and weighs the plant continuously as it grows from seed to harvest²), load cells may be required to perform in low-stress, long-term loading while maintaining high precision.

FIGURE: Example of a load cell and usage

2.2 Creep (the Material Deformation, not the Radiohead Song)

Creep is defined as "the tendency of a solid material to move slowly or deform permanently under the influence of persistent mechanical stresses"[5]. It operates on the principle of Hooke's law (similarly to elastic strain) where the final deflection is proportionate to the applied stress. It is time-dependent, and is best understood through a graph of creep strain vs. time:

FIGURE: Classical creep strain vs. time

Creep strain over time is divided into three phases[6]:

- 1. Primary Creep: starts at a rapid rate and slows with time as the material strengthens with temporary dislocation;
- 2. Secondary Creep: has a relatively uniform rate proportionate to stress;
- 3. Tertiary Creep: accelerating creep rate and terminates when the material ultimately ruptures.

Creep deformation in metals occurs via a variety of mechanisms[6]:

• Bulk Diffusion (Nabarro-Herring creep): Creep rate decreases as grain size increases

¹The exact mechanism by which this resistance changes is beyond the scope of this report; it is assumed that it is directly proportionate to the deflection of the load cell.

²https://github.com/UTAgritech/PeaPod

- Grain Boundary Diffusion (Coble creep): Stronger grain size dependence than Nabarro Herring
- Dislocation creep: Controlled by movement of dislocations, strong dependence on applied stress.

2.3 Conclusion

In order for load cells to be developed for novel applications where they are loaded with low-load over long-term, it is paramount that secondary and tertiary creep be minimized, as the existence of these phenomena will lead to increasing deflections (and thus innacurate readings) over long periods of time under even the slightest loads. Since stresses are low, however, the metal alloy *can be brittle* (very stiff but weak), depending on the specific tolerances of the intended application.

3 PETG Polymer Treatment for 3D Printing

3.1 Introduction

Polyethylene tetrapthalate's glycol-modified variant (PETG) is a strong, flexible plastic used in fused deposition modelling (FDM) 3D printing (the most common form). Though less popular than polylactic acid (PLA) or acrylonitrile butadiene styrene (ABS), it boasts the following properties[7]:

- · High strength and durability
- Moderate flexibility
- Easy to use
- Minimal/No shrinkage or warping post-print
- Water insoluble

These properties make it a star candidate for structural prints during periods of rapid prototyping, as is most often the case with engineering. However, there are certain drawbacks, most notably the phenomenon known as "stringing". Due to the higher melting temperature (~235°C) and chemical composition, excess material is deposited unintentionally when the nozzle is lifted from the print, resulting in annoying strings that can be difficult to remove and can even result in a failed print, potentially losing hours of valuable prototyping time.

3.2 Conclusion

In order to improve the efficiency of 3D printing-based prototyping using PETG, a polymer treatment should be developed that prevents potentially disastrous "stringing"[8] while not sacrificing any of its existing beneficical qualities.

4 References

- 1. https://www.compliantmechanisms.byu.edu/about-compliant-mechanisms
- 2. https://www.jstor.org/stable/43957291
- 3. https://en.wikipedia.org/wiki/Fatigue_(material)
- 4. https://www.arlynscales.com/industrial-scales/what-is-load-cell-creep/
- 5. https://en.wikipedia.org/wiki/Creep_(deformation)
- $6. \ https://web.iit.edu/sites/web/files/departments/academic-affairs/academic-resource-center/pdfs/MaterialsCollege (and the context of th$
- 8. https://all3dp.com/2/petg-stringing-3-easy-ways-to-prevent-it/