AIRBUS A330

MSFS · AIRBUS A330 (INIBUILDS) — NORMAL CHECKLIST · GROUND

SINGLE PILOT · COLD AND DARK → BEFORE TAKE-OFF · PAGE 1/2

A333 by Maverick1994

PRELIM PREP 1 2 › PRELIM PERF › COCKPIT PREP › FMGS PREP › FCU · AT NO AT › BEFORE START › ENG START › AFTER START › TAXI › BEFORE T/O

AT autothrust on · NO AT without autothrust · A GPU only · OPTION pick one

PRELIMINARY COCKPIT PREP

- ENG MASTERS 1 & 2 ..... OFF
- ENG START SELECTOR ..... NORM
- WX RADAR · PWS ..... OFF
- GAIN · MODE ..... AS REQD
- LANDING GEAR LEVER ..... DOWN
- WIPERS ..... BOTH OFF
- BAT 1 · 2 · APU ..... CHECK VOLTAGE
- A EXT PWR A & B ..... ON & AUTO
- APU FIRE · AGENT LT ..... CHECK · OFF
- APU FIRE TEST ..... PRESS & HOLD

AIR & POWER · CHOOSE ONE

OPTION 1 · APU NOW

- APU MASTER SW ..... ON
- APU START ..... PRESS · MONITOR
- EXT PWR A & B ..... AS REQD
- APU BLEED ..... ON

OPTION 2 · GPU, APU LATER

- GPU (EFB) ..... KEEP CONNECTED

PRELIMINARY COCKPIT PREP (CONT.)

- AIR COND · WHITE LIGHTS ..... OFF
- X-BLEED ..... AUTO
- CKPT · CABIN TEMP ..... AS REQD
- CARGO AIR COND ..... AS REQD
- COCKPIT LIGHTS ..... AS REQD
- EFB ..... ON

FMGS PRE-INIT · PRELIM PERF

- ENG · ACFT TYPE · DATABASE ..... CHECK
- FLIGHT NUMBER ..... INSERT
- FROM/TO ..... INSERT / SIMBRIEF
- AIRFIELD DATA ..... OBTAIN
- WEIGHT & BALANCE ..... INSERT
- PRELIM T/O PERF ..... COMPUTE ON EFB

ECAM · BRAKES · EXTERIOR

- DOOR · HYD · ENG SD PAGES ..... CHECK
- FLAPS · SPEED BRAKE ..... CHECK
- ACCU · PARK BRK · BRK PRESS ..... CHECK
- ALTN BRAKING · CHOCKS ..... CHECK
- PARK BRK OFF · PEDALS ..... PRESS · CHECK
- PEDALS RELEASE · PARK BRK ..... ON
- EMERGENCY EQUIPMENT ..... CHECK
- GEAR PINS & COVERS ..... CHECK

COCKPIT PREPARATION

- ALL WHITE LIGHTS ..... OFF
- RCDR GND CTL ..... ON
- EVAC CPT / PURS-CPT ..... AS REQD
- ADIRS · ALL IR MODE ..... NAV
- FUEL PUMPS ..... ON
- STROBE · BEACON ..... AUTO · OFF
- WING · RWY T/O · LAND · NOSE ..... OFF
- NAV & LOGO 1
- SEAT BELTS · NO SMOKING ..... ON · AUTO
- EMER EXIT LT ..... ARM
- PROBE/WINDOW HEAT ..... AUTO
- LDG ELEV ..... AUTO
- MAN VALVE SET ..... BOTH
- PACK FLOW ..... AS REQD
- ELEC SD · BAT 1 · 2 · APU ..... OFF THEN ON
- ELEC DC SD PAGE ..... CHECK
- TRIM TANK MODE · FEED ..... AUTO
- ENG 1 & 2 FIRE · AGENT LTS ..... CHECK · OFF
- ENG FIRE TEST ..... PRESS & HOLD
- MAINT · VENT PANELS ..... CHECK
- COM 3 ..... RECEPT
- ISIS ..... BRIGHTNESS · CHECK
- NORTH REF ..... OFF
- DMC · ECAM ND SELECTORS ..... AUTO · NORM
- CLOCK ..... SET
- GEAR GRAVITY EXTN ..... OFF

COCKPIT PREPARATION (CONT.)

- A/SKID & N/W STRG ..... ON
- RMP CPT & FO ..... ON · COMM TUNE
- GREEN NAV · SEL LTS ..... OFF
- ACP INT · VHF KNOBS ..... CHECK
- ACCU · PARK BRK · BRK PRESS ..... CHECK · ON
- COCKPIT DOOR ..... CHECK
- SWITCHING PANEL ..... NORM
- THRUST LEVERS · REVERSERS ..... IDLE · STOWED
- ENG MASTERS · ENG START ..... OFF · NORM
- ATC · ALT RPTG · XPDR ..... STBY · ON · SYS 1
- NAV CHARTS ..... PREPARE

FMGS PREPARATION

- INIT · FROM/TO · ALTN ..... CHECK / REQUEST
- FLT NBR · CI · CRZ FL ..... ENTER
- CRZ FL TEMP ..... CHECK
- DEPARTURE · ROUTE · ARRIVAL ..... SELECT · INSERT
- WINDS · SEC F-PLN ..... AS REQD
- RADIO NAV ..... CHECK / SET
- WEIGHT / PERF ..... CALCULATE ON EFB
- INIT B · ZFW/ZFWCG · BLOCK ..... INSERT
- PERF T.O · V1 · VR · V2 ..... INSERT
- FLEX TEMP · FLAPS/THS ..... INSERT
- THR RED/ACC · EO ACC ALT ..... CHECK / SET
- NEXT PHASE · PRESET SPEEDS ..... AS REQD

FCU · INSTRUMENTS

- LOUDSPEAKER ..... SET
- BARO ..... SET ALL
- FD 1 / 2 ..... ON
- LS · ND MODE/RANGE · ADF/VOR ..... AS REQD
- SPD/MACH WINDOW ..... CHECK
- HDG-VS / TRK-FPA ..... CHECK
- ALT WINDOW ..... SET
- AT A/THR ..... ARMS AT FLX/TOGA
- NO AT A/THR ..... MANUAL THRUST
- REGUL LO PR ..... NOT DISPLAYED

FCU · INSTRUMENTS (CONT.)

- DOOR/OXY SD PAGE ..... CHECK
- PFD · ND ..... CHECK
- PRESS SD · STS · INOP SYS ..... CHECK
- IRS ALIGN ..... CHECK
- TAKEOFF BRIEFING ..... PERFORM

BEFORE PUSHBACK OR START

- FINAL LOADSHEET · ZFW/ZFWCG ..... CHECK / REVISE
- LOADSHEET CG · ECAM CG · FOB ..... CHECK
- FINAL T/O PERF ..... RECOMPUTE
- FMS T/O DATA ..... REVISE
- MCDU CPT · FO ..... PERF TO · F-PLN
- EXT PWR ..... DISCONNECT
- ACARS INIT ..... COMPLETED
- GEAR PINS & COVERS · SIGNS ..... REMOVED · ON/AUTO
- ADIRS · FUEL QTY ..... NAV · CHECK
- T/O DATA · BARO REF ..... SET
- PUSHBACK / START CLEARANCE ..... OBTAIN
- WINDOWS · DOORS · FLT DECK DOOR ..... CLOSED
- SLIDES ..... ARMED
- BEACON ..... ON
- THRUST LEVERS ..... IDLE
- ACCU PRESS · PARK BRK ..... CHECK · ON
- NW STRG DISC MEMO ..... DISPLAYED
- TRANSPONDER ..... AS REQD

ENGINE START

- ENG START SELECTOR ..... IGN START
- ENG 1 MASTER ..... ON
- ENG 1 IDLE PARAMETERS ..... CHECK
- ENG 2 MASTER ..... ON
- ENG 2 IDLE PARAMETERS ..... CHECK

AFTER START

- ENG START SELECTOR ..... NORM
- APU BLEED ..... OFF
- ENG · WING ANTI-ICE ..... AS REQD
- APU MASTER SW ..... OFF

AFTER START (CONT.)

- NWS TOWING FAULT LT ..... OFF
- GROUND SPOILERS ..... ARM
- RUDDER TRIM RESET ..... PRESS · ZERO
- FLAPS ..... SET · CHECK
- PITCH TRIM ..... CHECK / SET
- ECAM STS ..... REVIEW
- NW STRG DISC MEMO ..... CHECK
- GROUND EQUIPMENT ..... CLEAR

TAXI-OUT

- TAXI CLEARANCE ..... OBTAIN
- NOSE · RWY TURN OFF ..... TAXI · AS REQD
- PARK BRK ..... OFF
- BRAKES ..... CHECK · PRESS ZERO
- FLIGHT CONTROLS ..... CHECK
- ATC CLEARANCE ..... CONFIRM
- F-PLN SID · INIT CLB SPEED ..... REVISE / CHECK
- FCU ALT · HDG ..... SET · AS REQD
- BOTH FD · PFD/ND ..... ON · CHECK
- T/O BRIEFING ..... CONFIRM
- RADAR · PWS ..... ON · AUTO
- XPDR CODE/MODE ..... SET
- TERR ON ND ..... AS REQD
- AUTO BRAKE ..... MAX
- T.O CONFIG ..... TEST
- T.O MEMO ..... NO BLUE
- CABIN REPORT ..... RECEIVED

BEFORE TAKE-OFF CHECKLIST

- F/CTL · INSTRUMENTS ..... CHECKED
- BRIEFING · FLAPS ..... CONFIRMED
- V1 · VR · V2 / FLEX ..... ANNOUNCE
- SPLRS · AUTO BRK ..... ARMED · MAX
- T.O CONFIG ..... NORM

Source: Airbus A330 MSFS Manual v1.0.1 (iniBuilds) · simplified procedures pp. 114–144 · AT/NO AT lines adapted from the A/THR description · Unofficial · not affiliated with iniBuilds · For simulation use only

LINE-UP › TAKE-OFF AT NO AT › AFTER T/O › CLIMB › CRUISE › DESCENT PREP › DESCENT › APPROACH › APPR TYPE 1 2 3 › LANDING › GO-AROUND › AFTER LDG › PARKING › SECURING

AT autothrust on · NO AT without autothrust · A GPU only · OPTION pick one

RUNWAY LINE-UP

BRAKE TEMP · FANS	CHECK
LINE-UP CLEARANCE	OBTAIN
STROBE · TCAS	ON · TA/RA
APPROACH PATH	CLEAR
CABIN CREW	ADVISE
SLIDING TABLES	STOW
T/O RUNWAY	CONFIRM
PACKS 1 & 2	AS REQD

TAKE-OFF

NOSE · RWY TURN OFF · LAND	T.O · ON · ON
SIDESTICK	½ FWD (FULL >20 KT XW)
BRAKES	RELEASE
THRUST LEVERS	FLX OR TOGA
AT FMA · A/THR	ARMED / ACTIVE
NO AT A/THR	DISCONNECT · MANUAL
CHRONO · T/O EPR/N1	START · CHECK
100 KT	STICK NEUTRAL
VR	ROTATE
POSITIVE CLIMB	GEAR UP
AUTOPILOT	AS REQD
THR RED · THRUST LEVERS	CL
PACKS	ON (IF OFF)
F SPEED · S SPEED	FLAPS 1 · FLAPS 0
GROUND SPOILERS	DISARM
NOSE · RWY TURN OFF	OFF

AFTER TAKE-OFF · CLIMB

APU BLEED · APU MASTER	OFF
TCAS	TA/RA
ENG · WING ANTI-ICE	AS REQD
GEAR · FLAPS · PACKS	UP · RET · ON
MCDU PF · PM	PERF CLB · F-PLN
BARO	STD
AT FMA · THR CLB	CHECK
NO AT THRUST	HOLD CLIMB SPEED
FL100 · LAND LTS	OFF
SEAT BELTS · EFIS	AS REQD

AFTER TAKE-OFF · CLIMB (CONT.)

ECAM MEMO · NAVAIDS	REVIEW · CLEAR
OPT/MAX ALT	CHECK

CRUISE

ECAM MEMO	REVIEW
SD PAGES (ENG…FUEL)	REVIEW
FLIGHT PROGRESS	CHECK
STEP FL	AS REQD
NAV ACCURACY · RADAR TILT	MONITOR · ADJUST
AT FMA · MACH	CHECK
NO AT THRUST	SET FOR MACH

DESCENT PREPARATION

WX · LANDING INFO · CHARTS	OBTAIN
APPR · STAR · TRANS · VIA	ENTER
F-PLN · DES WIND	CHECK
PERF CRZ · DES	CHECK
PERF APPR · QNH · TEMP · WIND	ENTER
MINIMUM · LDG CONF	INSERT · AS REQD
PERF GO-AROUND	CHECK
RADIO NAV · SEC F-PLN	AS REQD
LDG ELEV	CHECK
AUTO BRK	LOW / MED
APPROACH BRIEFING	CONFIRM
TERR · RADAR · ANTI-ICE	AS REQD

DESCENT

DESCENT CLEARANCE · FCU ALT	OBTAIN · SET
ALT KNOB	PUSH (DES) / PULL
MCDU PF · PM	PROG/PERF · F-PLN
AT FMA · THR IDLE	CHECK
NO AT THRUST	IDLE / AS REQD
BARO · ECAM STS	SET · CHECK
FL100 · LAND LTS · SEAT BELTS	ON
EFIS CSTR · LS	ON · AS REQD
NAVAIDS · NAV ACCURACY	SELECT · CHECK
APPROACH CHECKLIST	COMPLETE

APPROACH

APPROACH PHASE	CHECK ACTIVE
SPEED BRAKES · RADAR	AS REQD
TCAS	TA/RA
FLAPS 1 · FLAPS 2	SELECT
LANDING GEAR	DOWN
AUTO BRAKE	CONFIRM
GROUND SPOILERS	ARM
NOSE · RWY TURN OFF	T.O · ON
FLAPS 3 · WHEEL SD	SELECT · CHECK
FLAPS FULL	SELECT
AT A/THR · SPEED	CHECK (VAPP)
NO AT THRUST	HOLD VAPP
WING ANTI-ICE · TABLE	OFF · STOW
CABIN REPORT · LDG MEMO	CHECK

APPROACH TYPE · CHOOSE ONE

OPTION 1 · ILS (LOC/GS)

APPR PB · BOTH AP	PRESS · ENGAGE
LOC · G/S	ARMED · CAPTURE
GO-AROUND ALT	SET
LAND MODE	ENGAGED

OPTION 2 · RNAV (GNSS)

PROG · RWY BRG/DIST	INSERT
APPR PB · APP NAV	PRESS · ARMED
FINAL APP	ENGAGED
GO-AROUND ALT	SET

OPTION 3 · NPA (TRK/FPA)

NAV / LOC	AS REQD
TRK-FPA (BIRD)	SELECT
FPA · PULL	SET · ENGAGED
GO-AROUND ALT	SET

BOTH OPTIONS · CONTINUE

MINIMUM	CONTINUE / GO-AROUND

LANDING

CABIN CREW	ADVISED
AUTO THRUST · AUTOBRAKE	AS REQD
MISSED APPR ALT · ECAM MEMO	SET · CHECK

GO-AROUND

THRUST LEVERS	TOGA
ROTATION · FLAPS	PERFORM · −1 STAGE
POSITIVE CLIMB	GEAR UP
NAV / HDG · AP	AS REQD
THRUST LEVERS	CL
F · S SPEED	FLAPS 1 · 0
SPOILERS · NOSE · RWY T/O	DISARM · OFF

AFTER LANDING

GROUND SPOILERS	DISARM
LAND · STROBE · NOSE	OFF · AUTO · TAXI
RADAR · PWS	OFF
ENG START · FLAPS	NORM · RETRACT
TCAS · ATC	STBY · AS REQD
APU	START
ANTI-ICE · BRAKE TEMP/FANS	AS REQD

PARKING

ACCU PRESS · PARK BRK	CHECK · ON
ANTI-ICE	OFF
APU BLEED	ON
ALL ENG MASTERS	OFF
SLIDES	DISARMED
SEAT BELTS · BEACON	OFF
FUEL PUMPS · ATC	OFF · STBY

SECURING

PARK BRK	ON
OXYGEN CREW SUPPLY	OFF
ALL IR MODE	OFF
EXTERIOR LIGHTS	OFF
APU BLEED · EXT PWR	OFF
APU MASTER SW	OFF
EMER EXIT LT · SIGNS	OFF
BAT 1 · 2 · APU	OFF