EGB220 Mechatronics Design I
PCB Submission Form & Checklist

Team Number:

Team PCB contact person:
Email:
Mobile:

Please complete the first column of the table below.
Note you need to be compliant to *all* items below for your submission to be considered ready to be sent for fabrication.

Compliant (Y/N)	Item
Y	Board **must contain your team number on the top overlay layer**, usually called ".GTO" (Gerber top overlay) or "layer 21" in Eagle or "SilkscreenTop" in Fusion 360
Y	Board must have an outline layer used to determine the size of the board. To make the batch process quicker please use the Mech1 layer for this, or GM1 (Gerber Mech 1). This is "layer 20" in Eagle, or "BoardOutline" in Fusion 360.
Y	All the files for **each PCB** being submitted must be **in its own zip file (**I.e. **submit one zip file per PCB design).**
Y	The **first two characters** of the zip filename should be your **team number** (e.g. Team A7's file name should start by 'A7…')
Y	If you need multiple copies of the PCB make it clear in the filename and in the email, i.e. EGB220_TeamA7_SensorBoardLeft_Rev01_x10.zip to get 10 copies of SensorBoardLeft for Team A7 (Note you automatically get **5 copies** per order)
Y	Check each zip file by uploading to http://www.gerber-viewer.com/ - Verify you can see your team number on GTO
Y	Multiple board designs must be submitted as separate zip files each following naming convention above

Instructions:

1. Check your submission before emailing your order (see further instructions below)
2. Email the completed version of this form and the zip file to foe.eei@qut.edu.au
3. Subject of the email should be: '**EGB220 PCB Submission TeamXX'**, where XX is your team name (e.g. B3). You do not need to cc the teaching team.
4. Please **do not submit files with multiple levels of zip compression** (e.g. a zip file within a zip file/archive), as the PCB manufacturer cannot read those zip files inside another zip file. If you are submitting 2 sets of gerbers, e.g. sensor.zip and main.zip, please send those as two separate files in the same email.

Checking your submission beforehand
Note you can (and should!) check your Gerbers before submission by going to the following link:
https://www.pcbway.com/QuickOrderOnline.aspx

Then click on the button "+GERBERS"… this will then display the PCB if you have done it correctly. It will also point out issues such as missing drill files. It is important you check this and make the necessary corrections, to avoid having your submission rejected.