



SAFE WORK METHOD STATEMENT

Persons responsible for supervising, inspecting work, work methods , plant & equipment and tools	Supervisor/Foreman	Date:	
High Risk Construction Work:	BRICKLAYING	Project:	
SWMS prepared by Patrick Monaghan - Paneltec Group - Operations Manager and in consultation with management and workers – 2025. SWMS Review Date: August 2026 unless required earlier		Location:	
Signature: _____ 			
Approval to use this SWMS: "I certify that the attached SWMS has been reviewed by me, is endorsed for compliance with WorkSafe guidelines and is approved for use"			
<u>John Guy</u> Name	<u>Director - Paneltec Pty Ltd</u> Position	<u>0408 449 023</u> Phone	<u></u> Signature
			<u>31/08/2025 – V12.0</u> Date

RISK MATRIX

Level	Description of Consequence or Impact	Consequence	Likelihood / Probability		
			L Likely	M Moderate	U Unlikely
H (1) (High level of harm)	Potential death, permanent disability or major structural failure/damage. Off-site environmental discharge/release not contained and significant long-term environmental harm.	H (1) (High)	1	1	2
M (2) (Medium level of harm)	Potential temporary disability or minor structural failure/damage. On-site environmental discharge/release contained, minor remediation required, short-term environmental harm.	M (2) (Medium)	1	2	3
L (3) (Low level of harm)	Incident that has the potential to cause persons to require first aid. On-site environmental discharge/release immediately contained, minor level clean up with no short-term environmental harm.	L (3) (Low)	2	3	3
Level	Likelihood / Probability				
Likely	Could happen frequently				
Moderate	Could happen occasionally				
Unlikely	May occur only in exceptional circumstances				

HIERARCHY OF RISK CONTROL

The hierarchy of controls must be applied in the order below for all identified hazards.

Level 1 Eliminate the hazard
Level 2 Substitute the hazard with something safer.
Level 3 Isolate the hazard from people. Reduce the risks through engineering controls.
Level 4 Reduce exposure to the hazard using administrative actions.
Level 5 Use personal protective equipment The control measures that you put in place should be reviewed regularly to make sure they work as planned

ACTIVITY ANALYSIS

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls in Place
Training and skill.	Un-trained persons could cause injury to themselves and others.	1	1. All persons working on a housing construction site must carry with them a current 'Construction Induction Card (Red Card or equivalent). 2. All persons working on site must be suitably trained and competent in the work they are to perform.	Worker	2
Personal Protective Clothing & Equipment (PPE)	Personal injury	1	1. Before starting work on site check available PPE is adequate for all tasks to be under taken and in good working condition. Including safety boots, high visibility clothing, ear muffs, dust mask, hard hat (where designated) and other protective clothing & equipment as required. 2. Apply barrier cream to clean hands before and after work to protect against cement dermatitis. 3. When handling limil and cement, or when cutting masonry, goggles and dust mask must be worn along with other appropriate PPE.	Worker	2
UV Protection	UV Exposure; skin cancer.	1	1. Be sun smart wear a broad brimmed hat, sun/safety glasses, sun protective clothing and 30+ sunscreen.	Worker	2
Vehicle access	Vehicle Collisions with other workers or pedestrians.	1	1. Comply with speed limits on and around building site. 2. Drive only in designated access routes. 3. Do not park cars where it will create a hazard to public vehicles, pedestrians or other workers. 4. All persons are to keep completely clear of delivery areas until delivery is complete. 5. High visibility shirts to be worn when working in close proximity to vehicles. 6. If required to work near vehicles a barricaded zone will be necessary.	Worker	2
Personnel access	Trip, slip hazards.	2	1. Clear any obstacles from around all work areas before and as work progresses. 2. Keep pathways clear of trip hazards. 3. No work within 2m of an open trench or shaft unless barricades are in place. 4. Use fluorescent paint to highlight external pipes. 5. If necessary cut of PVC pipes at ground level and re-cap, mark position of pipe on slab rebate.	Worker	3

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls in Place
			6. Spread out sand to create a stable path if required 7. Before commencing work ensure that roof space is clear of any broken tiles or debris.		
Material's handling	Manual handling disorders.	2	1. Physical fitness and warm up exercises will assist in avoiding manual handling injury. 2. Materials to be lifted from trucks using lifting devices such as purpose built cranes used by competent operators where applicable. 3. If not possible to use lifting devices, lift smaller loads and work together for more awkward loads. 4. Use a wheelbarrow or trolley whenever possible. 5. Only carry what is a comfortable weight & do not overload yourself. 6. Bend your knees when lifting not your back. 7. Wheel barrow is to be kept in good serviceable condition. Tyre to be at correct pressure. 8. Have bricks delivered as close as possible to work areas. 9. When possible position wheelbarrow so it is facing the right direction once loaded. 10. When wet or muddy lay out planking as a platform for the wheelbarrow to be pushed along easily. 11. Use a brick elevator when raising materials and always maintain a clear fall zone around elevator. 12. When laying bricks place mud boards and bricks at a height and distance as to reduce twisting and bending of body.	Worker	3
Using electrical equipment	Electrical shock	1	1. Use battery powered tools where possible. 2. Test & tag electrical tools equipment every 3 months. 3. Always follow the manufactures instructions. 4. Only use heavy duty leads not over 35m in length. 5. Protect leads from damage and keep them clear of ground. 6. Do not use piggyback or portable domestic power boards. 7. Use a portable Residual Current Device (RCD-orange box with trip switch) for all electrical tools and leads. 8. Do not carry power tools by the lead. 9. Do not let electrical equipment come into contact with water or mud. Use lead stands if required.	Worker	2

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls in Place
Using Tools, Plant & Equipment.	If not in a safe & serviceable condition; various hazards.	1	1. All tools, plant and equipment to be in good working order. 2. Repair or replace worn and damaged items as necessary. 3. All persons using tools and equipment to be competently trained in their operation. 4. Read operators manuals where available. 5. If unsure how to use a tool safely ask for assistance. 6. Regularly maintain plant and machinery to manufacturer's requirements. Register details in maintenance log books. 7. Mixers to be well maintained and serviceable. • Proper guards are fitted around pulley belts; • Electric mixers have good leads and use an RCD. • Petrol driven mixers are tuned and only operate outside. • Mixer to be placed down wind of operator when possible.	Worker	2
When using cement, limil, coloured oxide & plasticiser.	Contact with hazardous substances	2	1. Obtain the Safety data Sheet (SDS) for all products and follow the safety precautions described including wearing correct PPE.	Worker	3
Drums of water on site	Drowning.	1	1. No drums of water are to be left over night without a secure lid. 2. Empty water into storm water drain if necessary.	Worker	2
Laying bricks.	Coarseness/sharp edges on bricks.	2	1. Wear gloves or Tape fingers to prevent abrasions to hands.	Worker	3
	Setting up profiles.	2	1. Securely clamp metal profiles to prevent them falling onto people working nearby.	Worker	3
	Structural collapse before completion & curing	1	1. Use brick ties or temporary bracing as required.	Worker	2
Working off a platform/trestle up to 2m high.	Fall from height	1	1. Trestles are to be erected on a stable and level surface, and in accordance with Australian Standards. 2. Working height from trestle shall not exceed the height of two meters above the supporting surface. 3. Do not exceed specified load limits. Load limit includes the total weight of persons, materials, debris, tools, equipment and impact forces. 4. Heavy duty trestles to be used, 4 planks wide whenever possible	Worker	2

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls in Place
			5. Inspect trestles and planks before every use for any fault or non-compliance. 6. Planks and supporting timbers shall overlap their supports by no less than 150mm or more than 250mm. 7. Where necessary planks should be secured against uplift. 8. Access and egress to trestles is via a suitable heavy duty ladder.		
Working above 2m	Fall from height	1	1. Use a heavy duty modular scaffold with brick guards, handed over by a licenced scaffolder as complete. 2. To prevent collapse do not load platforms with more than 100 bricks per bay or 400kg of blocks. 3. No modular scaffold alterations except by licensed scaffolder. 4. Platforms only to be accessed by a suitable heavy duty ladder or stairs.	Worker	2
	Electric shock from overhead power lines	1	1. Do not access scaffold closer than 4.6 m to power lines unless: • proof of power disconnection is sighted, or • Worker has fitted ply hoarding sheets to outside of scaffold to full height of working lift.	Worker	2
Brick Cleaning Using Hazardous Substances.	Contact with hazardous substances; inc. Hydrochloric acid and other additives.	1	1. Obtain and maintain in vehicle the 'Safety Data Sheet' for all hazardous products and follow the safety precautions described including wearing correct PPE. 2. All workers shall have undergone specific training in regard to storage and handling of hazardous substances prior to use. 3. Appropriate signage to be put in place prior to work commencing. 4. Containers of hydrochloric acid must be clearly labeled. Empty containers will not be left on site. 5. All care to be taken to contain acid/water on site, neighboring properties and wind conditions must be considered. 6. Wash/dilute excessively all wet areas with water after acid has been applied. Refer to SWMS-Brick Cleaning	Worker	2
Clean Up	Various for bricklayer and following trades.	2	1. Put waste in bin, cage or area provided. 2. Leave the site in a clean and safe manner. Note; Be aware that a back-charge may apply if this is not done.	Worker	3
	Site security; un-authorised access.	2	1. Close temporary fencing on departure.	Worker	3

ENVIRONMENTAL RISK ASSESSMENT & CONTROL MEASURES THAT MAY BE REQUIRED ON SITE DEPENDING ON THE ACTIVITY					
Work Activity Risk	Hazard	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class after Controls in place
Emergencies	Accident/ Incident Fire Spill	1	1. Personnel have been advised at toolbox meeting and are prepared in the event of an incident occurring. 2. Emergency numbers available on site. 3. Fire Extinguishers/First Aid Kits/Spill Kits on site.	Supervisor All	2
Air Quality	Exhaust Fumes Dust	2	1. Control exhaust emissions eg. Regular maintenance, replace old machinery, fit appropriate emission control measures. 2. Dampen milled surface with water cart. 3. Use water cart where required.	Supervisor All	3
Community Relations	Inconvenience as a result of works/traffic management	2	1. Identify from the list of potentially impacted parties who may be impacted by the work being undertaken. 2. Letter drops could be considered (unless specifically required) to notify residents/businesses etc. about works to be undertaken and if it has an effect on them.	Supervisor All	3
Flora & Fauna	Some works may require the removal of vegetation. Native fauna may be at risk from excavation works	2	1. Assess work area for significant vegetation: size of trees, faunal habitat - define work and exclusion areas using fencing and signage. 2. Machinery is to be thoroughly washed down prior to leaving site where noxious weeds are present.	Supervisor All	3
Heritage & Archaeology	Unmonitored excavation at significant sites can lead to loss or destruction of valuable artifacts/relics, and disturbance of historical sites. including cultural heritage and/or archaeological significance	1	1. Undertake a survey of the site to identify any areas of significance. The client's representative may undertake this. Government bodies may be able to assist. 2. Develop a project specific procedure based on the findings and recommendations. 3. Installation of exclusion fencing and signage if required.	Supervisor All	2
Noise Pollution, Community Relations & Vibration	Sensitivity to noise - to public & fauna	1	1. Work undertaken during "normal" hours where possible. 2. Affected residents notified in person or in writing. 3. Plant and equipment regularly serviced & fitted with efficient mufflers. 4. Magnitude of vibration reduced by using smaller plant etc.	Supervisor All	2

Work Activity Risk	Hazard	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class after Controls in place
Soil Management & Water Quality	Soil needs to be managed to ensure that; there are no off-site impacts. Damage to stockpile areas (not prepared properly). Mud deposited onto roadways.	2	1. Wash down machinery in only nominated areas. 2. Not within 20 metres of water courses. 3. Use only approved and nominated stockpile areas. 4. Build bund wall out of material available on site. 5. Drivers to check vehicle tyres/bodies for build up of mud when leaving stockpile sites and remove if necessary.	Supervisor All	3
Fuels and Chemicals	Contamination of waterways due to spillages of oil, degreasers, diesel, etc.	1	1. Store fuel and chemicals in accordance with relevant standards/guidelines. 2. Minimise storage on site and locate storage facilities away from drains and waterways. 3. All containers clearly labelled and Safety Data Sheets are available on site. 4. All drums stored securely and in a bunded area. 5. Spill kits or alternative spill containment materials available on site. 6. Regular maintenance of plant hoses. 7. Use correct refuelling equipment.	Supervisor All	2
Visual Impact Litter and Amenities Waste Management	Litter such as paper, plastic, and other refuse as well as being a possible safety risk may be carried off-site or washed into waterways resulting in pollution and danger to native fauna. Litter is also visually obtrusive. Production generated lighting, litter, mud, dirt and dust may also impact residents.	2	1. Use site induction to communicate the requirement for a tidy site. Also stress consideration for local residents. 2. If as a result of our works, dirt, mud, or litter affects a resident, then we will rectify this problem immediately. 3. Inspect the site frequently and insist on tidiness. Ensure public roads are free of dirt/mud from the work site. 4. Broken-out paved surfaces shall be repaired as soon as possible. 5. Remove all rubbish from site each day. 6. Waste will be recycled where possible.	Supervisor All	3

Personal Protective Equipment

All site personnel must wear the required PPE specified in the controls above, such as:

Safety Hi-vis Vests/Shirts	Safety Boots	Sunscreen	Broad Brimmed Sun Hat	Sunglasses	Gloves specific to the task	White reflective overalls/night
Hard Hat where required	Safety Glasses	Hearing protection where required	Long clothing	Dust masks	Respiratory equipment if required	

Workers may require Task Specific Training depending on activity each worker will be required to fulfill.

All workers shall hold a current Construction Induction Card						
- If required Client Site Induction - Activity Induction (SWMS & SWP's)	Vehicle Licences (Car or Truck depending on class of vehicle or mobile plant driven)	Plant Operators licences or competency assessments where required	Competencies for Work Zone Traffic Management			
First Aid certificate training	Manual Handling training	Fire Extinguisher training	Fatigue Management Training			

A Site Specific Induction & Toolbox Meeting will be held each day prior to the start of each job.

Legislation & Codes of Practice (refer to company Legislation register for applicable Australian Standards applicable to works)

Work Health & Safety Act 2012 and Work Health & Safety Regulations 2022

Codes of Practice

Confined Spaces - 2020	Hazardous Manual Tasks - 2020	Managing Noise & Preventing Hearing Loss at Work-2020	Managing Risks of Plant in the Workplace - 2018
Construction Work - 2020	How to Manage WH&S Risks - 2018	Managing Risk of Falls at Workplaces - 2020	Managing Electrical Risks in the Workplace -2019
Excavation Work - 2020	First Aid in the Workplace - 2018	Managing Work Environment & Facilities - 2020	WHS Consultation Co-operation & Co-ordination - 2018
Welding Processes - 2021	How to Safely Remove Asbestos - 2020	Managing Risk of Hazardous Chemicals - 2018	Safe Design of Structures - 2018

Plant & Equipment for this activity

- All plant is inspected prior to sending out to site
- Daily maintenance & service checks.
- Daily pre-start checks are conducted on all plant and trucks by the operators and daily checklist filled out.
- Regular servicing at 250hr intervals or as per manufactures specifications. Service History available on request to the office.

List of plant for this Activity

Engineering details/certificates/regulatory approvals/permits/electrical isolation (if applicable):

Implementation, Monitoring and Review of SWMS

The Supervisor on site has the responsibility to:

- Brief each team member on this SWMS before commencing work.
- Ensure control measures have been implemented prior to the start of works.
- Observe work being carried out.
- If controls documented in SWMS are not adequate, stop the work, review the SWMS, adjust as required and re-brief the team.
- Ensure team knows that work is to immediately stop if the SWMS is not being followed.
- Retain this SWMS on site for the duration of the high-risk construction work.
- All persons involved in these particular tasks on site must sign this document as read and understood.

SWMS attendance sheet — I have been given the opportunity to provide input into the development and review of this SWMS

Name (please print clearly)	Signature	Company	Date

Daily pre-start meetings will be held to ensure all workers are informed of control measures and additional safety hazards & controls to be noted on toolbox form.

WORK ACTIVITY BRIEFING

Implementation, Monitoring and Review of SWMS

The Supervisor on site has the responsibility to:

- Brief each team member on this SWMS before commencing work.
- Ensure control measures have been implemented prior to the start of works.
- Observe work being carried out.
- If controls documented in SWMS are not adequate, stop the work, review the SWMS, adjust as required and re-brief the team.
- Ensure team knows that work is to immediately stop if the SWMS is not being followed.
- Retain this SWMS on site for the duration of the high-risk construction work.
- All persons involved in these particular tasks on site must sign this document as read and understood.

SWMS attendance sheet — I have been given the opportunity to provide input into the development and review of this SWMS

Name (please print clearly)	Signature	Company	Date

Daily pre-start meetings will be held to ensure all workers are informed of control measures and additional safety hazards & controls to be noted on toolbox form.

WORK ACTIVITY BRIEFING**Implementation, Monitoring and Review of SWMS**

The Supervisor on site has the responsibility to:

- Brief each team member on this SWMS before commencing work.
- Ensure control measures have been implemented prior to the start of works.
- Observe work being carried out.
- If controls documented in SWMS are not adequate, stop the work, review the SWMS, adjust as required and re-brief the team.
- Ensure team knows that work is to immediately stop if the SWMS is not being followed.
- Retain this SWMS on site for the duration of the high-risk construction work.
- All persons involved in these particular tasks on site must sign this document as read and understood.

SWMS attendance sheet — I have been given the opportunity to provide input into the development and review of this SWMS

Name (please print clearly)	Signature	Company	Date

Daily pre-start meetings will be held to ensure all workers are informed of control measures and additional safety hazards & controls to be noted on toolbox form.

Implementation, Monitoring and Review of SWMS

The Supervisor on site has the responsibility to:

- Brief each team member on this SWMS before commencing work.
- Ensure control measures have been implemented prior to the start of works.
- Observe work being carried out.
- If controls documented in SWMS are not adequate, stop the work, review the SWMS, adjust as required and re-brief the team.
- Ensure team knows that work is to immediately stop if the SWMS is not being followed.
- Retain this SWMS on site for the duration of the high-risk construction work.
- All persons involved in these particular tasks on site must sign this document as read and understood.

SWMS attendance sheet — I have been given the opportunity to provide input into the development and review of this SWMS

Name (please print clearly)	Signature	Company	Date

Daily pre-start meetings will be held to ensure all workers are informed of control measures and additional safety hazards & controls to be noted on toolbox form.