

# **ROHM Sensor Platform Kit**

Distributor Training
November 2014



## Overview



- What is ROHM's Sensor Platform Kit?
- How does it work?
- How can you use it? (Sales Perspective)
- Sensor Details
- Sensor Applications


### What is ROHM's Sensor Platform Kit?



- ROHM's Sensor Platform Kit is a combined evaluation/development kit that contains the following
  - 1 Base Board Platform
  - 2 Ambient Light Sensors (1 digital, 1 analog)
  - 1 Analog Temperature Sensor
  - 1 Omnipolar Hall Sensor
  - 1 UV Sensor
  - 1 MEMs Accel + Magnetometer Sensor
  - 1 ROHM branded USB backup Battery







#### How does it work?




- Two Primary Modes of Operation
  - Standalone Mode (No PC Required)
    - "Range" based outputs (UV, Light, Temp) shown using LED output in binary format (0 to 255)
    - For any "non-ranged" outputs (Accel, Hall), different LED output schemes are used to show functionality
  - Precision Output Mode (PC Required)
    - Connect USB to PC. Simple COM port interface raw and scaled data

# How do you REALLY use it?



- Use as a Sales Tool
  - USB backup battery is provided: Kit can operate directly out of the package
  - Useful when visiting customers to show ROHM's diverse sensor lineup
- Use as an Engineering Development Board
  - Kit allows for a quick check (either in standalone or precision output mode)
  - Modular sensor boards: can be removed and connected to the user's design
  - Open hardware and open source firmware design
    - https://github.com/ROHMUSDC/ROHMSensorPlatformEVK





### **ROHM Included Sensor Details**



- BH1721FVC Digital ALS (I2C)
  - 1 to 65528 Lx Range (16bit ADC)
- BH1620FVC Analog ALS
  - Different Gain Modes allow for 0 to 100,000Lx Range
- BU52011HFV Omnipolar Hall Sensor
  - ±3.0mT switch operation point, dual output for N and S polarity
  - Different PNs in lineup have different mT operating points
- BDE0600G Temperature Sensor
  - High Accuracy Output (±3.5C @ Ta = 30C)
  - Different PNs in lineup have different thermostat trigger interrupt pin function triggering from +55C to +115C @ 5C Steps
- ML8511 Analog UV Sensor
  - Sensitive to UV-A and UV-B. Can be used to calculate UV Index. Outputs in  $mW/cm^2$
- KMX61 Accel and Mag Sensor
  - Accel: ±2g, ±4g, ±8g
  - Mag: ±1200µT
  - General: 14bit ADC, I2C

# **ROHM Sensor Applications**



- Ambient Light Sensors
  - Phones, TV, Notebook PC, Wearables, IOT/E, Portable Gaming,
     Digital Camera, LCD Displays
- Omnipolar Hall Sensor
  - Contact-less SW, Tablet/PC/Phone Covers
- Temperature Sensor
  - Thermal Protection for Electrical Equipment, FAN Control for Thermal Management
- UV Sensor
  - Smartphone, Watches, Wearables, IOT/E, Weather Stations,
     Bicycle Navigation
- Accel and Mag Sensor
  - Phone/Tablet/PC, Wearables, Game Controllers, Vehicle Stability

# Disclaimer



Some products in this document may have been replaced or may be under development. For the most current product information, contact a ROHM sales representative in your area: http://www.rohmsemiconductor.com/contact\_us/contact\_us.htm.

ROHM assumes no responsibility for the use of any circuits described herein, conveys no license under any patent or other right, and makes no representations that the circuits are free from patent infringement. Specifications subject to change without notice for the purpose of improvement.

The products listed in this document are designed to be used with ordinary electronic equipment or devices (such as audio visual equipment, office-automation equipment, communications devices, electrical appliances and electronic toys). Should you intend to use these products with equipment or devices which require an extremely high level of reliability and the malfunction of which would directly endanger human life (such as medical instruments, transportation equipment, aerospace machinery, nuclear-reactor controllers, fuel controllers and other safety devices), please be sure to consult with a ROHM sales representative in advance.

©2010 ROHM Semiconductor USA, LLC. Although every effort has been made to ensure accuracy, ROHM accepts no responsibility for errors or omissions. Specifications and product availability may be revised without notice. No part of this document represents an offer or contract. Industry part numbers, where specified, are given as an approximate comparative guide to circuit function only. Consult ROHM prior to use of components in safety, health or life-critical systems. All trademarks acknowledged.