

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : Break Table Receive Befc :
00011 "# Function :
00012 "# Call Program : MPM05
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 00000 LONG IDX_BKTY1 = 69;
00018 00001 LONG IDX_BKTY2 = 70;
00019 00002 LONG IDX_BKTZ1 = 72;
00020 00003 LONG IDX_BKTZ2 = 73;
00021 00004 LONG IDX_BKTZ3 = 74;
00022 00005 LONG IDX_BKTT1 = 75;
00023 00006 LONG IDX_BKTT2 = 76;
00024 END_VAR;
00025
00026 00007 MSEE MPS310; " Break Table Speed, Position Update
Set
00027
00028 " Chuck Break Not Command
00029
00030 // IF !MB30036 == 1;
00031 // " Break Table Vacuum On
00032 // IF !MB05686F == 1 " SCT Break Table Blow On Check
00033 // " Break Table Blow On
00034 // MB05586F = 1; " Break Table Blow On Request
00035 // IOW MB05686F | MB000800 == 1 " Break Table Blow On Check
00036 // TIM TMW26202; " Break Table Vacuum On Delay Time
00037 // IEND;
00038 //
00039 //// " Table Cleaning Brush Down status
00040 //// IF !MB056802 | !MB056803 == 1;
00041 //// MB05580F = 1;
00042 //// IOW MB05680F == 1
00043 //// IEND;
00044 // IEND;
00045
00046 // " Table Cleaning Brush Up Status
00047 // IF !MB05682E | !MB05682F == 1;
00048 // " Table Cleaning Brush Up Status
00049 // MB05582E = 1;
00050 // MB05582F = 1;
00051 // " Table Cleaning Brush Up Status
00052 // IOW MB05682E & MB05682F == 1;
00053 // IEND;
00054
00055 " Cutter X Waiting Position
00056 //IOW MB045741 == 1;
00057
00058 " Transfer Z Waiting Position Check
00059 00008 IOW MB076010 | MB07601A | MB076002 | MB076003 == 1;
00060
00061 " Table Break Glass Data Check
00062 00009 IOW !MB030036 == 1;
00063
00064 " Inner Bit Reset
00065 00010 DW00001 = 0;
00066 00011 PFORK TBL_Y1 TBL_Z1 TBL_T1 BLOW;
00067
00068 TBL_Y1:
00069 " Table Break Y
00070 00012 IF CW00099 == 1;
00071 00013 DL00100 = ML74406 + CW00212 " Table Break Y TackUp Z Moving Sync
00072 00014 IOW ILB416 < DL00100 " Table Break Y Moving Permission Z
00073 00015 Current Pos Check " Table Break Z, T Position Moving C
IOW DB00012 == 1
omplete
00074 00016 ELSE;
00075 00017 IOW DB00011 & DB00012 == 1 " Table Break Z, T Position Moving C
omplete
00076 00018 IEND;
00077 00019 IOW MB55790 & MB55791 & MB055792 == " Table Break Y Interference Check
00078
00079 00020 ML16138 = ML73806 " Table Break Y Moving Position Writ
e
00080
00081 00021 IOW MB55761 == 1 " Table Break Y Receive Before Posit
ion Moving Permission

```

```

00082
00083 00022      IF !MB56001 == 1;
00084 00023          MOV [BKTY1]ML16138 [BKTY2]ML16138;
00085 00024          IOW MB56001 == 1
                                " Table Break Y Pos. Movir
                                " Table Break Y Receive Befroe Posit
ion
00086 00025      IEND;
00087
00088 00026      DB00010 = 1;
                                " Table Break Y Receive Befroe Posit
ion
00089
00090 00027      JOINTO LabelX;
00091
00092      TBL_Z1:
00093          " Table Break ;
00094 00028          ML16144 = ML74406
                                " Table Break Z Moving Position Writ
e
00095
00096 00029      IOW MB55771 == 1
                                " Table Break Z Receive Before Posit
ion Moving Permission
00097
00098 00030      IF !MB056021 == 1;
00099 00031          MOV [BKTZ1]ML16144 [BKTZ2]ML16144 [BKTZ3]ML16144;
00100 00032          IOW MB056021 == 1
                                " Table Break Z Pos. Movir
                                " Table Break Z Receive Befroe Posit
ion
00101 00033      IEND;
00102
00103 00034      DB00011 = 1;
                                " Table Break Y Receive Befroe Posit
ion Moving Complete
00104
00105 00035      JOINTO LabelX;
00106
00107      TBL_T1:
00108          " Table Break ;
00109 00036          ML16150 = ML75002
                                " Table Break Z Moving Position Writ
e
00110
00111 00037      IOW MB055780 == 1
                                " Table Break Z Receive Before Posit
ion Moving Permission
00112
00113 00038      IF !MB056050 == 1;
00114 00039          MOV [BKTT1]ML16150 [BKTT2]ML16150;
00115 00040          IOW MB056050 == 1
                                " Table Break Z Pos. Movir
                                " Table Break Z Receive Befroe Posit
ion
00116 00041      IEND;
00117
00118 00042      DB00012 = 1;
                                " Table Break Y Receive Befroe Posit
ion Moving Complete
00119
00120 00043      JOINTO LabelX;
00121      BLOW:
00122 00044          IF !MB30036 == 1;
00123 00045              IF !MB05686F == 1
                                    " SCT Break Table Blow On Check
00124                  " Break Table Blow On
00125 00046                  MB05586F = 1;
                                    " Break Table Blow On Request
00126 00047                  IOW MB05686F | MB000800 == 1
                                    " Break Table Blow On Check
00127 00048                  TIM TMW26202;
                                    " Break Table Vacuum On Delay Ti
me
00128 00049      IEND;
00129 00050      IEND;
00130 00051      JOINTO LabelX;
00131
00132 00052      LabelX: PJOINT;
00133
00134 00053      RET;

```