

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017     CONST LONG AXIS_STR1Y1 = 16;
00018     CONST LONG AXIS_STR1Y2 = 17;
00019 END_VAR;
00020
00021 00000     PLD [STR1Y1][STR1Y2];
00022 00001     VEL [STR1Y1]ML41612 [STR1Y2]ML41612;
00023
00024 00002     DW00030 = MW07840                                " Stick Transfer 1 Y Motion Code Setting
00025
00026 00003     SFORK    DW00030 == 1 ? LBL01                      " Stick Transfer 1 Y StandBy Pos
00027                  DW00030 == 2 ? LBL02                      " Stick Transfer 1 Y Carry In Pos
00028                  DW00030 == 3 ? LBL03                      " Stick Transfer 1 Y Carry Out Pos
00029                  DW00030 == 4 ? LBL04                      " Stick Transfer 1 Y PreAlign Pos
00030                  DW00030 == 5 ? LBL05                      "
00031                  DW00030 == 6 ? LBL06                      "
00032                  DW00030 == 7 ? LBL07                      "
00033                  DW00030 == 8 ? LBL08                      "
00034                  DEFAULT ? LBL100;
00035
00036 00004     LBL01:
00037
00038 00005         IOW MB075760 == 1                                " Stick Transfer 1 Y StandBy Pos Enable
00039
00040 00006         ML16032 = ML63202                                " Move Data:Stick Transfer 1 Y StandBy P
00041 os
00042         MOV [STR1Y1]ML16032 [STR1Y2]ML16032 ;
00043 00008         IOW MB076000 == 1                                " Stick Transfer 1 Y StandBy Pos Moving
00044         Comp Check
00045
00046 00009         JOINTO LBL0X;
00047
00048 00010     LBL02:
00049
00050 00011         IOW MB075761 == 1                                " Stick Transfer 1 Y Carry In Pos Enable
00051
00052 00012         ML16032 = ML63206                                " Move Data:Stick Transfer 1 Y Carry In
00053 Pos
00054         MOV [STR1Y1]ML16032 [STR1Y2]ML16032 ;
00055 00014         IOW MB076001 == 1                                " Stick Transfer 1 Y Carry In Moving Com
00056         p Check
00057 00015         JOINTO LBL0X;
00058
00059 00016     LBL03:
00060
00061 00017         IOW MB075762 == 1                                " Stick Transfer 1 Y Carry Out Pos Enabl
00062         e
00063 00018         ML16032 = ML63210                                " Move Data:Stick Transfer 1 Y Carry Out
00064 Pos
00065         MOV [STR1Y1]ML16032 [STR1Y2]ML16032;
00066 00020         IOW MB076002 == 1                                " Stick Transfer 1 Y Carry Out Pos Movin
00067         g Comp Check
00068 00021         JOINTO LBL0X;
00069
00070 00022     LBL04:
00071
00072 00023         IOW MB075763 == 1                                " Stick Transfer 1 Y PreAlign Pos Enable
00073
00074 00024         ML16032 = ML63226                                " Move Data:Stick Transfer 1 Y PreAlign
00075 Pos
00076         MOV [STR1Y1]ML16032 [STR1Y2]ML16032 ;
00077 00026         IOW MB076003 == 1                                " Stick Transfer 1 Y PreAlign Pos Moving
00078         Comp Check

```

P00002 MPS470 : STR1 Motion 1 (STR1Y)

00079 00027 JOINTO LBL0X;
00080
00081 00028 LBL05:
00082
00083 00029 JOINTO LBL0X;
00084
00085 00030 LBL06:
00086
00087 00031 JOINTO LBL0X;
00088
00089 00032 LBL07:
00090
00091 00033 JOINTO LBL0X;
00092
00093 00034 LBL08:
00094
00095 00035 JOINTO LBL0X;
00096
00097 00036 LBL100:
00098 00037 JOINTO LBL0X;
00099 00038 LBL0X: SJOINT;
00100
00101
00102 00039 DW00030 = 0;
 reset
00103 00040 MW07840 = 0;
 reset
00104
00105 00041 RET;

" Unit8 Stick Transfer 1 Y Motion Code R
" Unit8 Stick Transfer 1 Y Motion Code R

			MPS470 : STR1 Motion 1 (STR1Y)	P00002
--	--	--	--------------------------------	--------