

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017
00018 END_VAR;
00019
00020 00000      PLD [SBTY][SBTT];
00021
00022 00001      MW08028 = 0;                                " Stick Buffer Table PIO Reset
00023
00024 00002      IF !MB002007 "& MB081322" == 1;
00025
00026 00003          MB080280 = 1;                                " [Stick Buffer Table -> Stick Transfer
00027 00004      1) Receive Possible                                " [Stick Transfer 1 -> Stick Buffer Tabl
          IOW MB075270 | MB080013 == 1
00028 00005      e) Send Possible
          EOX;
00029
00030 00006          IF !MB080013 == 1
00031 00007          MB080281 = 1;                                " [Stick Buffer Table -> Stick Transfer
00032 00008      1) Receive Star                                " [Stick Transfer 1 -> Stick Buffer Tabl
          IOW MB075271 == 1
00033      e) Send Strat
          IOW MB075275 | MB080013 == 1                                " [Stick Transfer 1 -> Stick Buffer Tabl
00034 00009      e) Vacuum On Request
          IF !MB080013 == 1;
00035      //          IF !MB000800 == 1
00036 00010          MB080888 = 1;                                " Stick Buffer Table Vacuum (
00037 00011          IOW MB081888 == 1                                " Stick Buffer Table Vacuum On Check
00038 00012          TIM TMW30412;                                " Stick Buffer Table Vacuum On Check Tim
00039 00013      er
          ELSE;
00040 00014          TIM T100;
00041 00015          IEND;
00042 00016
00043
00044 00017      MB002486 = 1;                                " Work Move : SCT Stick Transfer 1 -> St
          ick Buffer Tabl
00045 00018          IOW MB002007 == 1                                " P Wokr : Stick Buffer Tabl
00046
00047 00019      MB080282 = 1;                                " [Stick Buffer Table -> Stick Transfer
00048 00020      1) Receive Complet                                " [Stick Transfer 1 -> Stick Buffer Tabl
          IOW MB075272 == 1
00049      e) Send Complete
          //          IEND;
00050 00021          IEND;
00051
00052 00022      MW08028 = 0;
00053 00023      IEND;
00054 00024      MB081370 = 0;                                " Unit9 Cycle1 Move Check
00055
00056 00025      RET;

```