

CARGO HOLD CLEANING Checklist

(Ship's Name :)

CARGO HOLD CLEANING Checklist

(Ship's Name :)

Date		
Previous Cargo		
Next Cargo		
Charterer's cleanliness requirements		
A. At the discharge port		
No	Description / Check items	Result
1	Ensure that as much cargo residue, lashing material and / or dunnage is removed as possible and landed ashore.	
2	Deckheads, framing and bulkheads should be swept down during discharge where permitted and safe and practicable.	
3	Check bilges are free of cargo, if not, clean the bilge wells and have the cargo residues discharged ashore.	
4	Remove all cargo residues from hatches, coamings and drain channels (do not use an air hose; drain channels should be swept clean). These should be washed down if permitted, be aware that some ports having stringent requirements regarding deck water run-off.	
B. Prior to commencing hold cleaning		
No	Description / Check items	Result
5	Determine the degree of hold cleaning and preparation required by reviewing voyage instructions, the charter party and by consulting with the managers / charterers. The hold cleaning requirements in the IMSBC Code should also be followed. When determining the cleaning requirements the following points should be considered: • If the same cargo is to be carried, charterers may require no cleaning / washing and permit loading on top. • If clean cargo, such as steel coils have been carried, little or no cleaning / washing may be necessary. • Is the next cargo incompatible with the previous cargo necessitating extra cleaning? • Are cleaning chemicals / detergents required? • Will a barrier coat need to be applied? • Are sufficient cleaning tools, fresh water, chemicals, and barrier coatings onboard? • Does the loadport and / or discharge port have any specific cleanliness requirement, for example, when carrying foodstuffs or fertiliser?	

C. When the cleaning and washing requirements for the next cargo have been determined, the following points should be considered when preparing the holds		
No	Description / Check items	Result
6	A risk assessment and tool box talk should be carried out prior to work commencing.	
7	When working at height on ladders, scaffold towers or other means of access is required; ensure all relevant Permits to Work as required by the vessel's Safety Management System are completed.	
8	Sweep up or double sweep the holds to remove any remaining cargo residue, paying attention to cargo residue in bilges, on the topside of underdeck framing, and the blind side of ladders, stairs, pipework and fixtures and fittings.	
9	Where cargo residue has set hard, this should be removed by chipping or scraping.	
10	Dispose of all dry cargo residues, cargo residues in hold wash water, dunnage, lashing materials, cleaning chemicals and detergents in accordance with the requirements of MARPOL Annex V, and any applicable local regulatory requirements.	
11	Wash down hatch coamings, drain channels and compression bars, if not completed at the discharge port. Adjacent decks, mast houses and cranes may also need cleaning and must not be overlooked.	
12	Sea water wash all hold surfaces paying particular attention to underdeck framing, the underside of hatch covers, the blind side or ladders, stairs, pipework and pipe guards.	
13	With cargo residue that may set, e.g. cement, ensure copious amounts of wash water are used and the residues are discharged via portable pumps, rather than via the fixed cargo hold bilge system.	
14	After a sea water wash conduct a thorough fresh water rinse of the holds to remove all traces of sea water (chlorides); except where advised by charterers that this will not be necessary.	
15	Wash / blow through cargo hold bilge sounding pipes and thermometer pipes and ensure they are clear.	
16	Clean and disinfect bilge wells when foodstuffs are to be carried.	
17	Mop up / squeegee puddles of water remaining in the holds.	
18	Touch up cement wash in bilge wells if required and fit burlap or hessian to bilge plates when a cargo with fine particles is to be carried.	
19	Loose rust scale, loose paint flakes and paint blisters should be removed, in particular for foodstuff cargoes. Loose rust scale should not be painted over.	
20	Allow the holds to dry thoroughly, using mechanical ventilators where fitted and with consideration given to opening hatches where safe and practicable to do so.	
21	Where cargo hold paintwork has been touched up, ensure the paint is compatible with the planned cargo and painting is completed sufficiently in advance of arrival to allow the paint to thoroughly cure.	
22	When required for the next cargo, apply a barrier coating such as lime wash, hold-block or slipcoat in accordance with the manufacturers' instructions; ensuring the coating has fully dried prior to loading.	
MASTER'S INSTRUCTION OR OPINIONS		

Responsible Officer's Signature

Verified by Master