

## **Check List**

Order Code: TGM-62011 Software code: C418

Instruction : ทดสอบการทำงานของอินพุต Remote

1. Config							
Function	Input	Botton	Comment	Min	Max	Pass	Fail
SCALE High 1		SCALE+ (1)		SCALE Low 1	9999		
SCALE High 2	_	SCALE+ (2)		SCALE Low 2	9999		
SCALE Low 1		SCALE- (1)		-1999	SCALE High 1		
SCALE Low 2		SCALE- (2)		-1999	SCALE High 2		
Decimal Point 1		DP (1)	แสดงค่า เป็นตัวเลข	0	2		
Decimal Point 2	%	DP (2)		0	2		
Alarm Mode	<b>Religie</b>	OP MODE		0	4		
Alarm High 1		F1 (1)		Alarm Low 1	Alarm High 2		
Alarm Low 1		F2 (1)		Alarm Low 2	Alarm High 1		
Alarm High 2		F1 (2)		Alarm High 1	9999		
Alarm Low 2		F2 (2)		-1999	Alarm Low 1		

Prepared By	Verified By	Approved By



## **Check List**

Order Code: TGM-62011 Software code: C418

Instruction : ทดสอบการทำงานของ 4 - 20 mA

HIGH GOLDH. VIVIGE EIT 18 VI TO TREE EO T ZO TILV								
2.Modbus Poll								
Function	Channel	Send (mA)	setting			View	Pass	Fail
Function			Scale High	Scale Low	Dp	view	Fa55	i ali
		4	2000	400	2	4.00		
		12	2000	400	2	12.00		
		20	2000	400	2	20.00		
	1							
	1							
Innut								
Input	2	4	2000	400	2	4.00		
		12	2000	400	2	12.00		
		20	2000	400	2	20.00		

<u>Instruction : ทดสอบการทำงานของ Alarm</u>

2.Modbus Poll								
Function	Channel	Scale	Mode	setting Alarm High	Alarm Low	TL	Pass	Fail
	1	5.00 9.00 12.00 16.00 19.00	1	15.00	10.00	OUT 2 OFF OUT 2 ON OUT 2 OFF OUT 2 ON OUT 2 OFF		
Alarm	2	5.00 10.00 12.00 16.00 19.00	1	18.00	6.00	OUT 3 ON OUT 3 OFF OUT 3 OFF OUT 3 OFF OUT 3 ON		

Prepared By	Verified By	Approved By