TR-08 // RADIO / COMMUNICATIONS

1. PHASE ALPHA: CRISIS MONITORING ('OMG WHAT IS HAPPENING OUT THERE???')

■ **THE MONITOR-ONLY RULE:** Keep your radio configured to Monitor Mode only. Do not transmit or press the Push-To-Talk (PTT) switch unless coordinating immediate life-safety operations. Transmitting drains battery power four times faster.

■ **LOCAL EMERGENCY COORDINATION SEGMENTS:**
1. NOAA Weather Radio frequencies: Access the local Pensacola/Pace, FL broadcast loop on Channel 1 (162.400 MHz) or Channel 2 (162.425 MHz).
2. FRS/GMRS Public Radio: Monitor Channels 1 through 7 and Channels 15 through 22.
3. Amateur Radio Calling: Monitor the VHF 2-meter national calling frequency on 146.520 MHz Simplex.

2. PHASE BRAVO: LONG-TERM NETWORKING & TRANSMISSION BREVITY

■ **THE 5-SECOND BREVITY MANDATE:** Before tapping the transmission switch, write down your exact message on paper. Keep all voice calls under 5 seconds. State your tactical call sign, your location grid, and your direct needs cleanly.

■ **THE PARASITIC DRAIN CORROSION BARRIER:** If a radio, scanner, or walkie-talkie is slated for storage for longer than 30 days, you must physically remove all AA, AAA, or internal lithium battery cells from the chassis.

■ **DIRECTIONAL LINE-OF-SIGHT ALIGNMENT:** VHF and UHF emergency radio waves travel via line-of-sight paths. Climb to the highest ground position in your area (TR-04) and extend your antenna vertically to clear structural blocks.

CRITICAL PANEL / REFERENCE REGISTER
Transmitting on restricted amateur ham radio frequencies or high-power GMRS bands without an active FCC license is illegal under normal conditions. Emergency rules permit transmission only during immediate, extreme threats to life safety.

AUTHORITATIVE REFERENCES: Federal Communications Commission (FCC) Part 95 Emergency Operating Rules, National Telecommunications and Information Administration (NTIA).