

Stage right house crowd mic



Full Band Setup

32 Bottom 16 Direct

Crowd Right

| OIR | ANUEKS | | | оста, | | | | Date Updated: 2024-11-17 |
|---------------|----------------|-------|----------------|-----------|------------------|--------------------|----------------|----------------------------------|
| Musician | Position | Mixer | IEM Box | Sub Snake | Input | Mic/DI | Stand | Notes |
| | | 1 | Top 1 | Drum 1 | Chad Vocals | Shure Beta 56A | Overhead Stand | Light reverb. Light Delay |
| | S | 2 | Top 2 | Drum 2 | Kick | Shure Beta 52A | Internal | Suspended inside bass drum |
| | | 3 | Top 3 | Drum 3 | Snare | Shure Beta 56A | Drum Clamp | |
| | E | 4 | Top 4 | Drum 4 | Hi-Hat | Shure SM137 | Drum Clamp | 48V provided by IEM Box |
| (U | | 5 | Top 5 | Drum 5 | Tom 1 | Shure Beta 98AMP/C | Drum Clamp | 48V provided by IEM Box |
| | 2 | 6 | Тор 6 | Drum 6 | Tom 2 | Shure Beta 98AMP/C | Drum Clamp | 48V provided by IEM Box |
| Cha | <u> </u> | 7 | Top 7 | Drum 7 | Tom 3 | Shure Beta 98AMP/C | Drum Clamp | 48V provided by IEM Box |
| | | 8 | Top 8 | Drum 8 | Tom 4 | Shure Beta 98AMP/C | Drum Clamp | 48V provided by IEM Box |
| | | 9 | Top 9 | Drum 9 | Overhead Ride | Shure SM137 | Boom Stand | 48V provided by IEM Box |
| | | 10 | Top 10 | Drum 10 | Overhead Hat | Shure SM137 | Boom Stand | 48V provided by IEM Box |
| | | 11 | Top 11 | | | | Unused | |
| | | 12 | Top 12 | | | | Unused | |
| | | 13 | Top 13 | | | | Unused | |
| | | 14 | Top 14 | | | | Unused | |
| 11+:1:+./ | Bluetooth | 15 | Top 15 | Direct | Bluetooth Left | Direct | N/A | |
| Utility | | 16 | Top 16 | Direct | Bluetooth Right | Direct | N/A | |
| John | Store | 17 | Bottom 1 | DSR 1 | John Vocals | Shure Beta 58 | Boom Stand | Light reverb. Light Delay |
| | Stage Right | 18 | Bottom 2 | DSR 2 | John Bass | Behringer BDI 21 | Direct | |
| Bass | S | 19 | Bottom 3 | DSR 3 | John Aux | Direct | Floor | |
| Jessica | Center | 20 | Bottom 4 | DSR 4 | Jessica Vocals | Shure Beta 58A | Boom Stand | EQ up low and mid. Heavy reverb. |
| Guitar | Stage Right | 21 | Bottom 5 | DSR 5 | Jessica Acoustic | DI Box | Direct | |
| Paul | Center | 22 | Bottom 6 | DSL 1 | Paul Vocals | Shure 55SH | Boom Stand | Light reverb. Light Delay |
| Guitar | Stage Left | 23 | Bottom 7 | USL 1 | Paul Electric | Sennheiser E609 | Amp Hang | |
| Guitai | Stage zert | 24 | Bottom 8 | USL 2 | Paul Electric | Behringer B906 | Amp Hang | |
| | | 25 | Bottom 9 | | | | Unused | |
| | | 26 | Bottom 10 | DSL 2 | Kenzi Vocals | Telefunken M80 | Overhead Stand | Light reverb. Light Delay |
| Kenzi Keys | Stage | 27 | Bottom 11 | DSL 3 | Kenzi Piano | Behringer DI4800A | Piano Stand | |
| e G | Left | | Bottom 12 | DSL 4 | Kenzi Keyboard | Behringer DI4800A | Piano Stand | |
| Kenzi Keys | Leit | 29 | Bottom 13 | USL 3 | Kenzi Electric | Shure SM57 | Floor Stand | |
| | | 30 | Bottom 14 | DSL 5 | Kenzi Acoustic | Behringer DI4800A | Floor Stand | |
| I I+ili+v | Crowd | | Bottom 15 | Direct | Crowd Left | House | House | Stage left house crowd mic |
| Utility | Crowd | 32 | Bottom 16 | Direct | Crowd Right | House | House | Stage right house crowd mic |



Full Band Setup

www. the perfect strangers. band

Date Updated: 2024-11-17

| Drum & Utility Snake (Top Snake) Input | | | | | | | |
|---|--------|-------|--------|-------|-------|-------|-------|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| Chad Vocals | Kick | Snare | Hi-Hat | Tom 1 | Tom 2 | Tom 3 | Tom 4 |
| | | | | | | | |
| 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| Overhd | Overhd | | | | | BT | BT |
| Ride | Hat | | | | | Left | Right |

| Output | | | | | | | |
|----------------|-------|-------|-------|-------|--------|---|---|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| Chad Vocals | Tom 1 | Tom 2 | Tom 3 | Tom 4 | Hi-Hat | | |

| Band & IEM Snake (Bottom Snake) Input | | | | | | | |
|---------------------------------------|-----------|----------|-------------------|------------------|-------------|------------------|-------|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| John Vocals | John Bass | John Aux | Jessica Vocals | Jessica Acstc | Paul Vocals | Paul Electric | |
| | | | | | | | |
| 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| | Kenzi | Kenzi | Kenzi | Kenzi | Kenzi | Crowd | Crowd |
| | Vocals | Piano | Keys | Electrc | Acstc | Left | Right |

| Output | | | | | | | |
|----------|----------|----------------|----------|-----------|---|-----------|---------------|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| Chad IEM | John IEM | Jessica IEM | Paul IEM | Kenzi IEM | | Main Left | Main Right |

| Notes | | | | | | | |
|-------|---|--|--|--|--|--|--|
| 1 | Drum Snake outputs are used to extend splitter | | | | | | |
| 2 | Paul's IEM transmitter Port 1 does not work (capped) | | | | | | |
| 3 | Colored cables = band vocals & instruments | | | | | | |
| 4 | Black patch cables in the box are not to be unplugged | | | | | | |
| 5 | Crowd mic L/R is on ports 30/31 on bottom splitter. May require gender changer. | | | | | | |
| 6 | Talkback is on port 32 of the bottom splitter. May require gender changer. | | | | | | |

| IEM Operating Frequencies | | | | | | | |
|---------------------------|---------------|---------------|--|--|--|--|--|
| Device | Model | Frequencies | | | | | |
| Chad's IEM | Shure PSM 200 | 518 - 554 MHz | | | | | |
| Paul's IEM | Shure PSM 200 | 518 - 554 MHz | | | | | |
| Jessica's IEM | Shure PSM 200 | 518 - 554 MHz | | | | | |
| Kenzi's IEM | Shure PSM 300 | 488–937.5 MHz | | | | | |
| John's IEM | Shure PSM 200 | 518 - 554 MHz | | | | | |