Full Band Setup (Channels)

theperfectstrangers.band

Date Updated: 2026.01.03

Musician	Position	Channel	Sub Snake	Input Name	Mic/DI	Stand	Notes
Chad	Drums	1	Drum 1	Chad Vocals	Shure Beta 56A	Overhead Stand	Light reverb. Light Delay
		2	Drum 2	Kick	Shure Beta 52A	Internal	Suspended inside bass drum
		3	Drum 3	Snare	Shure Beta 56A	Drum Clamp	
		4	Drum 4	Hi-Hat	Shure SM137	Drum Clamp	48V provided by IEM Box
		5	Drum 5	Tom 1	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		6	Drum 6	Tom 2	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		7	Drum 7	Tom 3	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		8	Drum 8	Tom 4	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		9	Drum 9	Overhead Ride	Shure SM137	Boom Stand	48V provided by IEM Box
		10	Drum 10	Overhead Hat	Shure SM137	Boom Stand	48V provided by IEM Box
		11				*Unused*	
		12				*Unused*	
		13				*Unused*	
Billy Bass	Stage Right	14	DSR 1	Billy Vocals	Shure Beta 58	Boom Stand	Light reverb. Light Delay
		15	DSR 2	Billy Bass	Behringer BDI 21	Direct	
		16				*Unused*	
Jessica Guitar	Center Stage Right	17	DSR 4	Jessica Vocals	Shure Beta 58A	Boom Stand	EQ up low and mid. Heavy reverb.
		18	DSR 5	Jessica Acoustic	DI Box	Direct	
		19				*Unused*	
Paul Guitar	Center Stage Left	20	DSL 1	Paul Vocals	Shure 55SH	Boom Stand	Light reverb. Light Delay
		21	USL 1	Paul Electric	Sennheiser E609	Amp Hang	
		22	USL 2	Paul Acoustic	Behringer DI4800A	Floor Stand	
		23				*Unused*	
		24				*Unused*	
		25				*Unused*	
Kenzi Keys	Stage Left	26	USL 3	Kenzi Electric	Shure SM57	Floor Stand	
		27	DSL 5	Kenzi Acoustic	Behringer DI4800A	Floor Stand	
		28	DSL 2	Kenzi Vocals	Telefunken M80	Overhead Stand	Light reverb. Light Delay
		29	DSL 3	Kenzi Piano	Behringer DI4800A	Piano Stand	
		30	DSL 4	Kenzi Keyboard	Behringer DI4800A	Piano Stand	
Guest	Unkown	31		Guest 1 Vocals	Shure SM57	Boom Stand	Light reverb. Light Delay
		32		Guest 2 Vocals	Shure SM57	Boom Stand	Light reverb. Light Delay
Utility	Crowd	33	Direct	Crowd Left	House	House	Stage left house crowd mic
		34		*Unused*			
		35		*Unused*			
		36		*Unused*			
		37				*Unused*	
	Bluetooth	38	Direct	Bluetooth Left	Direct	N/A	
		39				*Unused*	
	Talkback	40	Direct	Bluetooth Left	Direct	N/A	

Full Band Setup (Inputs)

theperfectstrangers.band

Date Updated: 2026.01.03

WING Rack Rear Input (Local)

Input

1	2	3	4	5	6	7	8
Chad Vocals	Kick	Snare	Hi-Hat	Tom 1	Tom 2	Tom 3	Tom 4
9	10	11	12	13	14	15	16
Overhd Ride	Overhd Hat						

17	18	19	20	21	22	23	24
Crowd Left	Crowd Right			BT Left	BT Right		Talkback

Output

1	2	3	4	5	6	7	8
Billy IEM Left	Billy IEM Right	Jessica IEM Left	Jessica IEM Right	Paul IEM Left	Paul IEM Right	Kenzi IEM Left	Kenzi IEM Right

Midas DL16 Front Input (AES50A)

Input

1	2	3	4	5	6	7	8
Billy Vocals	Billy Bass	Jessica Vocals	Jessica Acstc	Paul Vocals	Paul Electric	Paul Acoustic	
9	10	11	12	13	14	15	16
	Kenzi Electrc	Kenzi Acstc	Kenzi Vocals	Kenzi Piano	Kenzi Keys	Guest 1 Vocals	Guest 2 Vocals

Output

1	2	3	4	5	6	7	8
Chad IEM Left	Chad IEM Right			Subs Left	Subs Right	Main Left	Main Right

Notes

1	Paul's IEM transmitter Port 1 does not work (capped)
2	Black patch cables in IEM box are not to be unplugged
3	Colored cables = band vocals & instruments
4	All WING Rack Local Inputs/Outputs are mapped to the rear patch panel
5	Talkback is set to Auto. Can be activated by using Wing Edit app.
6	
7	
8	
9	
10	
11	
12	

IEM Operating Frequencies

Device	Model	Frequencies
Chad's IEM	Shure PSM 200	518 - 554 MHz
Paul's IEM	Shure PSM 200	518 - 554 MHz
Jessica's IEM	Shure PSM 200	518 - 554 MHz
Kenzi's IEM	Shure PSM 300	488–937.5 MHz
Billy's IEM	Shure PSM 200	518 - 554 MHz