CPE301 - SPRING 2018

Design Assignment 2

DO NOT REMOVE THIS PAGE DURING SUBMISSION:


The student understands that all required components should be submitted in complete for grading of this assignment.

NO	SUBMISSION ITEM	COMPLETED (Y/N)	MARKS (/MAX)
1	COMPONENTS LIST AND CONNECTION BLOCK DIAGRAM w/ PINS		
2.	INITIAL CODE OF TASK 1/A		
3.	INCREMENTAL / DIFFERENTIAL CODE OF TASK 2/B		
3.	INCREMENTAL / DIFFERENTIAL CODE OF TASK 3/C		
3.	INCREMENTAL / DIFFERENTIAL CODE OF TASK 4/D		
3.	INCREMENTAL / DIFFERENTIAL CODE OF TASK 5/E		
4.	SCHEMATICS		
5.	SCREENSHOTS OF EACH TASK OUTPUT		
5.	SCREENSHOT OF EACH DEMO		
6.	VIDEO LINKS OF EACH DEMO		
7.	GOOGLECODE LINK OF THE DA		

1. COMPONENTS LIST AND CONNECTION BLOCK DIAGRAM w/ PINS

The components used for this project were the atmega xplained mini, a solderless breadboard, and LED, a push button, and some wires.

Block diagram with pins used in the Atmega328P



2. INITIAL/DEVELOPED CODE OF TASK 1

Assembly Code

```
; DA2_1.asm
; Created: 3/6/2018 10:12:34 AM
; Author : trace
start:
       ; constant declaration (value & register)
               LOOPCNT = 244; loop count for timer
       .EQU
       CLR
                       R0
                                                      ; R0 = 0
       ; port initialization
       LDI
                       R16, (1<<2)
                       DDRB, R16
       OUT
                                              ; Pb.2 output
                                              ; PORTB = 0
       OUT
                       PORTB, RO
```

```
; variable initialization
        LDI
                       R16, (1<<2)
                                              ; R16 = 0x04: bit 2 = 1
        LDI
                       R17, LOOPCNT; initialize loopCnt (loop count)
        CLR
                       R1
                                                      ; counter = 0
init:
        OUT
                       TCNTO, RO
                                                                      ; initialize Timer0 to 0
        OUT
                       TCCROA, RO
                                                                      ; Timer0: normal, internal clk
                       R18, (1<<CS00) | (1<<CS01)
        LDI
                                                      ; Timer0: enabled, 64 prescalar
        OUT
                       TCCROB, R18
timerLp:
        IN
                       R2, TIFRO
                                              ; read TOV0 (overflow)
        SBRS
                       R2, 0
                                              ; if (TOV0 is set), skip to next instr
        RJMP
                       timerLp
                                              ; jump back to timerLp
        CLR
                       R18
                                                      ; stop Timer0
        OUT
                       TCCROB, R18
                       R18, (1<<TOV0); clear TOV0 flag
        LDI
        OUT
                       TIFRO, R18
        DEC
                       R17
                                                      ; loopCnt--
        BRNE
                       init
toggle:
        IN
                       R6, PORTB
                                              ; R6 = PORTB
        EOR
                       R6, R16
                                              ; toggle bit 0 of R0
        OUT
                       PORTB, R6
                                               ; toggle Pb.0
                       R17, LOOPCNT ; reinitialize loopCnt
        LDI
        JMP
                       init
C Code
/* DA2_C.c
* Created: 3/1/2018 11:19:22 AM
* Author : trace
#define F_CPU 800000UL
#include "avr/io.h"
#include <util/delay.h>
int main ()
{
        DDRB = 1 << 2;
       while(1)
        {
```

_delay_ms(250);

```
PORTB ^= 1<<2;
}
```

3. TASK 2

Assembly Code

```
; DA2_2.asm
; Created: 3/6/2018 10:18:53 AM
; Author : trace
.org 0x0000
        ldi r16,0b00001111; Make the lower 4 bits output
        out ddrb,r16; for port b.
        LDI R20,5 ; to set prescaler
       STS TCCR1B,R20 ;Prescaler: 1024
top:
        CBI DDRD, 2
       SBIS PIND, 0 //skip next inst if pind=0
        RJMP top
        sbi portb,2; Set bit 0 immediate of port b
        rcall delay; Calling a subroutine.
        cbi portb,2; Clear bit 0 immediate of port b
        rjmp top; Relative jump to label top
delay:
        LDS R29, TCNT1H; loading upper bit of counter to R29
        LDS R28, TCNT1L; loading lower bit of counter to R28
        CPI R28,0xFF; comparing if lower is 0x84 10,000
        BRSH body
        RJMP delay
body:
        CPI R29,0x3D;3906
        BRSH done
        RJMP delay
done:
        LDI R20,0x00
        STS TCNT1H,R20 ;resetting the counter to 0 for next round
        LDI R20,0x00
        STS TCNT1L,R20 ;resetting the counter to 0 for next round
        RET
```

C Code

```
* DA2 C.c
* Created: 3/1/2018 11:19:22 AM
* Author : trace
#define F_CPU 1600000UL
#include <avr/io.h>
#include <util/delay.h>
int main(void)
{
       DDRB |= (1<<2);
       DDRD &= ^{(1<<2)};//Makes firs pin of PORTD as Input
       PORTD |= (1<<2); //Set pull up resistor
       while(1) //infinite loop
               if(PIND & (1<<PD0) == 1) //If switch is pressed
               {
                       _delay_ms(200);
                       PORTB ^= 1<<2; //Toggle Led
                       delay ms(1000);
                       PORTB ^= 1<<2; //Toggle Led
               }
       }
}
```

4. Task 3

Assembly Code

```
; DA2_3.asm
;
; Created: 2/26/2018 1:22:46 PM
; Author: trace
;
;0.5 Second Period with 50% DC
RESET:

SBI DDRB, 2; PB2 is output
LDI R16, 0; R16 = 0
OUT PORTB, R16; output Port B
LDI R17, 0x04; 3rd bit = 1
LDI R18, 15; loop initialization for .5 sec
```

```
START:
       LDI R19, 0x0
                             ;R19 = 0
       OUT TCNT0, R19
                              ;Timer0 = 0
       OUT TCCROA, R16
                              ;Timer0 = normal
       LDI R20, (1 << CS00) | (1 << CS02)
       OUT TCCR0B, R20
                              ;Enable Timer0 and set prescalar = 1024
LOOP:
                              ;Check TimerO flag register
       IN
               R21, TIFRO
       SBRS R21, 0
                       ;if overflow, dont jmp
       RJMP LOOP
       LDI R21, 0x0
                              ;R21 = 0
       OUT TCCR0B, R21
                              ;Stop Timer0
       LDI R21, (1 << TOV0)
       OUT TIFRO, R21; Clear overflow flag
        DEC R18
                    ; R21 = R21 - 1
       BRNE START
TOGGLE:
       EOR R16, R17
                              ;R16 xor R17
       OUT PORTB, R16
                              ;TOGGLE PB2
                       ;Reinitialize loop
       LDI R18, 15
       RJMP START
C Code
/* DA2 C.c
* Created: 3/1/2018 11:19:22 AM
* Author : trace
*/
#include <avr/io.h>
int main(void)
{
                                             // variable for the loop below
       unsigned int i;
       DDRB = (1<<2); // set PB2
       PORTB = 0;
                                                             // initialize PORTB to 0
       // initialize timer0 with no prescalar and normal mode
       TCCROA = 0;
       TCCROB = 1;
       TCNT0 = 0;
                              // initialize Timer0 = 0
       while (1){
               for(i=0; i<15624; i++){
                       while((TIFR0 & (1<<0)) == 0); // wait until overflow flag is set
```

```
TIFRO |= 1;
                                                                    // clear overflow flag
               }
                                                     // toggle PB2
               PORTB ^= (1<<2);
       }
}
5.
       Task 4
Assembly Code
; DA2_4.asm
; Created: 3/6/2018 10:45:18 AM
; Author : trace
.org 0
       jmp START
.org 0x20
       jmp TIM0_OVF
                                     ; Timer0 overflow interrupt vector
START:
       ; Toggle PORTB.2 every .5 second
       SBI
               DDRB,2
                                      ;PB.2 as an output
       LDI
               R18,0
                                      ;PB.2 = 0
       OUT
               PORTB,R18
                                      R16 = 0x04: bit 2 = 1
       LDI
               R16,0x04
                              ;initialize loop count to 30
       LDI R21, 15
Begin:
       LDI
               R19, 0x0
                                      ;load Timer0 = 0
       OUT
               TCNT0,R19
       OUT
               TCCROA,R18
                                      ;Timer0: normal mode, internal clock
               R17,(1<<CS00) | (1<<CS02) ;Timer0: enabled, prescalar = 1024
       LDI
       OUT
               TCCROB, R17
       ;enable interrupts
       LDI
               R20, 0x01
       STS TIMSKO, R20
                              ;enable overflow interrupt
                                      ;enable global interrupts
       SEI
Loop:
       RJMP LOOP
                                      ;infinite loop
;Timer0 overflow ISR
TIM0 OVF:
       LDI
               R20,0x0
                                      ;stop/disable Timer0
       OUT
               TCCR0B,R20
```


```
R20,(1 << TOV0); R20 = 0x01
        LDI
        OUT
                TIFRO,R20
                                       ;clear TOV0 flag
                                       ;R21--
        DEC R21
        BRNE DONE
                                       ;repeat if Timer0 hasn't overflowed 15 times
        LDI R21, 15
                       ;reinitialize loop count to 15
        EOR
                R18,R16
                                       ;toggle bit 2 of R18
        OUT
                PORTB,R18
                                       ;toggle PB.2
DONE:
                               ;load Timer0 = 0
        LDI
                R19, 0
        OUT
                TCNTO,R19
                R17,(1 << CS00) \mid (1 << CS02); Timer0: enabled, prescalar = 1024
        LDI
        OUT
                TCCROB, R17
        RETI
                                       ;return from interrupt, interrupts enabled
C Code
* DA2 C.c
* Created: 3/1/2018 11:19:22 AM
* Author : trace
*/
#include "avr/io.h"
#include <avr/interrupt.h>
                       // global variable for keeping track of # of times Timer0 overflows
volatile int ovrflw;
int main(void) {
        ovrflw= 0;
                                               // initialize ovrflw to keep track of # of times
       // Timer0 overflows
       // port initialization
        DDRB = (1<<2); // set PB2 as output
        PORTB = 0;
                               // initialize PORTB to 0
       // initialize timer0 with starting value of 0, normal mode with no pre scaler
       TCNT0 = 0;
       TCCROA = 0;
       TCCROB |= 1;
       // enable interrupts
       TIMSK0 |= (1 << TOIE0);
                                       // enable overflow interrupt
                                                       // enable global interrupts
        sei();
                                                // loop forever
        while(1);
```

```
}
// this interrupt service routine (ISR) runs whenever an overflow on TimerO occurs
ISR (TIMERO_OVF_vect) {
       if (ovrflw== 15624) {
               PORTB ^= (1<<2);
                                             // toggle PB2
               ovrflw= 0;
                                                     // reinitialize ovrflw
}
else
ovrflw++;
              // increment ovrflw
6.
       Task 5
Assembly Code
; DA2_5.asm
; Created: 3/10/2018 4:29:23 PM
; Author : trace
.ORG 0 ;location for reset
       JMP MAIN
.ORG 0x02 ;location for EXT_INT0
       JMP EXO_ISR
MAIN:
       LDI R20,HIGH(RAMEND)
       OUT SPH,R20
       LDI R20,LOW(RAMEND)
       OUT SPL,R20
       SBI DDRB,2;PB2 = output
       SBI PORTD,2 ;pull-up activated
       LDI R20,1<<INTO ;Enable INTO
       OUT EIMSK,R20
       LDI R20, (1<<ISC00 | 1<<ISC01) ;Fall Edge
       STS EICRA,R20
       SEI; Set I (Enable Interrupts)
HERE:
       JMP HERE
EXO_ISR:
       LDI R20, 1<<INTF0
```

```
STS EIFR, R20; clear flag
       IN R21,PORTB
       LDI R22,0x04
       EOR R21,R22
       OUT PORTB,R21
RETI
C Code
* DA2 C.c
* Created: 3/1/2018 11:19:22 AM
* Author : trace
*/
#include <avr/io.h>
#include <avr/interrupt.h>
#define F CPU 1600000UL
#include <util/delay.h>
int main(void)
       DDRD = (1<<2); //PD2 Input
       //PORTD |= (1<<2); //pull-up activated
       DDRB = (1<<2); //Makes PB2 output
                                                             // Enable INTO
       EIMSK = 1<<INTO;
       EICRA = 1<<ISC01 | 1<<ISC00; // Trigger INTO on rising edge
       sei();
                                      //Enable Global Interrupt
       while(1);
}
//Interrupt Service Routine for INTO
ISR(INTO_vect)
               PORTB ^= (1<<PB2); //Toggle PB2
               delay ms(1000);
               PORTB ^= (1<<PB2); //Toggle PB2
               EIFR |= (1<<INTF0); // clear the INTO flag
```

}

7. SCHEMATICS



8. SCREENSHOTS OF EACH TASK OUTPUT (ATMEL STUDIO OUTPUT)

```
- | 昴 メ © 曜 🚜
                                                                                                                                                                                                           · | j
                ; port initialization
LDI R16, (1<<2)
OUT DDRB, R16
OUT PORTB, R0
                                                                                                                                                                                           cessor Status
Name
                               R16, (1<<2)
DDRB, R16 ; Pb.2 output
PORTB, R0 ; PORTB = 0
                                                                                                                                                                                       Program Counter 0x00000015
Stack Pointer 0x08FF
                ; variable initialization

UI R16, (1<2) ; R16 = 0x04: bit 2 = 1

UI R17, LOOPCHT ; initialize loopCnt (loop count)

CLR R1 ; counter = 0
                                                                                                                                                                                       Stack Pointer
X Register
Y Register
Z Register
Status Register
Cycle Counter
                                                                                                                                                                                                                  0x0000
0x0000
                                                                                                                                                                                                                   0x0000
           init:
OUT
OUT
LDI
OUT
                                                                                                                                                                                                                  HINSVNZC
                               TCNT0, R0 ; initialize Timer0 to 0 TCCR8A, R0 ; Timer0: normal, internal clk R18, (1<<CS00) | (1<<CS01) ; Timer0: enabled, 64 prescalar TCCR08, R18
                                                                                                                                                                                                                  8.000 MHz
                                                                                                                                                                                       Stop Watch
           TIMETLP:
IN
SBRS
RJMP
CLR
OUT
LDI
OUT
DEC
BRNE
                                                                                                                                                                                       ■ Registers
                              R2, TIFR0 ; read TOV0 (overflow) ; if (TOV0 is set), skip to next instr ; jump back to timerip ; stop Timer0 ; stop Timer0 ; clear TOV0 flag TIFR0, R1B ; loopCnt-init
                                                                                                                                                                                                                   0x00
0x01
0x00
                                                                                                                                                                                        R01
                                                                                                                                                                                        R02
R03
R04
                                                                                                                                                                                                                    0x00
                                                                                                                                                                                       R05
R06
R07
                                                                                                                                                                                                                   0x00
0x00
                            R6, PORTB ; R6 = PORTB
R6, R16 ; toggle bit 0 of R8
PORTB, R6 ; toggle Pb.0
R17, LOOPCNT ; reinitialize loopCnt
init
                                                                                                                                                                                                                    0x00
      toggle.
IN
EOR
OUT
LDI
JMP
```

Figure 1 Half a cycle of Task 1 Assembly Code. 0.25 Seconds




Figure 2: Half a cycle of Task 1 C Code. 0.25 Seconds




Figure 3: Full cycle of task 1, Assembly Code. 0.5 Seconds




Figure 4: Full cycle of task 1, C Code. 0.5 Seconds




Figure 5: Full Cycle of Task 3 Assembly Code. 0.5 Seconds.

```
→ 🗘 → while (1)
main.while
    DA2 C.c
    * Created: 3/1/2018 11:19:22 AM
* Author : trace
*/
                                                                                      Name
                                                                                                      Value
                                                                                    Program Counter
Stack Pointer
   #include <avr/io.h>
                                                                                    X Register
                                                                                                  0×0000
  ∃int main(void)
                                                                                    Y Register
      unsigned int i;
                             // variable for the loop below
                                                                                    Z Register
Status Register
                                                                                                  0x0000
      DDRB = (1<<2); // set PB2
PORTB = 0;
                                                                                                  ITHSVNZC
                                   // initialize PORTB to 0
                                                                                    Cycle Counter
                                                                                    Stop Watch
                                                                                                  249.98 ms
      // initialize timer0 with no prescalar and normal mode
                                                                                    ■ Registers
                                                                                     R01
                                                                                                  0x00
      R03
                                                                                                  0x00
                                                                                                   0x00
                                                                                    R05
                                                                                                  0x00
          PORTB ^= (1<<2);
                                 // toggle PB2
                                                                                                  0x00
0x00
                                                                                                   0v00
```

Figure 6: Half Cycle of Task 3 C code. 0.25 Seconds




Figure 7: Full Cycle of Task 4 Assembly Code. 0.5 Seconds




Figure 8: Half cycle of Task 4 C Code. 0.25 Seconds

9. SCREENSHOT OF EACH DEMO (BOARD SETUP)




Figure 9: Board Setup for Task 1, Task 3, and Task 4




Figure 10: Board setup for Task 2 and Task 5

10. VIDEO LINKS OF EACH DEMO

Task 1 Assembly: https://www.youtube.com/watch?v=DoauVUG7VW8

Task 1 C: https://www.youtube.com/watch?v=ve6Gr7Gz-vQ

<u>Task 2 Assembly:</u> https://www.youtube.com/watch?v=KDIGaYRWjEc

Task 2 C: https://www.youtube.com/watch?v=A-hojAG77uE

Task 3 Assembly: https://www.youtube.com/watch?v=-HLhe0F6zU8

Task 3 C: https://www.youtube.com/watch?v=boD4b2jlvZ8

Task 4 Assembly: https://www.youtube.com/watch?v=FhFOzb6HhTY

Task 4 C: https://www.youtube.com/watch?v=CXvC9ACjI4Q

<u>Task 5 Assembly:</u> https://www.youtube.com/watch?v=-aQgYOmq2vc

Task 5 C: https://www.youtube.com/watch?v=5_HqqGo9MB4

11. GITHUB LINK OF THIS DA

https://github.com/TraceStewart/epc103gnirps8102vlnu/tree/master/DA2

Student Academic Misconduct Policy

http://studentconduct.unlv.edu/misconduct/policy.html

"This assignment submission is my own, original work".

Trace Stewart