METHOD STATEMENT

Stone Sealer WR — Silane / Siloxane Non-Film-Forming Water Repellent

Project Name		**Document No.**	OMX-MS-STONESEALERWR
Main Contractor		**Revision**	01
Consultant		**Date of Issue**	Nov 2026
Product	Stone Sealer WR	**Status**	For Approval

1. Purpose

This method statement defines the procedure, sequence, resources, quality checks and safety measures for the supply and application of Stone Sealer WR on site. It ensures that the work is carried out safely, in line with the approved drawings and project specification, and achieves the performance stated in the O MIX Technical Data Sheet.

2. Scope of Work

This method statement covers surface preparation and application of Stone Sealer WR silane/siloxane water repellent on stone, concrete, brick and masonry façades.

- Inspection and acceptance of the substrate and the work area.
- Surface preparation and repair of defects.
- Mixing and application of the material as described in this document.
- Curing, protection and handover of the completed area.
- Quality control, inspection and documentation of each stage.

3. Definitions

Term	Meaning
Water repellent	Penetrating treatment that reduces water absorption without forming a film.
Flood coat	Application until the surface is saturated without run-down.
Trial area	Small area treated to approve appearance and consumption.

4. Roles & Responsibilities

Role	Responsibility
Project Manager	Overall responsibility for planning, resources, approvals and coordination with the consultant and main contractor.
Site Engineer	Supervises the work daily; confirms substrate readiness, climate conditions, mixing, consumption and sequence; keeps daily records.

Role	Responsibility
QA/QC Inspector	Carries out inspections and tests at each stage, records results, raises inspection requests at hold points and signs the checklist.
HSE Officer	Conducts toolbox talks, checks PPE, ventilation, access and safe storage; stops work if unsafe conditions arise.
Foreman / Applicators	Carry out the work as per this method statement and report any deviation immediately.
Storekeeper	Receives, stores and issues materials in original packaging under the stated storage conditions; controls batch numbers.

5. Materials

Material	Description
Stone Sealer WR	Silane / siloxane water repellent, 20 kg containers
Repair materials	For cracks and joints before treatment

5.1 Key product data

Property	Typical Value
Base	Silane / siloxane
Appearance	Clear, non-film-forming
Reduction of water absorption	80 – 95 %
Coverage	3 – 6 m²/L
Consumption	0.2 – 0.4 kg/m² per coat
Number of coats	2
Recoat	2 – 4 hours (wet-on-dry)
Shelf life	12 months

6. Tools & Equipment

- Low-pressure sprayer
- Brushes
- Rollers
- Pressure washer
- Masking materials
- Thermo-hygrometer and surface thermometer (dew point check)
- Moisture meter
- Measuring buckets and scale
- Masking tape and protective sheeting
- Lighting and extension cables

6.1 Personal protective equipment

- Gloves
- Goggles
- Mask for spray mist

7. Storage & Handling

- 12 months in original, unopened packaging. Store at +5 °C to +35 °C, away from direct sunlight.
- Store on pallets, off the ground, in a dry, covered and ventilated area.
- Keep containers closed until use; use materials on a first-in, first-out basis.
- Keep containers tightly closed and protect from frost and direct sunlight.
- Handle with care to avoid damage to packaging; do not stack beyond the safe height.

8. Pre-Start Requirements

- Material submittal, this method statement and the inspection plan approved by the consultant.
- Work area handed over clean, free of other trades and with safe access.
- Adequate lighting, power supply and ventilation available.
- Climate conditions checked and recorded before work starts.
- A trial area prepared and approved where required by the project.
- Toolbox talk held with the work team covering this method statement and the safety measures.

9. Surface Preparation

1. Clean the surface by pressure washing or brushing; remove dirt, efflorescence and loose material.
2. Repair cracks wider than 0.3 mm and defective joints.
3. Allow the surface to dry completely.
4. Mask glass, frames and adjacent areas.
5. Prepare and approve a trial area.
6. Obtain QA/QC approval of the prepared surface before application.

10. Preparation of Material

1. Check the batch number and expiry date and record them.
2. Stir before use.
3. Use as supplied; do not dilute.

11. Application

1. Apply the first coat by low-pressure spray, brush or roller until saturated.
2. Work from bottom to top on vertical surfaces.

3. Apply the second coat after 2 – 4 hours.
4. Wipe excess from dense surfaces before it dries.
5. Record consumption per area.

12. Curing & Protection

- Protect from rain for at least 4 hours.
- Water repellency develops fully within a few days.
- Remove masking after drying.

13. Quality Control & Inspection

Check	Stage	Acceptance Criteria	By
Substrate	Before application	Clean, dry, sound	QA/QC
Trial area	Before full application	Approved	QA/QC + Consultant
Consumption	Each coat	0.2 – 0.4 kg/m²	QA/QC
Repellency	After curing	Water beads; no absorption	QA/QC

13.1 Inspection and test plan

Activity	Inspection / Test	Frequency	Record
Material receipt	Product, batch, expiry	Each delivery	Material inspection report
Surface preparation	Clean, dry, repaired	Each area	Inspection request (hold point)
Application	Coats, consumption	Each area	Daily report
Final	Water drop test	Each area	Handover checklist

14. Defects & Remedies

Defect	Likely Cause	Remedy
Dark or shiny patches	Excess material on dense surfaces	Wipe excess while wet
Poor repellency	Wet substrate; under-application	Allow to dry and re-apply
Run-down marks	Over-application on walls	Work bottom to top in lighter passes

15. Health, Safety & Environment

Hazard	Control Measures
Eye and skin contact	Gloves, goggles
Spray mist	Low-pressure spray; masks

Hazard	Control Measures
Work at height	Approved scaffolding and harness
Slips	Housekeeping

- Wear gloves and safety goggles.
- Avoid inhalation of spray mist; ensure ventilation.
- Avoid prolonged skin contact.
- Eyes: rinse with clean water for 15 minutes and seek medical advice.
- Skin: wash with soap and water.

15.1 Waste & environment

- Collect empty containers and residues in designated bins.
- Do not discharge material or washings into drains or soil.
- Allow small quantities of leftover mixed material to cure before disposal; dispose of according to local regulations.

16. Cleaning

- Clean tools immediately after use.

17. Limitations

- Do not apply on wet surfaces or before rain.
- Not a waterproofing membrane against water pressure.
- Any deviation from this method statement must be approved by the Site Engineer and the consultant.

Appendix A — Inspection Checklist

Inspection Item	Result	Remarks
Surface cleaned and dry	☐ Yes ☐ No	
Cracks repaired	☐ Yes ☐ No	
Masking done	☐ Yes ☐ No	
Trial approved	☐ Yes ☐ No	
First coat applied	☐ Yes ☐ No	
Second coat after 2 – 4 h	☐ Yes ☐ No	
Protected from rain	☐ Yes ☐ No	
Water drop test passed	☐ Yes ☐ No	

Inspected by	Signature	Date