METHOD STATEMENT

O MIX Safecoat — Hygienic Anti-Microbial Wall & Ceiling System

Project Name		**Document No.**	OMX-SMS-05
Main Contractor		**Revision**	01
Consultant		**Date of Issue**	Nov 2026
System	O MIX Safecoat	**Status**	For Approval

1. Purpose

This method statement defines the sequence, resources, inspection and test plan and safety measures for the installation of the O MIX Safecoat system on site. It describes how each layer of the system is prepared, mixed, applied, inspected and protected so that the completed system achieves the performance stated in the O MIX Technical Data Sheets of its components.

2. Scope of Work

O MIX Safecoat is a hygienic wall and ceiling system for clean and sensitive areas. A polymer-modified cementitious filler levels the surface, an acrylic sealer reduces absorption, and an anti-microbial water-based top coat resists bacteria, fungi and disinfectants.

- Substrate inspection, testing and acceptance.
- Surface preparation and repair of defects.
- Stage 1: Levelling / skim coat — O-Filler.
- Stage 2: Sealer — Carboseal.
- Stage 3: Anti-microbial top coat (2 coats) — Safe Coat AC.
- Curing, protection, final testing and handover.

2.1 System build-up

Stage	Product	Function	Consumption
1	O-Filler	Levelling / skim coat	0.5 – 1.0 kg/m²
2	Carboseal	Sealer	0.10 – 0.15 kg/m²
3	Safe Coat AC	Anti-microbial top coat (2 coats)	0.12 – 0.15 kg/m² per coat

2.2 Typical areas of use

- Hospitals and laboratories.
- Clean rooms.
- Pharmaceutical plants.
- Food processing areas.

3. Definitions

Term	Meaning
System	All layers of the build-up applied in the stated sequence.
Hold point	Stage at which work stops until QA/QC (and the consultant, where required) approve.
Recoat window	Minimum and maximum time between two layers for proper inter-layer bonding.
Dew point	Temperature at which moisture condenses; the substrate must be at least 3 °C above it.
Mock-up / trial area	Area applied before the main works to approve materials, method and appearance.

4. Roles & Responsibilities

Role	Responsibility
Project Manager	Planning, resources, approvals and coordination with the consultant and main contractor.
Site Engineer	Daily supervision; confirms substrate readiness, climate, mixing, consumption and recoat windows; keeps daily records.
QA/QC Inspector	Carries out tests at each hold point, records results and signs the inspection checklist.
HSE Officer	Toolbox talks, PPE, ventilation, safe access and storage; stops unsafe work.
Applicator Foreman	Leads the application team and follows this method statement; reports deviations.
O MIX Technical Representative	Technical support, site visits and advice on product use when requested.

5. Materials

Product	Description	Packaging
O-Filler	Polymer-Modified Cementitious Filler & Skim Coat	20 kg bags.
Carboseal	Acrylic Sealer Primer for Paints & Coatings	4 kg and 20 kg pails.
Safe Coat AC	Water-Based Anti-Microbial Coating for Hygienic Areas	5 kg and 20 kg pails.

5.1 Key product data

Product	Mixing ratio	Pot life / working time	Recoat / drying
O-Filler	3.5 – 4.0 L per 20 kg bag	30 – 40 min	24 h drying, then light sanding
Carboseal	Ready to use	—	30 – 60 minutes
Safe Coat AC	Ready to use	—	4 – 6 hours

6. Tools & Equipment

- Diamond grinder and/or shot blaster with dust extraction; industrial vacuum
- Slow-speed drill mixer (300 – 500 rpm) with spiral paddle
- Rollers, brushes, squeegees, notched trowels and steel trowels as required by each stage
- Scales and measuring containers for part mixing (where permitted)
- Thermo-hygrometer, surface thermometer and dew-point calculator
- Moisture meter and plastic sheets for moisture testing
- Masking tape, protective sheeting, barriers and warning signs
- Lighting and extension cables with residual current protection

6.1 Personal protective equipment

- Safety shoes, helmet and high-visibility vest
- Chemical-resistant gloves (nitrile) and safety goggles
- Coveralls with long sleeves
- Dust masks (P2) during grinding and powder mixing
- Respirators with organic vapour cartridges for solvent-containing products and confined spaces
- Knee pads for floor work

7. Storage & Handling

- Store all products in original, unopened packaging in a dry, shaded and ventilated store at the temperatures stated in each TDS.
- Keep Part A, Part B (and Part C) of each kit together; do not mix components from different batches.
- Protect liquids from frost and direct sun, and powders from moisture.
- Store solvent-containing products away from heat, sparks and ignition sources.
- Use materials on a first-in, first-out basis and record batch numbers for each area.
- Condition materials to +15 °C to +25 °C for 24 hours before use in hot or cold weather.

8. Pre-Start Requirements

- Approved material submittal, this method statement and the inspection and test plan.
- Approved drawings showing areas, joints, upstands, drains and details.
- Work area handed over clean, free of other trades, with safe access, lighting and power.
- Mock-up / trial area executed and approved for system, colour and finish.
- Toolbox talk held with the team on this method statement and HSE measures.
- Climate monitoring equipment calibrated and available.

9. Substrate Inspection & Acceptance (Hold Point)

Check	Acceptance criteria	Method
Concrete age	≥ 28 days (cement-based substrates)	Site records
Compressive strength	≥ 25 N/mm²	Rebound hammer (ASTM C805) or cores
Surface tensile (pull-off) strength	≥ 1.5 N/mm²	Pull-off test ASTM D7234
Climate	Substrate ≥ 3 °C above dew point; RH ≤ 85 %	ISO 8502-4 / thermo-hygrometer

10. Surface Preparation

1. Remove dust, loose paint, efflorescence and contaminants.
2. Repair holes and cracks; level the surface with O-Filler.
3. Ensure the substrate is sound and dry.
4. Mask and protect adjacent surfaces, drains and fixtures.
5. Record substrate test results and obtain QA/QC approval before priming (hold point).

11. Application Sequence

Apply the system stage by stage in the order below. Each stage must be inspected and approved before the next stage starts, and the next stage must be applied within the recoat window stated.

11.1 Stage 1 — Levelling / skim coat: O-Filler

Consumption: 0.5 – 1.0 kg/m². Time before next stage: 24 h drying, then light sanding.

1. Pour 3.5 – 4.0 L of clean water into a bucket.
2. Add 20 kg powder gradually while mixing at low speed.
3. Mix 3 minutes, rest 2 minutes, remix briefly.
4. Apply with a steel trowel in layers of 1 – 5 mm (fine) or 5 – 10 mm (coarse).
5. Allow each layer to set before applying the next.
6. Finish with a float or sponge as required.

11.2 Stage 2 — Sealer: Carboseal

Consumption: 0.10 – 0.15 kg/m². Time before next stage: 2 – 4 h.

1. Dilute up to 1 : 1 with water as recommended for the substrate.
2. Apply one coat by brush or roller.

11.3 Stage 3 — Anti-microbial top coat (2 coats): Safe Coat AC

Consumption: 0.12 – 0.15 kg/m² per coat. Time before next stage: 4 – 6 h between coats.

1. Stir thoroughly; use as supplied.

2. Apply the first coat by brush, roller or airless spray.
3. Apply the second coat after 4 – 6 hours.

12. Hold Points & Recoat Windows

Stage	Before starting	Waiting time before next stage	Approved by
1. O-Filler	Substrate accepted (Section 9)	24 h drying, then light sanding	QA/QC
2. Carboseal	Previous stage inspected and approved	2 – 4 h	QA/QC
3. Safe Coat AC	Previous stage inspected and approved	4 – 6 h between coats	QA/QC

13. Curing, Protection & Return to Service

- Protect each layer from rain, dew, dust, water and traffic until it has cured.
- Barricade the area and display warning signs during application and curing.
- Keep ventilation running in enclosed areas until full cure.

14. Quality Control & Inspection Test Plan

Activity	Inspection / Test	Frequency	Record
Material receipt	Product, batch, expiry, packaging condition	Each delivery	Material inspection report
Climate	Air / substrate temperature, RH, dew point (ISO 8502-4)	Start of shift and every 4 h	Daily climate log
Substrate	Strength, pull-off (ASTM D7234), moisture (ASTM D4263)	Each area (hold point)	Inspection request
Mixing	Complete kits, ratio, mixing time	Each mix	Daily record
Consumption	Material used vs area	Each stage	Daily record
Final inspection	Appearance, continuity, finish, details	Each area	Handover checklist

15. Defects & Remedies

Defect	Likely cause	Remedy
Poor adhesion / delamination	Weak, dusty or damp substrate; recoat window exceeded	Remove, re-prepare and reapply; abrade and re-prime if window exceeded
Pinholes / bubbles	Outgassing; air trapped in mixing; thick application	Seal porous areas; mix slowly; spiked roller; sand and recoat
Cracking of cementitious layers	Rapid drying; layer too thick	Protect from sun and wind; apply thinner layers
Colour / shade variation	Different batches; uneven application	Use one batch per area; apply additional coat

16. Health, Safety & Environment

Hazard	Control measures
Skin / eye contact with resins and cement	Gloves, goggles, coveralls; eye-wash station
Inhalation of dust and vapours	Dust extraction; ventilation; masks / respirators
Fire (solvent vapours)	No smoking or hot work; fire extinguisher at the work area
Slips and trips	Housekeeping; barricades and warning signs
Manual handling	Correct lifting; mechanical aids for drums and pails
Electrical equipment	Inspected tools; protected cables with RCD

- Read the Safety Data Sheet of each product before use.
- Keep first-aid kit and eye-wash on site; follow the first-aid measures in each TDS.

16.1 Waste & environment

- Collect empty containers and residues in designated bins.
- Allow small quantities of mixed resin to cure before disposal; dispose of according to local regulations.
- Do not discharge materials or washings into drains or soil.

17. Cleaning

- Clean tools of water-based and cementitious products with water immediately after use.
- Clean tools of epoxy and PU products with the recommended thinner before the material cures.
- Cured material can only be removed mechanically.

18. Limitations

- Do not apply outside the temperature and humidity limits stated in the TDS of each product.
- Do not apply on wet surfaces or when rain or dew is expected before the layer has cured.
- Do not mix or substitute products from other systems without written approval from O MIX.
- Any deviation from this method statement must be approved by the Site Engineer and the consultant.

Appendix A — Inspection Checklist

Inspection Item	Result	Remarks
Approved submittal and method statement on site	☐ Yes ☐ No	
Mock-up approved	☐ Yes ☐ No	
Substrate tests passed (strength, pull-off, moisture)	☐ Yes ☐ No	
Surface preparation approved	☐ Yes ☐ No	
Stage 1 — O-Filler applied and approved	☐ Yes ☐ No	
Stage 2 — Carboseal applied and approved	☐ Yes ☐ No	
Stage 3 — Safe Coat AC applied and approved	☐ Yes ☐ No	
Recoat windows respected	☐ Yes ☐ No	
Final tests passed	☐ Yes ☐ No	
Area protected and handed over	☐ Yes ☐ No	

Inspected by	Signature	Date

Appendix B — Daily Application Record

Date	Area / zone	Stage	Batch No.	Qty used	Air / substrate °C	RH %	Sign