METHOD STATEMENT

Roofguard AC — Two-Component Flexible Acrylic Cementitious Waterproofing Coating

Project Name		**Document No.**	OMX-MS-ROOFGUARDAC
Main Contractor		**Revision**	01
Consultant		**Date of Issue**	Nov 2026
Product	Roofguard AC	**Status**	For Approval

1. Purpose

This method statement defines the procedure, sequence, resources, quality checks and safety measures for the supply and application of Roofguard AC on site. It ensures that the work is carried out safely, in line with the approved drawings and project specification, and achieves the performance stated in the O MIX Technical Data Sheet.

2. Scope of Work

This method statement covers surface preparation, priming, detailing, mixing and application of Roofguard AC, a two-component flexible acrylic waterproofing coating, on roofs, terraces, wet areas and water tanks, including reinforced systems with fibreglass mesh or geotextile.

- Inspection and acceptance of the substrate and the work area.
- Surface preparation and repair of defects.
- Mixing and application of the material as described in this document.
- Curing, protection and handover of the completed area.
- Quality control, inspection and documentation of each stage.

3. Definitions

Term	Meaning
Pot life	Time the mixed material remains workable after combining Part A and Part B.
Crosswise application	Each coat applied at 90° to the previous coat.
Reinforcement	Fibreglass mesh or geotextile embedded in the wet coating.
Cove	Rounded fillet at wall/floor junctions to avoid sharp corners.
SSD	Saturated surface dry — substrate damp but without standing water.

4. Roles & Responsibilities

Role	Responsibility
Project Manager	Overall responsibility for planning, resources, approvals and coordination with the consultant and main contractor.

Role	Responsibility
Site Engineer	Supervises the work daily; confirms substrate readiness, climate conditions, mixing, consumption and sequence; keeps daily records.
QA/QC Inspector	Carries out inspections and tests at each stage, records results, raises inspection requests at hold points and signs the checklist.
HSE Officer	Conducts toolbox talks, checks PPE, ventilation, access and safe storage; stops work if unsafe conditions arise.
Foreman / Applicators	Carry out the work as per this method statement and report any deviation immediately.
Storekeeper	Receives, stores and issues materials in original packaging under the stated storage conditions; controls batch numbers.

5. Materials

Material	Description
Roofguard AC	Two-component acrylic waterproofing, 20 kg sets (5 kg liquid + 15 kg powder) and 5 kg sets
Bondmix WB	Primer (wet-surface primer on damp substrates)
Reinforcement	Fibreglass mesh or Geomat geotextile where specified
O-Flex PVC	Joint tape system for moving joints
Repair mortar	For cracks, holes and coves
Quartz sand	Dry, for broadcasting on the final coat where required

5.1 Key product data

Property	Typical Value
Mixing ratio (A : B)	1 : 3 by weight (liquid : powder) — pre-weighed sets, mix as recommended
Specific gravity	1.55
Solids content	60 % by volume
Tensile strength	1.25 MPa
Elongation at break	150 %
Adhesion to concrete	2.3 MPa
Crack bridging	up to 1 mm
Accelerated weathering	QUV 2000 h

6. Tools & Equipment

- Grinder
- Wire brushes
- Industrial vacuum
- Slow-speed mixer

- Brushes
- Rollers
- Trowels
- Scissors
- Wet-film gauge
- Thermo-hygrometer and surface thermometer (dew point check)
- Moisture meter
- Measuring buckets and scale
- Masking tape and protective sheeting
- Lighting and extension cables

6.1 Personal protective equipment

- Gloves
- Goggles
- Dust mask
- Overalls
- Safety shoes

7. Storage & Handling

- 12 months in original, unopened packaging. Store at +5 °C to +35 °C; protect the liquid from frost and the powder from moisture.
- Store on pallets, off the ground, in a dry, covered and ventilated area.
- Keep containers closed until use; use materials on a first-in, first-out basis.
- Protect bags from moisture; do not use material with lumps.
- Handle with care to avoid damage to packaging; do not stack beyond the safe height.

8. Pre-Start Requirements

- Material submittal, this method statement and the inspection plan approved by the consultant.
- Work area handed over clean, free of other trades and with safe access.
- Adequate lighting, power supply and ventilation available.
- Climate conditions checked and recorded before work starts.
- A trial area prepared and approved where required by the project.
- Toolbox talk held with the work team covering this method statement and the safety measures.

9. Surface Preparation

1. Check that the substrate is sound, clean and at least 28 days old.
2. Remove laitance, oil, loose material and old coatings by grinding or wire brushing.
3. Open and repair cracks and holes with repair mortar; form coves at wall/floor junctions.

4. Check falls to drains and repair ponding areas.
5. Dampen absorbent or hot surfaces to SSD; remove standing water.
6. Apply Bondmix WB primer and allow to dry as per its datasheet.
7. Obtain QA/QC approval of the prepared and primed surface before coating.

10. Mixing

1. Check the batch numbers and expiry dates of both parts and record them.
2. Condition materials in the shade before mixing.
3. Shake or stir Part A liquid and pour into a clean mixing bucket.
4. Add Part B powder gradually while mixing with a slow-speed mixer.
5. Mix 2 – 3 minutes to a uniform, lump-free consistency.
6. Mix complete sets only; do not add water or other materials unless specified.
7. Mix only the quantity that can be applied within the pot life.

11. Application

1. Apply a first coat to corners, drains, upstands and cracks and embed the reinforcement while wet.
2. Apply the first full coat by brush or roller at 0.25 kg/m² (or as specified for the reinforced system).
3. Apply the second coat crosswise at 90° after min. 4 hours (touch dry) and within 24 hours.
4. Apply further coats to reach the specified total consumption.
5. Broadcast quartz sand on the final wet coat where a screed or tiles will follow.
6. Work in manageable areas and finish each area in one operation where possible.
7. Check layer thickness and consumption regularly and record the results.

12. Curing & Protection

- Protect from rain for at least 24 hours and from foot traffic until dry.
- Protect from direct strong sun and wind during the first hours; mist-cure lightly in hot weather.
- 80 % cure in 7 days, full cure in 28 days; flood test after full cure where specified.
- Install the protection layer (screed, tiles, PE sheet or geotextile) after the coating has cured.

13. Quality Control & Inspection

Check	Stage	Acceptance Criteria	By
Substrate	Before priming	Sound, clean, ≥ 28 days, cracks repaired, coves formed	QA/QC
Climate	During work	+10 °C to +30 °C, no rain for 24 h	Site Engineer
Primer	Before coating	Uniform, dry	QA/QC
Consumption	Each coat	0.25 kg/m² per coat or as specified	QA/QC
Reinforcement	During first coat	Fully embedded, overlaps 5 – 10 cm	QA/QC

Check	Stage	Acceptance Criteria	By
Water test	After full cure	Flood test 24 – 48 h, no leakage	QA/QC + Consultant

13.1 Inspection and test plan

Activity	Inspection / Test	Frequency	Record
Material receipt	Product, batch, expiry, packaging condition	Each delivery	Material inspection report
Climate	Air / substrate temperature, RH, dew point	Start of shift and every 4 hours	Daily climate log
Surface preparation	Visual, moisture, soundness	Each area	Inspection request (hold point)
Application	Consumption, thickness, appearance	Each coat / area	Daily progress report
Final inspection	Visual, continuity, finish	Each completed area	Handover checklist

14. Defects & Remedies

Defect	Likely Cause	Remedy
Cracking of the coating	Too thick in one coat; fast drying	Apply in thinner coats; protect from sun and wind
Pinholes	Porous substrate; no primer	Prime; apply additional crosswise coat
Poor adhesion	Dusty, weak or wet substrate	Remove, re-prepare, prime and reapply
Thin areas	Under-application	Check consumption; apply additional coat

15. Health, Safety & Environment

Hazard	Control Measures
Skin and eye contact	Gloves, goggles, overalls; eye-wash available
Inhalation of vapours / dust	Ventilation; masks as required
Slips and trips	Housekeeping; barricades and signs
Manual handling	Correct lifting technique; mechanical aids
Electrical tools	Inspected tools; protected cables

- Wear gloves, safety goggles and a dust mask when handling the powder.
- The powder contains cement and is alkaline when wet; avoid skin and eye contact.
- Ensure good ventilation in enclosed areas.
- Eyes: rinse immediately with plenty of clean water for at least 15 minutes and seek medical advice.
- Skin: wash with soap and water.

15.1 Waste & environment

- Collect empty containers and residues in designated bins.
- Do not discharge material or washings into drains or soil.
- Allow small quantities of leftover mixed material to cure before disposal; dispose of according to local regulations.

16. Cleaning

- Clean tools with water immediately after use; cured material can only be removed mechanically.

17. Limitations

- Ambient and substrate temperature: +10 °C to +30 °C.
- Substrate clean, sound and free of standing water.
- Do not apply in rain or when rain is expected before the material has set.
- Any deviation from this method statement must be approved by the Site Engineer and the consultant.

Appendix A — Inspection Checklist

Inspection Item	Result	Remarks
Substrate sound and clean	☐ Yes ☐ No	
Cracks repaired, coves formed	☐ Yes ☐ No	
Primer applied and dry	☐ Yes ☐ No	
Complete sets mixed	☐ Yes ☐ No	
Details reinforced	☐ Yes ☐ No	
First coat applied	☐ Yes ☐ No	
Second coat crosswise	☐ Yes ☐ No	
Total consumption verified	☐ Yes ☐ No	
Protected from rain and sun	☐ Yes ☐ No	
Flood test passed	☐ Yes ☐ No	

Inspected by	Signature	Date