

# Falcon 4.0 (BMS)

Navigation: Aegean Volume

Not suited for Real Operations For FALCON BMS 4.32 Use Only

### **CONTENTS**

Rev: 1109 BMS 4.32

- 1. Contents.
- 2. TACAN Selection Normal and backup mode / ILS selection
- 3. Blank for Notes.
- 4. Airbase TURKEY
- 5. Airbase TURKEY (Continued)
- 6. Airbase GREECE
- 7. Airbase GREECE (Continued)
- 8. Airbase GREECE (Continued) CYPRUS FYROM BULGARIA
- 9. RADIO FREQ common, Mission specifics.

### Rev: 1109 BMS 4.32

#### **TACAN SELECTION - NORMAL MODE**

<ol> <li>ICP Select T-ILS page</li> </ol>	
---	--

- 2. DED Check scratchpad selected. If not use the DCS-up btn to select scratchpad entry.(between asterisks)
- 3. ICP Input TCN channel (numeric btns) then ENTER key
- 4. DED Check TCN domain (A/A TR or TR) Toggle domain with DCS-SEQ button.
- 5. DED Check band. X for ground Y for air. Change band by imputing 0 (zero) on the scratchpad.
- 6. HSI Select TCN mode and check in range (flags off)
- 7. HSI Select Radial (CRS knob) and navigate.
- 8. ICP DCS-Rtn button to return to main DED page.

#### **TACAN SELECTION - BACKUP OPS**

- TACAN switch Select BACKUP
- 2. TACAN domain As required manually A/A TR or TR
- 3. TACAN band As required manually X (ground) or Y (air)
- 4. TACAN channel manually input TCN channel.
- 5. HSI Select TCN mode and check in range (flags off)
- 6. HSI Select Radial (CRS knob) and navigate
- 7. TACAN switch Back to UFC if required.

Backup mode is provided in case of avionic failure or battle damage. When all instruments are lost the backup mode may be the only mean to recover to friendly territory. All backup switches are on the left panel.

#### ILS SELECTION

4	100	0 · · · · · · · ·	•
1.	ICP	Select T-II S	s nage

2. DED Check scratchpad selected. If not use the DCS-up btn

to select scratchpad entry (between asterisks)

3. ILS Input ILS frequency (5 digits) then ENTER key

4. CRS Check CRS selected. If not use DCS-down to select

CRS entry. Input RWY CRS (3 digits)

5. CMD STRG As required (ON or OFF) visible in HUD only

6. HSI Select TCN/ILS or NAV/ILS mode and set RWY CRS

7. ADI Confirm Flags OFF (Loc & Glide)8. HUD & HSI Confirm ILS loc & glide bars visible.

LOC interception is performed first. GLIDE interception then follows **from below**. Normally LOC and GLIDE interception is completed at Outer Marker and gear is lowered.

### Rev: 1109 BMS 4.32

# PAGE INTENTIONALLY LEFT BLANK USE FOR NOTES

# AIRBASES - TURKEY

Airport		wr /VHF)	Tcn	Ch	Tcn Rng	ILS (RWY)	Runway	Elev	GPS Coord
ADNAN MENDERES (IZMIR)	257.8	118.1	098	Х	100	110.3 (34L) 108.5 (16L)	16/34 L/R	412	N38°18.077 E27°04.379
AFYON	257.8	122.1	099	Х	50	No ILS	14/32	3310	N38°44.176 E30°32.784
AKHISAR	257.8	122.1	039	Х	50	No ILS	16/34 L/R	263	N38°48.791 E27°47.548
AKINCI (Ankara)	362.3	122.1	092	Х	100	No ILS	03/21	2767	N40°05.022 E32°37.966
ANTALYA	257.8	126.1	102	Х	100	108.1 (34R) 108.7 (16R) 110.3 (34L)	34/16 L/R	177	N36°54.555 E30°35.233
ATATURK (Istanbul)	257.8	118.1	072	х	100	110.3 (16R) 111.1 (16L) 111.3 (34R) 111.5 (34L)	34/16 LR	163	N40°59.192 E28°57.441
BALIKESIR	257.8	122.1	043	Х	50	No ILS	01/19	340	N39°37.882 E27°56.436
BANDIRMA	257.8	122.1	047	Х	50	No ILS	01/19	170	N40°19.373 E28°03.870
BURSA	253.7	122	No	tac	an	No ILS	01/19	318	N40°14.523 E29°04.818
CANAKKALE AB	257.8	123.6	049	Х	50	No ILS	03/21	22	N40°08.794 E26°31.313
CARDAK	257.8	118.6	060	Х	50	110.7 (26)	08/26	2795	N37°46.893 E29°34.677
CIGLI	257.8	122.1	083	Х	50	No ILS	16/34	16	N38°31.530 E26°56.445
CORLU	362.3	120.37	106	Х	50	110.5 (05L)	05/23 L/R	574	N41°08.663 E28°04.997
DALAMAN	257.8	118.5	100	Х	50	110.1 (01)	01/19	20	N36°43.296 E28°35.202
ESENBOGA	257.8	118.1	090	Х	50	108.9 (02L) 108.1 (20L) 110.3 (02R) 108.3 (20R)	02/20 LR	3125	N40°07.840 E33°03.816
ESKISEHIR	257.8	122.1	091	X	50	No ILS	08/26	2581	N39°47.790 E30°36.908
ETIMESGUT	257.8	122.1	113	Х	50	110.5 (11)	11/29	2653	N39°57.544 E32°44.260
GAZIEMIR	314.8	120.3	No	tac	an	No ILS	Strip NS	412	N38°20.024 E27°04.416

# AIRBASES - TURKEY (Cont)

Rev: 1109 BMS 4.32

Airport	_	wr /VHF)	Tcn C	h	Tcn Rng	ILS (RWY)	Runway	Elev	GPS Coord
GUVERCINLIK	347.9	129,0	No	tac	an	No ILS	Strip EW	2694	N39°56.633 E32°47.801
HEZARFEN (istanbul)	314.8	120.3	No	tac	an	No ILS	Strip NS	229	N41°07.605 E28°43.967
KAKLIC	314.8	122.1	115	Χ	50	No ILS	16/34	13	N38°31.530 E26°54.3787
KONYA	257.8	122.1	088	Χ	50	No ILS	01/19	3381	N37°59.273 E32°26.637
KOSEKOY	347.9	129,0	No	tac	an	No ILS	Strip EW	32	N40°46.207 E30°08.207
KUTAHYA	257.8	122.1	046	Χ	50	No ILS	16/34	3026	N39°25.414 E30°02.636
SABIHA GOKCEN	243.1	128.55	025	X	100	109.9 (05R) 110.9 (23L)	05/23 L/R	268	N40°54.732 E29°27.704
SAMANDIRA	314.8	120.3	No	tac	an	No ILS	Strip NS	400	N40°59.523 E29°21.635
SULEYMAN DEMIREL	337.8	119.2	122	Χ	100	No ILS	05/23 L/R	2835	N37°47.213 E30°28.070
SIVRIHISAR	257.8	122.1	029	Χ	50	No ILS	11/29	3194	N39°27.369 E31°22.617
TEMELLI	314.8	120.3	No	tac	an	No ILS	Strip NS	2564	N39°44.623 E32°24.351
TOPEL	362.3	122.1	086	Χ	50	No ILS	08/26	182	N40°44.907 E30°11.900
YALOVA	314.8	120.3	No	tac	an	No ILS	Strip EW	6	N40°41.202 E29°29.430
YENISEHIR	340.3	124.2	079	X	50	109.7 (26)	08/26	764	N40°15.398 E29°39.0761

# AIRBASES - GREECE

Airport		wr 7/VHF)	Tcn Ch		Tcn Rng	ILS (R	WY)	Rwy	Elev	GPS Coord
ALEXANDRIA	257.8	123.5	Ν	lo ta	can No ILS		12/30	26	N40°39.406 E22°36.856	
ALEXANDROU- POLIS (Dimokritos)	257.8	123.8	085	Х	50	No I	LS	08/26	19	N40°51.500 E26°06.167
AMIGDHALEON	257.8	122.1	٨	lo ta	ıcan	No I	LS	14/32	203	N40°58.515 E24°29.133
CHIOS	257.8	122.7	123	Χ	50	No I	LS	01/19	16	N38°20.827 E26°03.046
CHRISOUPOLIS (mega Alexandros Intl)	257.8	118.4	063	Х	50	No I	LS	05/23 LR	16	N40°55.809 E24°46.110
ELEFSIS	362.3	120.15	019	Χ	50	No I	LS	01/19	144	N38°04.661 E23°27.343
HELLINIKON	257.8	118.1	Ν	lo ta	ıcan	No I	LS	16/34	68	N37°54.906 E23°37.044
IRAKLION (Nikos Kazantzakis)	257.8	120.85	020	Х	100	110.8	(30)	12/30	114	N35°19.331 E24°52.382
KALAMATA	257.8	120.75	064	X	50	110.6	(34)	16/34	26	N37°04.775 E21°50.964
KARPATHOS	257.8	123.2	033	X	50	No I	LS	12/30	65	N35°26.875 E26°51.093
KASTELI	362.3	122.1	056	Χ	50	No I	LS	02/20	1181	N35°12.206 E25°00.578
KOMOTINI	366.3	119.7	N	o ta	can	No I	LS	Strip EW	78	N41°07.222 E25°29.123
коѕ	257.8	121.05	027	Х	50	110.9 110.9	(14) (32)	14/32	410	N36°48.490 E26°53.211
KOZANI (Filippos)	257.8	118.2	033	Χ	50	No I	LS	14/32	2080	N40°17.563 E21°55.455
LAMIA	366.3	119.7	N	o ta	can	No I	LS	Strip EW	98	N38°53.049 E22°24.302
LARISA	257.8	120.55	027	Х	50	No I	LS	08/26	239	N39°39.295 E22°29.985
LEROS	257.8	124.95	N	lo ta	ıcan	No I	LS	14/32	36	N37°11.122 E26°38.570
LIMNOS	257.8	128.5	095	Х	50	No I	LS	03/21	16	N39°55.861 E25°15.885
MARATHON	355.1	119.1	N	lo ta	ıcan	No I	LS	Strip NS	711	N38°09.247 E23°55.155
MARITSA	257.8	118.1		lo ta	ıcan	No I	LS	08/26	203	N36°23.372 E27°53.538

# **AIRBASES - GREECE (Cont)**

Airport	_	wr 7/VHF)	Tcn Tcn Ch Rng			ILS (RWY)	Rwy	Elev	GPS Coord
MEGARA	282.2	123.5	N	lo ta	ıcan	No ILS	08/26	120	N37°00.147 E23°15.861
MIKONOS	257.8	119.87 5	037	Х	50	No ILS	16/34	450	N37°25.252 E25°11.198
MITILINI	257.8	123.85	033	Х	50	No ILS	14/32	55	N39°03.202 E26°33.999
NEA ANCHIALOS	257.8	122.1	103	X	50	No ILS	08/26	82	N39°13.430 E22°47.718
OLIMBOI	366.3	119.7	N	lo ta	ıcan	No ILS	Strip EW	656	N39°14.791 E25°51.742
PARADISI (Dioagoras - Rodos)	381.0	118.2	121	Х	50	110.3 (26)	08/26	16	N36°21.755 E27°51.399
POLIKHNITOS	355.1	119.1	N	lo ta	ıcan	No ILS	Strip NS	649	N39°05.287 E26°09.617
SAMOS	257.8	122.1	053	Х	50	No ILS	08/26	32	N37°41.826 E26°47.228
SANTORINI	257.8	118.05	111	Х	100	No ILS	16/34	131	N36°24.362 E25°13.670
SKIATHOS	257.8	126.05	N	lo ta	ıcan	No ILS	02/20	49	N39°11.454 E23°28.252
SKIROS	257.8	123.2	108	Χ	50	No ILS	01/19	49	N38°57.468 E24°28.344
SOUDA	257.8	121.1	061	X	50	110.6 (11) 110.6 (29)	11/29	492	N35°32.431 E23°51.311
SPARTI	366.3	119.7	N	lo ta	ıcan	No ILS	Strip EW	498	N36°58.813 E22°20.292
STEFANOVIKION	366.3	119.7	N	lo ta	ıcan	No ILS	Strip EW	147	N39°29.690 E22°47.094
TANAGRA	257.8	120.25	112	Χ	50	No ILS	11/29	485	N38°20.552 E23°29.012
TATOI	257.8	118.5	N	lo ta	ıcan	No ILS	03/21	784	N38°07.014 E23°41.200
THESSALONIKI	257.8	118.1	065	Х	100	109.5 (01)	01/19 15/33	22	N40°31.057 E23°05.760
TRIPOLIS	257.8	122.1	035	Х	50	No ILS	02/20	2112	N37°32.167 E22°15.802
TYMPAKI	257.8	122.1	035	Х	50	No ILS	08/26	6	N35°04.162 E24°27.797

# **AIRBASES - GREECE (Cont)**

Airport	Tw (UHF/		Tcn Ch		Tcn Rng	ILS (	RWY)	Rwy	Elev	GPS Coord
VENIZELOS INTL	278.7 1	118.625	066	X	100	111.1 111.1 110.5 110.5	(02R) (20L) (02L) (20R)	02/20 LR	308	N37°58.163 E23°50.191

### **AIRBASES - CYPRUS**

Airport		wr /VHF)	Tcn C	h	Tcn Rng	ILS (F	RWY)	Rwy	Elev	GPS Coord
AKROTIRI (RAF)	339.9	122.1	107	Χ	100	109.7	(29)	11/29	75	N34°35.853 E32°37.3351
PAPHOS INT.	279.1	119.9	062	Х	50	108.9	(29)	11/29	39	N34°43.935 E32°07.599

### **AIRBASES - FYROM (Former Republic of Yugoslavia)**

Airport	Twr (UI	HF/VHF)	Tcn C	h	Tcn Rng	ILS (F	RWY)	Rwy	Elev	GPS Coord
SKOPJE	365.2	118.5	075	Х	50	108.7	(34)	16/34	754	N41°57.908 E21°51.550

# AIRBASES - BULGARIA

Airport		wr /VHF)	Tcn (	Tcn Ch Rng		ILS (R	ILS (RWY)		Elev	GPS Coord
BEZMER	320.3	122.8	No	No tacan			No ILS		509	N42°25.559 E26°38.067
BURGAS	314.9	119.9	057	057 X 50			(03)	03/21	135	N42°35.600 E27°51.355
CHERNOVO	256.4	118.9	No	No tacan			LS	Strip EW	2276	N42°25.893 E24°02.743
DOLNI RAKOVETS	366.8	122.8	No	tac	an	No I	LS	11/29	1997	N42°26.266 E23°15.117
LVAKHOVO	256.4	118.9	No	tac	an	No I	LS	Strip EW	760	N42°09.189 E24°29.703
PLODIV/KRUZOVO	315.6	119.6	096	096 X 50		111.1	(30)	12/30	597	N42°05.083 E25°06.389
UZUNDZHOVO	289.9	121.5	No	tac	an	No I	LS	11/29	567	N41°58.246 E25°50.188

# **RADIO FREQUENCY - COMMON**

Guard	243.0	UHF
	121.5	VHF

### **RADIO FREQUENCY - MISSION SPECIFIC**

СН	FREQ	7	377.1 / 132.35	14	377.2 / 121.1
1	297.5 / 138.05	8	292.2 / 126.15	15	
2	381.30 / 138.10	9	264.6 / 132.875	16	
3	275.8 / 138.2	10	286.4 / 132.325	17	
4	294.7 / 126.2	11	354.4 / 123.575	18	
5	279.6 / 134.25	12	269.1 / 121.2	19	
6	349.00 / 133.15	13	307.3 / 119.5	20	280.5 / 121.7