

数据名：分料送料IO映射

```
1 ;
2
3 // 1层皮带
4 Y30:= Conveyor[1].阻挡气缸 OR M70 ;
5 Y31:= Conveyor[1].分料气缸 OR M71;
6 Y10:= (Conveyor[1].输送线正转 OR M72 OR 上料按钮[1])& NOT M8;
7 Y11:= (Conveyor[1].输送线反转 OR M73)& NOT M8;
8 Y12:= Conveyor[1].输送线慢速 OR M74;
9
10 上料按钮[1]:=M253& SM8040&S20;
11
12
13
14
15
16 // 2层皮带
17
18 Y32:= Conveyor[2].阻挡气缸 OR M75;
19 Y33:= Conveyor[2].分料气缸 OR M76;
20 Y13:= (Conveyor[2].输送线正转 OR M77 OR 上料按钮[2])& NOT M8;
21 Y14:= (Conveyor[2].输送线反转 OR M78)& NOT M8;
22 Y15:= Conveyor[2].输送线慢速 OR M79;
23
24 上料按钮[2]:=M252 & SM8040&S20;
25
26
27 // 3层皮带
28
29
```

数据名：分料送料IO映射

```
30 Y34:= Conveyor[3].阻挡气缸 OR M81;
31 Y35:= Conveyor[3].分料气缸 OR M82;
32 Y16:= (Conveyor[3].输送线正转 OR M83 OR 上料按钮[3])& NOT M8;
33 Y17:= (Conveyor[3].输送线反转 OR M84)& NOT M8;
34 Y20:= Conveyor[3].输送线慢速 OR M85;
35
36 上料按钮[3]:=M251& SM8040&S20;
37
38 // 4层皮带
39
40
41 Y36:= Conveyor[4].阻挡气缸 OR M86;
42 Y37:= Conveyor[4].分料气缸 OR M87;
43
44
45 Y21:= (Conveyor[4].输送线正转 OR M88 OR 上料按钮[4])& NOT M8;
46 Y22:= (Conveyor[4].输送线反转 OR M89)& NOT M8;
47 Y23:= Conveyor[4].输送线慢速 OR M90;
48
49 上料按钮[4]:=M250& SM8040&S20;
```