GEHETI	:			Hellige-kom			erenz nr. 10	UNTUBER 1942
Datum	Walzenlage			Ringstellung			Steckerverbindungen	Kenngruppen
31	IX	VIII	II	23	02	08	AZ BT CO EG IQ JR KX LP MN UV	XVZ WMM DLZ RVV
30	VII	V	IX	03	10	22	AB CW DO GP HZ IM JY LR SU TX	WTI YKM SNQ CZJ
29	IX	VII	III	04	23	16	AE CN FW GS IL JR KV MX PQ YZ	RBF XPQ ULF FAZ
28	III	IX	IV	12	21	25	AC BR DX FY GP HI KN LV MQ OS	CCK WNH ZCL WFL
27	IX	IV	VI	06	17	09	AW CG DR EJ FN HS LU OP QT VZ	TGK OCI IVL ZOT
26	VIII	II	IX	14	10	18	AD BV CX EU HS JR KQ LT MP WY	LBC NJN CSK URH
25	III	VII	IX	09	03	15	AY CM EZ FS GJ HX NU OP QW TV	DQT RON WDW YVA
24	II	IX	VIII	16	09	10	BY CV FU GH IN JQ KW LZ OT PX	TEP YFV CTH EII
23	VII	IX	I	07	11	12	AW BF CJ DU GY HP IT KQ MV RS	RKX AXZ XLV VQL
22	IX	VIII	III	03	01	02	AP BW CR DZ EO FI GY JU KV LM	QFG FMF UKD BCV
21	VIII	I	IX	12	10	19	AP BN CF GY HW IR KL MV OT UZ	YMB ILO DJU GBW
20	IX	IV	VIII	01	26	22	AJ BY CW DO FX GU HQ LN RT SV	ORS AQK VBR EAF
19	II	IX	VIII	25	15	11	AV BI CH DQ GM KP NW OY SX UZ	YOR RBL PIC VNW
18	VII	VIII	IX	17	03	13	AL BO CV DM FR IW JN PU SZ TX	SBM IBX LBD BFI
17	IX	III	V	24	03	12	AF BX CY EU GN IS JK OP QV TZ	MWN BBQ VQE BRZ
16	VI	IX	II	03	16	25	AH BC DX EV GU KS LQ MY NT RW	UIJ EZX QNP OJL
15	IX	V	I	20	16	06	BK CR DX EL FY GI JQ MT OP SZ	CHR XOH YOI UVO
14	III	VII	IX	12	22	04	AK BT CE DV GJ LO MX NW PR SY	RYD LVI RED DJX
13	V	IX	VIII	22	03	17	BG CT DM FU HJ IP NO QS RV XY	JKI XWR JMM KZM
12	VIII	III	IX	23	13	10	AO BR CD FN GZ HM IL PW SU VY	XLW NJD VAF WAP
11	II	I	IX	11	19	23	BY CN DI FW GJ LP MR QX TZ UV	BQO NKQ NXR QHM
10	IV	IX	VII	16	01	11	AD BW CH ES FV IU JP KQ OZ RT	LJT HHO IND VFY
9	IX	IV	II	06	03	07	BI CM EG JV KO LW NX PZ QR SU	HBO LBV FZH USS
8	IV	IX	VII	22	05	07	BI DE FG HU KT LN MY OR PX QW	STF XKH AJO UBX
7	II	I	IX	02	06	20	AM BD CV GT HX IQ JN KU OS PW	OAF ZFS RNC VIT
6	VIII	V	IX	16	12	11	AR BF DY EM GT HL JQ KP SW XZ	AQZ SXD FFE EYV
5	II	IX	VIII	05	17	15	CW DP ET GY HJ IR KO MN QV SX	MON GUQ ULO NMH
4	IX	VI	V	18	01	04	AB CV DG FQ IR JM LX NS TU YZ	TPD AXG WWR HWW
3	VIII	I	IX	16	01	01	AI BZ CL DP FV GT JK OQ RS UY	HUY DLC UKO LAJ
2	II	I	IX	07	02	04	AE BX CR FY GT HU IS JM OQ WZ	IIH ZAN IKM CZR
1	IX	VI	IV	15	11	05	AV CK DL EU FH GI JO NX PW YZ	IMP FLS GEW SXT