# COMPRESSOR PACKAGE QUICK QUOTE REFERENCE SHEET

This sheet is meant only as a guide. Site visits and evaluations are still recommended to ensure the proper compressor package is quoted for the application.

#### **Step 1 Count Tools**

Count the total number of tools in use at one time and we'll calculate the cfm required to operate

Tools	CFM	Tools	CFM	Tools	CFM
x 3/8 Impact Wrench(s) =		x 6 inch Orbital Sander(s) =		Sandblasting Nozzles	
x ½ Impact Wrench(s) =		x 8 inch Orbital Sander(s) =		x 3/32 inch @ 90PSI =	
x 3/4 Impact Wrench(s) =		x 7 inch Air Sander(s) =		x 1% inch @ 90PSI =	
x 1 Impact Wrench(s) =		x 6 inch DA Sander(s) =		x 3/32 inch @ 90PSI =	
x 1/4 Air Ratchet(s) =		x 7 inch DA Sander(s) =		x 3/16 inch @ 90PSI =	
x 3/8 Air Ratchet(s) =		x Nail Gun(s) =		x ¼ inch @ 90PSI =	
x ½ Air Ratchet(s) =		x Staple Gun(s) =		x 5/16 inch @ 90PSI =	
x 1/4 Die Grinder(s) =		x ¼ Inch Nozzle		x ¾ inch @ 90PSI =	
x High Speed Grinder(s) = _		Blow $Gun(s) =$		x 1/16 inch @ 90PSI =	
x 3 inch Cut Off tool(s) =		x 1/4 Air Drill(s) =		x ½ inch @ 90PSI =	
x HVLP Paint Spray Gun(s) = _		x 3/8 Air Drill(s) =			
x 5 inch Orbital Sander(s) = _		x ½ Air Drill(s) =		Total tool CFM Demand =	
Other Equipment Count ALL other equipment that us	es air.	Other Equipment CFM =		Total CFM Demand of Equipment and Tools =	

#### Or Use the Technician Count Method

When using the technician only method it is critical to make sure and count ALL technicians that may be using tools at any one time to get a proper CFM total.

Type of tools used		Number of Techs		CFM
Impact Wrenches, Air ratchets, Staple/Nail Guns	х		=	
Grinding/Sanding/Coating Applications	х		=	
Total Technician CFM usage	Х		=	



## Step 2 Choose Your Equipment

Reciprocating Compressor  The maximum operating duty cycle on a reciprocating compressor is 70% optimal is 50%					

Oil free Reciprocating Compressor						
The maximum operating duty cycle on a oil free reciprocating compressor is 50% optimal is 30%						
30% Duty Cycle	50% Duty Cycle					

Rotary Screw Compressor					
The maximum operating duty cycle on a rotary screw compressor is 100%, optimal is 70%					
60% Duty Cycle	70% Duty Cycle	80% Duty Cycle			

Average Compressor CFM Production per horse power						
Reciprocating	CFM@175PSI	Rotary Screw	CFM@150PSI	CFM@125PSI		
5HP	18	5HP	16	18		
7.5HP	24	7.5HP	26	28		
10HP	35	10HP	38	40		
15HP	50	15HP	54	60		
20HP	80	20HP	78	85		
25HP	95	25HP	102	108		
		30HP	125	130		
		40HP	155	160		
		50HP	185	200		
		60HP	210	235		

Quick Metric Conversions					
	Amount		CFM		
Liters per minute to CFM		=			
Cubic meters per minute to CFM		=			
	Amount		PSI		
Bar to PSI		=			

### **KNIGHT COMPRESSORS**

sales@knight-compressor.com service@knight-compressor.com Dependable, hard-working, air compressors

