

# Kiss Me - Sixpence None the Richer

Stratocaster (HSS), GP-5 only. "Kiss Me" is built on a bright, clean, twee strum -- Fender Twin-clean rhythm guitar with light chorus running throughout -- and a lifted, shimmering tone with slapback delay for the instrumental hook and bridge. Tempo: 145 BPM.

## GP-5 Settings

Module order: NR -> PRE -> DST -> AMP -> CAB -> EQ -> MOD -> DLY -> RVB

- **NR -- Gate.** THRE 15. Light gate -- this patch stays clean and dynamic, don't choke the strum. Always on.
- **PRE -- COMP4.** Sustain 30, Attack 70, Clip 20, VOL 55. Gentle compression, evens out strum dynamics without squashing the pick attack. Always on.
- **DST -- Yellow OD.** Gain 20, VOL 65. Off for the main verse strum -- stays fully clean. On for the hook/bridge -- a light boost that lifts the tone, not real distortion. On CTL.
- **AMP -- Dark Twin (Fender 65 Twin Reverb).** Gain 30, VOL 60, Bass 45, Middle 45, Treble 65, Bright on. Base tone for both states -- glassy, bright Twin clean.
- **CAB -- Dark Twin 2x12.** VOL 55. Matched cab for the Twin sim.
- **EQ -- Guitar EQ 1.** 125Hz -5, 400Hz -8, 800Hz -3, 1.6kHz +8, 4kHz +10, VOL 55. Cuts low-mid mud, pushes highs for that bright, twee jangle. Always on.
- **MOD -- A-Chorus.** Depth 18, Rate 1.0Hz, Tone 55. Light chorus, both states -- this is the song's signature shimmer, always present under the strum. Always on.
- **DLY -- Slapback.** Mix 22, Time 110ms, Feedback 15, Trail on. Off for the verse -- keeps the main strum direct. On for the hook/bridge -- the slapback is what makes the lifted sections bounce and shimmer. On CTL.
- **RVB -- Room.** Mix 28, Decay 40, Trail on. Off for the verse -- stays tight and direct. On for the hook/bridge -- adds air behind the lifted tone. On CTL.

## CTL Switch

- **CTL Off** = main verse strum. DST off, DLY off, RVB off -- dry, bright, clean.
- **CTL On** = lifted hook/bridge sound. DST on, DLY on, RVB on -- same clean base tone, boosted and given room to breathe.
- Modules on CTL: DST, DLY, RVB. All three flip together on the same footswitch press.
- Use CTL Off for the verses. Switch to CTL On for the recognizable ascending hook and any bridge/instrumental section.