

DATUM RISK ENGINEERING

Hot Work Permit

1. Work Details

Site / Location		Permit No.	
Date		Valid from / to (time)	

Work to be carried out

Type of hot work

☐ Welding ☐ Cutting ☐ Grinding ☐ Brazing / Soldering ☐ Other

2. Pre-Work Fire Precautions Checklist

- ☐ Alternative methods considered and ruled out (e.g. cold cutting, mechanical fixings) — hot work is confirmed as necessary
- ☐ Nature of surrounding construction assessed — combustible construction (e.g. timber, insulated panels with combustible cores) identified and additional precautions applied if present (see below)
- ☐ Area cleared of combustible materials within 10m (33ft) radius (or relocated / protected)
- ☐ Floor and wall openings, ducts, and conduits sealed against spark/slag transfer
- ☐ Fire extinguisher(s) appropriate to the risk present at the work location
- ☐ Fire watch assigned and briefed to maintain continuous watch for a minimum of 60 minutes after work stops, including throughout any breaks taken
- ☐ Sprinkler system confirmed in service — any impairment authorised and time-limited
- ☐ Gas cylinders (if used) secured upright, with flashback arrestors fitted
- ☐ Below/adjacent areas checked for combustible materials on the reverse side of the work surface
- ☐ Atmosphere tested if work is in a confined space or near flammable vapours

If combustible construction is present: move work away from the surface where possible; shield with fire-resistant covers if it cannot be moved; check the opposite side of the wall, floor, or ceiling for hidden combustibles or heat transfer risk; extend fire watch duration and coverage; treat insulated panels with combustible cores with particular caution.

3. Authorisation

Permit issued by (name / role)		Signature	
Permit accepted by (worker / role)		Signature	
Fire watch (name)		Signature	

4. Work Completion / Close-Out

Work completed (time)		Final area check completed by	
Fire watch end time		Signature	

Fire watch end time must reflect a minimum of 60 minutes after work stops, maintained continuously throughout — including during any breaks taken.

This sample form should be adapted to reflect site-specific fire protection arrangements, local regulatory requirements, and the relevant insurer or standard's hot work permit conditions (e.g. FM Global, LPC, or equivalent) before use. It does not constitute engineering or compliance advice.