01 Math Review

Engineering Statics, STCS 200

Updated on: August 11, 2025

Statics and Math

- Statics is all math! All but the most trivial statics problems require algebra and/or trigonometry and/or geometry to solve.
- ► The good news is that the math is not very difficult. You won't need anything more advanced than high-school math.
- We will do a quick review here that should cover all the math you'll need for STCS 200.

Trigonometry

Triangles are a strong, stable shape and often used in engineering.


Triangles help avoid issues like this:



Triangles mean we need trigonometry.


Right Triangle

A **right triangle** is a triangle having one 90° angle.



Right Triangle


A **right triangle** is a triangle having one 90° angle.



Label the three sides $a,\,b$ and c. The side a, opposite the right angle, is called the **hypotenuse**.


Right Triangle

A **right triangle** is a triangle having one 90° angle.



Label the three sides a, b and c. The side a, opposite the right angle, is called the **hypotenuse**.

If we know the lengths of any two sides, we can calculate the length of the third side using the **Pythagorean Theorem**:



Right Triangle Exercises

Significant digits and significant figures are the same thing.

- Significant digits and significant figures are the same thing.
- Significant digits are a measure of the accuracy of a number.

- Significant digits and significant figures are the same thing.
- Significant digits are a measure of the accuracy of a number.

It is **extremely important** to recognize that we can get no more accuracy out of a calculation than we put in. If the inputs to a problem have three significant digits, we cannot expect any higher accuracy than three significant digits in our result — even if the calculator does give ten digits.

Non-zero digits

Non-zero digits are significant:

- ▶ 1234 has 4 significant digits.
- ► 12.34 has 4 significant digits.

Non-zero digits

Non-zero digits are significant:

- ▶ 1234 has 4 significant digits.
- ► 12.34 has 4 significant digits.

Zeros between non-zero digits are significant

- ► 12034 has 5 significant digits.
- ▶ 12.0034 has 6 significant digits.

Leading zeros are **not** significant

- ▶ 0.1234 has 4 significant digits.
- ▶ 0.0001234 has 4 significant digits.

Leading zeros are not significant

- ▶ 0.1234 has 4 significant digits.
- ▶ 0.0001234 has 4 significant digits.

Trailing zeros (after a decimal point) are significant

- ► 1234.0 has 5 significant digits.
- ► 1.23400 has 6 significant digits.

Trailing zeros (on whole numbers, i.e. integers) are more **complicated**

- ▶ 12300 can have 3, 4 or 5 significant digits!
 - Consider 12.3 m. This value has 3 significant digits. It is equal to 12300 mm, so in this case the 12300 also has 3 significant digits.
 - Now consider 12.30 m. This value has 4 significant digits. But it is still equal to 12300 mm, so in this case the 12300 has 4 significant digits.
 - ▶ What if 12300 mm refers to 12.300 m? Then it has 5 significant digits.
- Usually, the trailing zeros are placeholders for the magnitude of a value and we don't need to worry unduly.
- ▶ If we want to emphasize that 12300 has 4 significant digits, we can write $1.230 \times (10^3)$.

Calculations for Exercises

▶ In practice, it is often difficult to measure objects more accurately than to three significant digits so input values for exercises are generally given to 3 significant digits. (Or sometimes 4 significant digits when the leading significant digit is a 1)

Calculations for Exercises

- ▶ In practice, it is often difficult to measure objects more accurately than to three significant digits so input values for exercises are generally given to 3 significant digits. (Or sometimes 4 significant digits when the leading significant digit is a 1)
- ▶ We cannot expect to get more accuracy in our result at the end of a calculation than from our given input values at the beginning of the calculation so solutions should be correct to 3 significant digits, not more than the accuracy of the calculation inputs!

Calculations for Exercises

- In practice, it is often difficult to measure objects more accurately than to three significant digits so input values for exercises are generally given to 3 significant digits. (Or sometimes 4 significant digits when the leading significant digit is a 1)
- ▶ We cannot expect to get more accuracy in our result at the end of a calculation than from our given input values at the beginning of the calculation so solutions should be correct to 3 significant digits, not more than the accuracy of the calculation inputs!
- Intermediate calculations will accumulate rounding errors quickly if we use only three significant digits and these can affect the final result. For intermediate calculations, use 5 or more significant digits.

(When I write solutions down, I use 5 significant digits for intermediate calculations. You may use more if it is more convenient for you, e.g., if you are storing intermediate results in your calculator.)

Significant Digits and Rounding

When using five significant digits for intermediate calculations, it is necessary to convert to three (or four) when providing the final answer to an exercise. Then, rounding is often involved:

Significant Digits and Rounding

- When using five significant digits for intermediate calculations, it is necessary to convert to three (or four) when providing the final answer to an exercise. Then, rounding is often involved:
 - ▶ 2.3456 becomes 2.35 because the first non-significant digit (the 5 in this case) is \geq 5 and so the 4 rounds up.
 - ▶ 2.3446 becomes 2.34 because the first non-significant digit (the 4 in this case) is < 5 and the last significant digit, 4, remains unchanged.
- ► When the first discarded digit is a 5 (or higher), round up the digit before the 5 (or higher)
- ► There are various rules (such as the odd-even rule) which take a more complicated approach to rounding 5 but, for our purposes, 5 rounds up!

Right Triangle Exercises