

Patch Bay 1	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
TOP	Tanzbar Out L	Sub 37 Out	Fuzz In	MXR Dist In	-					LA-2A In	UA 550 In	DBX 160 Link	SSL Fusion In L/R		API L/R In		Dbx 160A L/R In		D-Comp L/R In		902 De-esser IN 1-2		Art Comp In L/R		
BOTTOM	Tanzbar Out R	-	Fuzz Out	MXR Dist Out	-					LA-2A Out	UA 550 Out	DBX 160 Link	SSL Fusion Out L/R		API L/R Out		Dbx 160A L/R Out		D-Comp L/R Out		902 De-esser OUT 1-2		Art Comp Out L/R		
Patch Bay 2	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
TOP	Ghost Channel Insert Send 1-16																Group 1 - 8 Insert Send								
BOTTOM	Ghost Channel Insert Return 1-16																Group 1 - 8 Insert Return								
Patch Bay 3	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
TOP	Ghost Channel Insert Send 17-32																Aux 1 Out	Aux 2 Out	Aux 3 Out	Aux 4 Out	Aux 5 / 6 Out		Aux 7 Out L/R		
BOTTOM	Ghost Channel Insert Return 17-32																EMT 140 In	PCM60 In	SDE 1000 In	Moog DLY In	-		-		
Patch Bay 4	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
TOP	Worm hole 1-8 top								Worm hole 9-16 top								Aux 8 Out L/R		SDE 1000 Return	Moog DLY Out	-		Main Insert Send		
BOTTOM	Console Line In 1-8								Console Line In 9-16								-		-	-	-	-		Main Insert Return	
Patch Bay 5	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
TOP	Worm hole Matched to Left Side Patch bay 1-16 bottom																-								
BOTTOM	Console Line In 17-32																-								
Patch Bay 6	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
TOP	Apollo #1 1-16 Out																Mult L 17-24								
BOTTOM	Ghost 1-16 Tape In																Mult R 17-24								
Patch Bay 7	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
TOP	Apollo #2 17-32 Out																EMT 140 Return L/R		PCM60 Return L/R		-		-		
BOTTOM	Ghost 17-32 Tape In																FX 1 In L/R		FX 2 In L/R		FX 3 In L/R		FX 4 In L/R		

Patch Bay 8	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Ghost 1-16 Tape Send																Control Room Out L/R	Alt CRM Out L	Alt CRM Out R	Studio A O/P L/R		Studio Phones B L/R Out		
BOTTOM	Apollo #1 1-16 In																Yamaha Monitors In	Mix Cube In	-	Headamp Pro Input		Meyer Mains In L/R		

Patch Bay 9	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Ghost 17-32 Tape Send																Apollo 2 Track Out	Record Player Out		Ghost MIX O/P L/R		Ghost MIX B O/P L/R		
BOTTOM	Apollo #2 17-32 In																Ghost 2 Track A Input	Ghost 2 Track B Input		-		-		

Patch Bay 10	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Kitchen L	Bath Up L	Bath Dn L	Den L	Gallery L	Master Bed L	Guest Bed L	Office L	Front Porch	Basement Snake A, B, C, D				-			Group 1 - 8 Out							
BOTTOM	Kitchen R	Bath Up R	Bath Dn R	Den R	Gallery R	Master Bed R	Guest Bed R	Office R	Back Porch	Basement Snake E, F, G, H				-			Hearback In 1 - 8							

Patch Bay 11-amp/rack	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	L / R Audio Source Out	DBX High Out L/R		DBX Mid Out L/R		DBX Low Out L/R		-															
BOTTOM	DBX Drive Rack L/R IN	High Amp In L/R		Mid Amp In L/R		Low Amp In L/R		-															

Patch Bay ethernet	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
	Hearback Out 1-8							Kitchen	Bath Up	Bath Dn	Den	Gallery	Master Bed	Guest Bed	Record Player	Office	Office 2	-	

Patch Bay midi	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
	-																					

Patch Bay power-switched		2	3	4	5	6	7	8	9	10
	Monitors	-	API 2500	D-Comp	dbx 902	PCM 60	SDE 1000	dbx 160 #1	dbx 160 #2	Headamp

2026-09-20

☐ **Reorganized: Main Rack Patch Bays**

- Full re-layout of bays 1-10 (top of rack first). Console buckets stay 16 wide on the left; the right 8 ports are grouped by job.
- ☐ ****Bay 1:**** instruments & pedals (1-9, spares reserved for more), mono outboard, stereo outboard, Art Comp far right
- ☐ ****Bays 2-3:**** Ghost channel inserts, with group inserts and aux sends on the right
- ☐ ****Bays 4-9:**** worm hole → line in, Apollo ↔ Ghost tape, with Aux 8 / Moog / Main Insert, FX returns, monitoring and 2-track on the right
- ☐ ****Bay 10:**** room sends (L over R), basement snake, group outs → Hearback

☐ **Added**

- ☐ SSL Fusion (bay 1), Aux 4 normalled into the Moog delay, stereo sends to 10 rooms
- ☐ MIDI patch bay label (22 jacks) and power switch label (10 switches) - names still to fill in

☐ **Removed**

- ☐ Tascam TSR-8, Pro Verb, Transition Delay

☐ **Changed**

- ☐ 902 de-esser no longer normalled; Ghost Mix Out normalled
- ☐ Porch renamed to Deck on the ethernet bay

2026-03-08

☐ **Added: Ethernet Patch Bay**

- Added a new single-row ethernet patch bay label (20 ports).
- Ports 1-8: Hearback outputs
- ☐ Hearback Out 1-8 (grouped block)
- Ports 9-18: Room network drops
- ☐ Kitchen
- ☐ Bath Up
- ☐ Bath Dn
- ☐ Den
- ☐ Gallery
- ☐ Master Bed
- ☐ Guest Bed
- ☐ Office
- ☐ Front Porch
- ☐ Back Porch

☐ **Moved: Bay 10 Reorganized**

- Cleaned up Patch Bay 10 layout. Old placeholder entries removed and routing consolidated.
- Removed from Bay 10:
 - ☐ TBD (was port 1 top)
 - ☐ Office (was port 1 bottom)
 - ☐ Mast Bed (was port 2 top)
 - ☐ Bath Upper (was port 2 bottom)
 - ☐ Kitchen (was port 3 top)
 - ☐ TBD (was port 3 bottom)
- Moved within Bay 10:
 - ☐ Room inputs (Kitchen-Back Porch) moved to ports 1-10 (far left)
 - ☐ Moog DLY moved to port 14 (inside filler block, left of Sub 37)
 - ☐ Tanzbar OUT L/R moved to ports 15-16 (left of Sub 37)
 - ☐ Filler block consolidated to ports 11-16

2026-03-07

☐ **Added: Room Inputs to Patch Bay 10**

Added room microphone/line inputs into the existing Patch Bay 10, replacing the spare filler block.

Rooms (stereo — top row = L, bottom row = R):

- ☐ Kitchen
- ☐ Bathroom (up)
- ☐ Bathroom (down)
- ☐ Den
- ☐ Gallery
- ☐ Master Bed
- ☐ Guest Bed
- ☐ Office

Rooms (mono — single jack):

- ☐ Front Porch (port 9)
- ☐ Back Porch (port 10)

Ports 11-24 left spare for future expansion.

All connections non-normalled.

2026-03-07

☐ **Added: Printable Reference Sheet**

Added auto-generated 2-page 8.5×11" landscape PDF reference guide output to `printable\_reference/reference\_sheet`.

Features:

- ☐ All patch bays displayed in a grid layout
- ☐ Column numbers 1-24 on each bay header
- ☐ Diagonal hatching indicates normalled connections
- ☐ Normalled key in bottom-right corner