Studio Carquinez Patch Bay Reference (1/2)

Patch Bay 1	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Worm hole Matched to Left Side Patch bay 1-16 top																API L/R In		Dbx 160A L/R In		D-Comp L/R In		902 De-esser IN 1-2	
BOTTOM	Console Line In 1-16																API L/R Out		Dbx 160A L/R Out		D-Comp L/R Out		902 De-esser OUT 1-2	

Patch Bay 2	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Worm hole Matched to Left Side Patch bay 1-16 bottom																Aux 1 Out	Aux 2 Out	Aux 3 Out	Aux 4 Out	Aux 5 / 6 Out		Aux 7 Out	
BOTTOM	Console Line In 17-32																EMT 140 IN	PCM60 IN	-	-	Pro Verb Out		Pro Verb In	

Patch Bay 3	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Apollo #1 1-16 Out																Aux 8 Out L/R		Studio A O/P L/R		Studio Phones B L/R Out		PCM60 Return L/R	
BOTTOM	Ghost 1-16 Tape In																-		Headamp Pro Input		Meyer Mains In L/R		EMT 140 Return L/R	

Patch Bay 4	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Apollo #2 17-32 Out																Tascam TSR-8 In 1-8							
BOTTOM	Ghost 17-32 Tape In																Tascam TSR-8 Out 1-8							

Patch Bay 5	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Ghost 1-16 Tape Send																Control Room Out		Apollo 2 Track Out		-		-	
BOTTOM	Apollo #1 1-16 In																Yamaha Monitors In		Ghost 2 Track A Input		Ghost 2 Track B Input			

Patch Bay 6	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Ghost 17-32 Tape Send																-							
BOTTOM	Apollo #2 17-32 In																-							

= Normalled

Studio Carquinez Patch Bay Reference (2/2)

Patch Bay 7	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Ghost Channel Insert Send 1-16																Group 1 / 2 Out		Group 3 / 4 Out		Group 5 / 6 Out		Group 7 / 8 Out	
BOTTOM	Ghost Channel Insert Return 1-16																FX 1 In L / R		FX 2 In L / R		FX 3 In L / R		FX 4 In L / R	

Patch Bay 8	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Ghost Channel Insert Send 17-32																Group 1 - 8 Insert Send							
BOTTOM	Ghost Channel Insert Return 17-32																Group 1 - 8 Insert Return							

Patch Bay 9	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Main Insert Send		-														SDE 1000 Return	-	DBX 160 Link	Fuzz In	Transition Delay In		Hall of Fame Verb In	
BOTTOM	Main Insert Return		-														-	-	DBX 160 Link	Fuzz Out	Transition Delay Out		Hall of Fame Verb Out	

Patch Bay 10	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	-																							
BOTTOM	-																							

Patch Bay 11-amp rack	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	L / R Audio Source Out		DBX High Out L/R		DBX Mid Out L/R		DBX Low Out L/R		-															
BOTTOM	DBX Drive Rack L/R IN		High Amp In L/R		Mid Amp In L/R		Low Amp In L/R		-															

= Normalled