Studio Carquinez Patch Bay Reference (1/2)

Last updated: 2026-03-08

Patch Bay 1	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Worm hole Matched to Left Side Patch bay 1-16 top																API L/R In		Dbx 160A L/R In		D-Comp L/R In		902 De-esser IN 1-2	
BOTTOM	Console Line In 1-16																API L/R Out		Dbx 160A L/R Out		D-Comp L/R Out		902 De-esser OUT 1-2	

Patch Bay 2	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Worm hole Matched to Left Side Patch bay 1-16 bottom																Aux 1 Out	Aux 2 Out	Aux 3 Out	Aux 4 Out	Aux 5 / 6 Out		Aux 7 Out	
BOTTOM	Console Line In 17-32																EMT 140 IN	PCM60 IN	SDE 1000 IN	-	Pro Verb Out		Pro Verb In	

Patch Bay 3	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Apollo #1 1-16 Out																Aux 8 Out L/R		Studio A O/P L/R		Studio Phones B L/R Out		PCM60 Return L/R	
BOTTOM	Ghost 1-16 Tape In																-		Headamp Pro Input		Meyer Mains In L/R		EMT 140 Return L/R	

Patch Bay 4	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Apollo #2 17-32 Out																Tascam TSR-8 In 1-8							
BOTTOM	Ghost 17-32 Tape In																Tascam TSR-8 Out 1-8							

Patch Bay 5	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Ghost 1-16 Tape Send																Control Room Out		Apollo 2 Track Out		Record Player OUT		Ghost Mix OUT	
BOTTOM	Apollo #1 1-16 In																Yamaha Monitors In		Ghost 2 Track A Input		Ghost 2 Track B Input		-	

Patch Bay 6	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Ghost 17-32 Tape Send																Alt CRM Out L/R		Hearback IN 1, 2, 3, 4				-	LA-2A In
BOTTOM	Apollo #2 17-32 In																Mix Cube L / -		Hearback IN 5, 6, 7, 8				-	LA-2A Out

Normalled =

Studio Carquinez Patch Bay Reference (2/2)

Last updated: 2026-03-08

Patch Bay 7	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Ghost Channel Insert Send 1-16																Group 1 / 2 Out		Group 3 / 4 Out		Group 5 / 6 Out		Group 7 / 8 Out	
BOTTOM	Ghost Channel Insert Return 1-16																FX 1 In L / R		FX 2 In L / R		FX 3 In L / R		FX 4 In L / R	

Patch Bay 8	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Ghost Channel Insert Send 17-32																Group 1 - 8 Insert Send							
BOTTOM	Ghost Channel Insert Return 17-32																Group 1 - 8 Insert Return							

Patch Bay 9	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Main Insert Send		Basement Snake Send A, B, C, D				-										SDE 1000 Return	-	DBX 160 Link	Fuzz In	Transition Delay In		-	
BOTTOM	Main Insert Return		Basement Snake Send E, F, G, H				-										-	-	DBX 160 Link	Fuzz Out	Transition Delay Out		Phones Amp In L/R	

Patch Bay 10	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	Kitchen L	Bath Up L	Bath Dn L	Den L	Gallery L	Master Bed	Guest Bed L	Office L	Front Porch	Back Porch	-			Moog DLY IN	Tanzbar OUT L/R		-	MXR Dist IN	Art Comp IN L/R		UA 550 In		-	
BOTTOM	Kitchen R	Bath Up R	Bath Dn R	Den R	Gallery R	Master Bed	Guest Bed R	Office R	Front Porch	Back Porch	-			Moog DLY OUT	-		Sub 37 OUT	MXR Dist OUT	Art Comp OUT L/R		UA 550 Out		-	

Patch Bay 11	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
TOP	-amp rack	L / R Audio Source Out		DBX High Out L/R		DBX Mid Out L/R		DBX Low Out L/R	-															
BOTTOM		DBX Drive Rack L/R IN		High Amp In L/R		Mid Amp In L/R		Low Amp In L/R	-															

Patch Bay ethernet	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
	Hearback Out 1-8								Kitchen	Bath Up	Bath Dn	Den	Gallery	Master Bed	Guest Bed	Office	Front Porch	Back Porch	-	

Normalled =