

Pre-Trip Inspection Checklist – Two Car Haulers

*Instructions: Check each item as completed.
Follow steps in order.*

Step 1: Preparation – Pre-Trip Inspection

- ☐ 1. Clock Into UKG.
- ☐ 2. Log into My20 and Start HOS.
- ☐ 3. Select Your Truck Number.
- ☐ 4. Begin Pre-Trip in My20.
- ☐ 5. You Have Non-Slip Shoes.
- ☐ 6. You Have Towels.
- ☐ 7. You Have Work Gloves.
- ☐ 8. You Have Thread Depth Gauges.
- ☐ 9. You Have Tire Pressure Gauge.
- ☐ 10. Turn Truck's Light Switch On.
- ☐ 11. Hazard Lights On.
- ☐ 12. Truck's Key.
 - ☐ A) Removes keys from the ignition.
 - ☐ B) Keep truck key in your pocket.
- ☐ 13. Rear axle tires (drive wheels).
 - ☐ A) Shock Drive Wheels (both sides).

Step 2: Front Cab Inspection

- ☐ 1. Upper Marker Lights.
- ☐ 2. Windshield – No Cracks.
- ☐ 3. Rear View Mirrors – Conditions.
- ☐ 4. Wiper Blades – Conditions.
- ☐ 5. Turning Signals.

- ☐ 6. Head Lights (low/high beam).
- ☐ 7. Hood – Conditions.
- ☐ 8. Hood Hinges – Conditions.
- ☐ 9. Hood Latches – Conditions.
- ☐ 10. Front Grill – Condition.
- ☐ 11. Front Bumper – Secured.
- ☐ 12. No Leaks Under the Truck.
- ☐ 13. Suspension – Not Leaning.
- ☐ 14. Front Axle – Conditions.

Step 3: Engine Bay – Passenger Side

- ☐ 1. Open Engine Bay.
- ☐ 2. Windshield Wipers Mechanism.
- ☐ 3. Coolant Reservoir – Condition.
 - ☐ A) Reservoir Cap & Level.
 - ☐ B) Reservoir Hoses.
- ☐ 4. Heater Hoses.
- ☐ 5. Top Radiator Hose.
- ☐ 6. Radiator Top and Side – Condition.
- ☐ 7. Engine Fan – Condition.
- ☐ 8. Engine Fan Clutch – Conditions.
- ☐ 9. Radiator Shroud – Conditions.
- ☐ 10. Belt – Conditions.
- ☐ 11. Alternator – Secured.
 - ☐ A) Wiring Harnesses & Condition.
- ☐ 12. AC Compressor – Condition.
 - ☐ A) AC Connectors – Condition.
- ☐ 13. Belt Tensioner – Condition.
- ☐ 14. Water Pump – No Leaks.

- ☐ 15. Intercooler Tube (cool side).
 - ☐ A) Tube Condition.
 - ☐ B) Tube Clamps.
 - ☐ C) Boots Condition.
- ☐ 16. Engine Block – Condition.
- ☐ 17. Air Dryer – Conditions.
 - ☐ A) Air Dryer Hoses and Connectors.
- ☐ 18. Wipers Reservoir – Conditions.
 - ☐ A) Wipers Reservoir Fluid Levels.
- ☐ 19. Air Horn – Condition/Connection.
- ☐ 20. Frame Rail – Condition.
- ☐ 21. Shock Absorber – Condition.
- ☐ 22. Suspension Hangers – Condition.
- ☐ 23. Leaf Springs – Condition.
- ☐ 24. Bump Stop – Condition.
- ☐ 25. Suspension U-Bolt – Condition.
- ☐ 26. All Castle Nuts with Cotter Pin.
- ☐ 27. Brake Air Hose – No Leaks.
- ☐ 28. ABS Line – Condition.
- ☐ 29. Brake Chamber – Secured.
 - ☐ A) Brake Chamber – No Leaks.
- ☐ 30. Brake Slack Adjuster – Condition.
 - ☐ A) Travel Less Than 1 inch.
- ☐ 31. Brake Shoes – Condition.
- ☐ 32. Wheel Rim Inside – No Cracks.
- ☐ 33. Tire Inside Wall – Condition.
- ☐ 34. Tire – Passenger Side.
 - ☐ A) Inside Wall Condition.
 - ☐ B) No Penetrating Object.

- ☐ C) No Cuts, Bulges or Tears.
- ☐ D) Tire Tread Depth $\geq 4/32$ ".
- ☐ E) Outside Wall Condition.
- ☐ 35. Wheel.
 - ☐ A) Outside Wheel – No Cracks.
 - ☐ B) No Missing Wheel Lug Stud.
 - ☐ C) No Missing Lug Nuts.
 - ☐ D) Lug Nuts – No Rust Trails.
 - ☐ E) Lug Nuts – Secured Tightly.
- ☐ 36. Tire Pressure – Use a Pressure Gauge.
 - ☐ Pressure at Manufacturer Recommended Level.
- ☐ 37. Wheel Hub – Oil Level and Seal.

Step 4: Engine Bay – Driver Side

- ☐ 1. Windshield Wipers Motor.
 - ☐ A) Wipers Linkages.
- ☐ 2. Air Hoses Connected to the E-10 Brake Valve (Two Orange, Two Green) Attached to the Truck's Firewall.
 - ☐ A) No Leaks, Good Condition.
- ☐ 3. Wire Harnesses and Connector.
 - ☐ A) Good Condition.
 - ☐ B) Securely Connected.
- ☐ 4. Air Filter – Condition.
 - ☐ A) Green Light Indicator On.
- ☐ 5. Intercooler Tube (hot side).
 - ☐ A) Tube Condition.
 - ☐ B) Clamp Conditions.
 - ☐ C) Boots Conditions.

- ☐ 6. Radiator Top and Driver Side.
 - ☐ A) No Cracks or Leaks.
- ☐ 7. Power Steering.
 - ☐ A) Reservoir – No Leaks.
 - ☐ B) Fluid Level.
 - ☐ C) Power Steering Hoses.
- ☐ 8. Engine Block – Conditions.
- ☐ 9. Engine Oil Level.
- ☐ 10. Transmission Fluid Level.
- ☐ 11. Steering Shaft.
 - ☐ A) U-Joints Condition.
 - ☐ B) Free Play Amount.
- ☐ 12. Fuel Filter – No Leaks.
- ☐ 13. Fuel Water Separator.
 - ☐ A) Separator – Not Leaking.
 - ☐ B) Separator Hoses.
- ☐ 14. Frame Rail – Condition.
- ☐ 15. Shock Absorber – Condition.
- ☐ 16. Suspension Hangers – Condition.
- ☐ 17. Leaf Springs – Condition.
- ☐ 18. Bump Stop – Condition.
- ☐ 19. Suspension U-Bolt – Condition.
- ☐ 20. Steering Gearbox – Condition.
- ☐ 21. Pitman Arm – Condition.
- ☐ 22. Drag Link – Condition.
- ☐ 23. Tie Rods – Condition.
- ☐ 24. Knuckle Arm – Condition.
- ☐ 25. Castle Nuts.
 - ☐ A) Secured with Cotter Pin.
- ☐ 26. Brake Air Hose to Brake Chamber.
 - ☐ A) Good Condition – No Leaks.
- ☐ 27. ABS Line – Condition.
- ☐ 28. Brake Chamber – No Leaks.
- ☐ 29. Brake Slack Adjuster.
 - ☐ A) Travel Less Than 1 inch.
- ☐ 30. Brake Shoes – Condition.
- ☐ 31. Wheel Inside – No Cracks.
- ☐ 32. Tire – Driver Side.
 - ☐ A) Inside Wall Condition.
 - ☐ B) No Penetrating Object.
 - ☐ C) No Cuts, Bulges or Tears.
 - ☐ D) Tire Tread Depth $\geq 4/32$ ".
 - ☐ E) Outside Wall Condition.
- ☐ 38. Wheel.
 - ☐ A) Outside Wheel – No Cracks.
 - ☐ B) No Missing Wheel Lug Stud.
 - ☐ C) No Missing Lug Nuts.
 - ☐ D) Lug Nuts – No Rust Trails.
 - ☐ E) Lug Nuts – Secured Tightly.
- ☐ 33. Tire Pressure – Use a Pressure Gauge.
 - ☐ Pressure at Manufacturer Recommended Level.
- ☐ 34. Wheel Hub – Oil Level and Seal.

Step 5: Cab Interior – Paperwork

- ☐ 1. Driver's License.
- ☐ 2. Medical Card.
- ☐ 3. ELD.
 - ☐ A) Electronic Logging Device.
- ☐ 4. Bill Of Lading.
- ☐ 5. Lease Agreement.
- ☐ 6. Truck Insurance.
- ☐ 7. Truck Registration.
- ☐ 8. Truck Inspection.
- ☐ 9. ELD Manual.
- ☐ 10. ELD Quick Guide.
- ☐ 11. ELD Malfunction Form.
- ☐ 12. Accident Kit.
- ☐ 13. Pre/Post Trip DVIR Guide.
- ☐ 14. Paper Logbook.
- ☐ 15. Store Planograms.

Step 6: Cab Exterior – Driver's Side

- ☐ 1. Driver's Door.
 - ☐ A) Door – No Exterior Damage.
 - ☐ B) Window Glass – Clean.
 - ☐ C) Window Glass – Not Broken.
 - ☐ D) Mirror – Not Broken & Clean.
 - ☐ E) Mirror Support Frame.
 - ☐ F) Camera – Securely Mounted.
 - ☐ G) CarMax Decal – Clearly Visible.
 - ☐ H) DOT# Decal – Not Faded.
 - ☐ I) ELD Decal – Visible/Not Faded.

- ☐ J) Camera Recording Decal – Visible.
- ☐ K) Truck Annual Inspection Decal.
- ☐ L) Truck Number Decal.
- ☐ M) Door Lock, Handle and Hinges.
- ☐ N) Grab Bar – Securely Mounted.
- ☐ O) Interior Door Panel – Undamaged.
- ☐ P) Interior Door Handle.
- ☐ Q) Lock and Window Controls.
- ☐ R) Door Interior Seal – In Place.
- ☐ 2. Driver Side Fender.
 - ☐ A) Secured and Undamaged.
 - ☐ B) Hood Latches – Secured.
- ☐ 3. DEF Tank – Condition.
 - ☐ A) No Leaks.
 - ☐ B) Cap and Seal – Present.
 - ☐ C) Tank Bracket/Straps – Secured.
 - ☐ D) Electrical Connections.
- ☐ 4. Fuel Tank – Conditions.
 - ☐ A) Tank Wiring – Connected.
 - ☐ B) Tank Vent Tube – Condition.
 - ☐ C) Tank Cap, Chain & Seal.
 - ☐ D) Tank Bracket/Straps.
 - ☐ E) Cab Access Steps – Condition.
 - ☐ F) Diesel Tank – Not Leaking.

Step 7: Bed Inspection – Driver’s Side

- ☐ 1. Bed Front Marker Light – Functional.
- ☐ 2. Bed Side Marker Light – Proper Color.
- ☐ 3. Upper Deck.

- ☐ A) No Slip Hazards or Debris.
- ☐ B) No Damages to Deck Plates.
- ☐ C) No Cracks to Deck Plates.
- ☐ D) Ratchets and Straps – Condition.
- ☐ E) Grab Pole – Secured.
- ☐ F) Grab Pole – Not Damaged or Bent.

- ☐ 4. Lower Deck.

- ☐ A) No Slip Hazards or Debris.
- ☐ B) No Damages to Deck Plates.
- ☐ C) No Cracks to Deck Plates.
- ☐ D) Ratchets and Straps – Condition.
- ☐ E) Hydraulic Cylinder – Not Leaking.
- ☐ F) Hydraulic Hose – Not Leaking.

- ☐ 5. Side Skirt (side metal panel).

- ☐ A) Undamaged.
- ☐ B) Securely Mounted.

- ☐ 6. Bed Ladder/Steps.

- ☐ A) No Slip Hazard.
- ☐ B) Safe and Secured.

- ☐ 7. Bed Front Ladder and Steps Openings.

Use these openings to visually inspect the following components when visible:

- ☐ A) Frame/Chassis – Condition.
- ☐ B) Frame Deck Attachments.
- ☐ C) Driveshaft Tube – Condition.

- ☐ D) Driveshaft U-Joints.
- ☐ E) Driveshaft Slip Yoke.
- ☐ F) Driveshaft Center Bearing.
- ☐ G) Differential – Not Leaking.
- ☐ H) Visual Parts of Rear Axle.
- ☐ I) Rear Brake Chamber.
- ☐ J) Rear Brakes Air Hoses.
- ☐ K) Inside Tire – Condition.

- ☐ 8. Bed Turning Signal and Reflector.

- ☐ 9. Toolbox.

- ☐ A) Door – Open and Close.
- ☐ B) Hinges and Handle – Functional.
- ☐ C) Spare Straps.
- ☐ D) Spill Kit.
- ☐ E) Wheel Chocks. (Note: Original said “Wheel Shocks” – corrected to industry term)
- ☐ F) Securely Locks.

- ☐ 10. Rear Axle.

WARNING: DO NOT PLACE YOUR HANDS ON TOP OF THE TIRES BETWEEN THE TIRES AND THE DECK.

Use the opening around the rear wheel well to inspect the following:

- ☐ A) Visible Parts of the Chassis.
- ☐ B) Suspension Hangers.
- ☐ C) Leaf Springs.
- ☐ D) Tire Inside Wall – Condition.
- ☐ E) Tires – No Penetrating Object.
- ☐ F) Tires – No Cuts, No Bulges.
- ☐ G) Tires – No Tears.

- ☐ H) Tire – Tread Depth $\geq 2/32$ ".
- ☐ I) Tires – Outside Wall.
- ☐ J) Wheel – No Cracks/Welds.
- ☐ K) Lug Nuts/Stud – Not Missing.
- ☐ L) Lug Nuts – Secured Tightly.
- ☐ M) Lug Nuts – No Rust Trails.
- ☐ N) Rear Axle Shaft to Hub Bolts.
- ☐ O) No Leak – Axle Shaft to Hub.
- ☐ 11. Tire Pressure.
 - ☐ A) Use Pressure Gauge.
 - ☐ B) Manufacturer Recommended.
- ☐ 12. Air Bag – Condition.
- ☐ 13. Rear End of Chassis.
- ☐ 14. Bed Rear Ladder/Steps Openings.
 - ☐ A) Through these openings, inspect the rear underside ensuring there is no damage.
- ☐ 15. Rear Marker Light and Reflector.

Step 8: Bed Inspection – Rear Side

- ☐ 1. Taillights.
 - ☐ A) Right Color and Functional.
 - ☐ B) Rear Marker Lights.
 - ☐ C) Reflectors – Right Color.
 - ☐ D) DOT Tape – Condition.
- ☐ 2. License Plate.
 - ☐ A) Undamaged and Secured.
 - ☐ B) Light – Right Color, Functional.
- ☐ 3. Deck Plates.
 - ☐ A) No Damage.

- ☐ B) Clear of Debris and Secured.
- ☐ 4. Frame – No Damage.
- ☐ 5. Ramp – Functional, No Damage.
- ☐ 6. Ramp Hydraulic Piston.

WARNING: DO NOT STEP ON PISTON.

- ☐ A) No Leaks and Functional.
- ☐ 7. Fold Out Ramps – Functional.
- ☐ 8. Loading Ramps Hydraulic.
- ☐ 9. Rear Axle.
 - LOOK UNDERNEATH THE DECK PLATE:
 - ☐ A) Inspect the Rear Axle.
 - ☐ B) Inspect the Deck Frame.
- ☐ 10. Rear of Cab – Undamaged Glass.

Step 9: Bed Inspection – Passenger Side

- ☐ 1. Rear Marker Light and Reflector.
- ☐ 2. Bed Rear Ladder/Steps Openings.
 - ☐ A) Through these openings, inspect the rear underside ensuring there is no damage.
- ☐ 3. Rear Axle.

WARNING: DO NOT PLACE YOUR HANDS ON TOP OF THE TIRES BETWEEN THE TIRES AND THE DECK.

Use the opening around the rear wheel well to inspect the following:

- ☐ A) Rear End of Chassis.
- ☐ B) Air Bag – Condition.
- ☐ C) Air Bag – Condition.
- ☐ D) Visible Parts of the Chassis.
- ☐ E) Suspension Hangers.

- ☐ F) Leaf Springs.
- ☐ G) Tire Inside Wall – Condition.
- ☐ H) Tires – No Penetrating Object.
- ☐ I) Tires – No Cuts, No Bulges.
- ☐ J) Tires – No Tears.
- ☐ K) Tire – Tread Depth $\geq 2/32$ ".
- ☐ L) Tires – Outside Wall.
- ☐ M) Wheel – No Cracks/Welds.
- ☐ N) Lug Nuts/Stud – Not Missing.
- ☐ O) Lug Nuts – Secured Tightly.
- ☐ P) Lug Nuts – No Rust Trails.
- ☐ Q) Rear Axle Shaft to Hub Bolts.
- ☐ R) No Leak – Axle Shaft to Hub.
- ☐ 4. Tire Pressure.
 - ☐ A) Use Pressure Gauge.
 - ☐ B) Manufacturer Recommended.
- ☐ 5. Hydraulic Tank.
 - ☐ A) Cap – Securely Locks.
 - ☐ B) Cap Seal – In Good Condition.
- ☐ 6. Hydraulic Control Valve – Undamaged.
- ☐ 7. Bed Front Ladder/Steps.
 - ☐ A) No Slip Hazard.
 - ☐ B) Safe and Secured.
 - ☐ C) Bed Turning Signal – Functional.
 - ☐ D) Bed Side Reflector – Proper Color.
- ☐ 8. Bed Front Ladder and Steps Openings.

Use these openings to visually inspect the following components when visible:

- ☐ A) Frame/Chassis – Condition.

- ☐ B) Frame Deck Attachments.
- ☐ C) Driveshaft Tube – Condition.
- ☐ D) Driveshaft U-Joints.
- ☐ E) Driveshaft Slip Yoke.
- ☐ F) Driveshaft Center Bearing.
- ☐ G) Differential – Not Leaking.
- ☐ H) Visual Parts of Rear Axle.
- ☐ I) Rear Brake Chamber.
- ☐ J) Rear Brakes Air Hoses.
- ☐ K) Hydraulics Tank – Condition.
- ☐ L) Hydraulics Filters and Hoses.
- ☐ 9. Lower Deck.
 - ☐ A) No Slip Hazards or Debris.
 - ☐ B) No Damages to Deck Plates.
 - ☐ C) No Cracks to Deck Plates.
 - ☐ D) Ratchets and Straps – Condition.
 - ☐ E) Hydraulic Cylinder – Not Leaking.
 - ☐ F) Hydraulic Hose – Not Leaking.
- ☐ 10. Grab Pole – Secure, Undamaged/Bent.
- ☐ 11. Upper Deck.
 - ☐ A) No Slip Hazards or Debris.
 - ☐ B) No Damages to Deck Plates.
 - ☐ C) No Cracks to Deck Plates.
 - ☐ D) Ratchets and Straps – Condition.
 - ☐ E) Grab Pole – Secured.
 - ☐ F) Grab Pole – Not Damaged or Bent.
- ☐ 12. Side Skirt (side metal panel).
 - ☐ A) Undamaged.
 - ☐ B) Securely Mounted.

- ☐ 13. Bed Front Side Marker Light.
- ☐ 14. Bed Front Marker Light – Functional.

Step 10: Cab – Passenger Side

- ☐ 1. Passenger Door.
 - ☐ A) Door – No Exterior Damage.
 - ☐ B) Window Glass – Clean.
 - ☐ C) Window Glass – Not Broken.
 - ☐ D) Mirror – Not Broken & Clean.
 - ☐ E) Mirror Support Frame.
 - ☐ F) Camera – Securely Mounted.
 - ☐ G) CarMax Decal – Clearly Visible.
 - ☐ H) DOT# Decal – Not Faded.
 - ☐ I) ELD Decal – Visible/Not Faded.
 - ☐ J) Camera Recording Decal – Visible.
 - ☐ K) Truck Annual Inspection Decal.
 - ☐ L) Truck Number Decal.
 - ☐ M) Door Lock, Handle and Hinges.
 - ☐ N) Grab Bar – Securely Mounted.
 - ☐ O) Interior Door Panel – Undamaged.
 - ☐ P) Interior Door Handle.
 - ☐ Q) Lock and Window Controls.
 - ☐ R) Interior Seal – In Place.
 - ☐ S) Cab Access Steps – Condition.
- ☐ 2. Battery Box.
 - ☐ A) Open Battery Box.
 - ☐ B) Batteries – Secured.
 - ☐ C) Battery Hold-Down Clamp.
 - ☐ D) Cables – Not Frayed or Exposed.

- ☐ E) Cable Terminals – No Corrosion.
- ☐ F) Cables – Not Burned/Overheating.
- ☐ G) Cables – In Good Condition.
- ☐ H) Cables – Properly Connected.

- ☐ 3. Driver Side Fender.
 - ☐ C) Secured and Undamaged.
 - ☐ D) Hood Latches – Secured.
- ☐ 4. Air Tanks.
 - ☐ A) No Air Leaks.
 - ☐ B) Condition of All Air Hoses.
 - ☐ C) Open Valves and Drain Air Tanks.
 - ☐ D) Close Air Tank Valve.

Step 11: Inside Cab – Driver Side

Start inspection on the driver's side.

- ☐ 1. Fire Extinguisher.
 - ☐ A) Securely Mounted.
 - ☐ B) Properly Rated.
 - ☐ C) Fully Charged.
 - ☐ D) Locking Pin – In Place.
- ☐ 2. Three Reflective Traffic Triangles.
- ☐ 3. Truck Paperwork Binder – Present.
- ☐ 4. Height Stick.
- ☐ 5. Seats – Securely Mounted.
- ☐ 6. Seat Belts & Buckles – Functional.
- ☐ 7. Start Truck.
- ☐ 8. Driver Side Rear Mirror – Adjusted.
- ☐ 9. Driver Window – Clean & Undamaged.
- ☐ 10. Window/Lock Button – Functional.

- ☐ 11. Cab – Clean, No Loose Items.
- ☐ 12. Wipers – Functioning with Fluids.
- ☐ 13. Steering Wheel – Securely Mounted.
- ☐ 14. Instrument Cluster.
 - ☐ A) All Gauges – Functioning.
 - ☐ B) No Warning/Check Engine Light.
- ☐ 15. Horn – Highway/City – Functional.
- ☐ 16. Hazard Signals – Functional.
- ☐ 17. Turn Signal Switch – Functional.
- ☐ 18. High/Low Beam – Functional.
- ☐ 19. Defroster – Functional.
- ☐ 20. Heat/AC – Functional.
- ☐ 21. Airbags Dump – Functional.
- ☐ 22. Power Take Off (PTO) – Functional.
- ☐ 23. Radio – Functional.
- ☐ 24. Windshield Glass – Functional.
- ☐ 25. ELD – Properly Secured & Visible.
- ☐ 26. Shifter – Functional.
- ☐ 27. Parking Brake Air Valve – Functional.
- ☐ 28. Passenger Window – Clean.
 - ☐ A) Passenger Window – Undamaged.
- ☐ 29. Spare Fuses – Readily Available.
 - ☐ A) Three Spare Fuses for Each Type of Amperage Rating Used by the Truck.

Step 12: Air Brake Test

- ☐ 1. Verify Wheels Are Chocked.
- ☐ 2. Parking Brake Valve – Popped Out.
- ☐ 3. Turn Engine On.

- ☐ 4. Air Compressor Test.
 - ☐ A) Allow Air Pressure Build to Governor Cut-Off (125 psi).
 - ☐ B) Turn Engine Off, Ignition On.
 - ☐ C) Release Parking Brake (push in).
 - ☐ D) Do Not Press Brake Pedal.
 - ☐ E) Start a Timer.
 - ☐ F) Air Loss for a Single Unit: Less Than 2 psi in 1 Minute.
 - ☐ G) Turn Engine On, Let PSI Build to Governor Cut-Off.
 - ☐ H) Turn Engine Off, Ignition On.
 - ☐ I) Press and Hold Pedal 1 Minute.
 - ☐ J) Air Loss for a Single Unit: Less Than 3 psi in 1 Minute.

Over 3 psi air loss is unacceptable.
Check for air leaks before driving.
- ☐ 5. Low Air Alarm Test.
 - ☐ A) Pump Brake Pedal until You Hear the Low Air Alarm (≈55 psi).
 - ☐ B) Continue Pumping until You See Red Warning Light Under the Air Tank Gauges.
 - ☐ C) Continue Pumping until Brake Air Valve (yellow valve) Pops Out.

Air Pressure Buildup Rate

- ☐ 1. Turn Engine On.
- ☐ 2. Start Timer When PSI Reaches 85.
- ☐ 3. Pressure Builds from 85 to 100 psi in 45 Seconds.
- ☐ 4. Air Compressor Governor Cut-Off at 125 psi.
- ☐ 5. Remove Wheel Chocks.

Parking Brake Test

Ensures parking brakes will hold, including during catastrophic air loss.

- ☐ 1. Parking Brake – On.
- ☐ 2. Gently Pull Against It.

Service Brakes Test

- ☐ 1. Release Parking Brake.
- ☐ 2. Drive Forward ($\approx$ 5 mph).
- ☐ 3. Press Brakes.