Launch Control XL 3 — Disco-Bläser 3 (lab/blaeser, 009 Jonas 5–7: liked figures + groovier ones, complexity, solo ↔ ensemble, lift)

Kept from round 2: push, 3-3-2, swell + fall, shout. New: double push, 3-3-2 over two bars, hits on the "a", swell into a push.

Row 3 = complexity (more groove notes). Button 1 = solo ↔ ensemble. Button 2 held = organic lift.

Knob | Fader | Button | unused

Mode 16 — Candidates

	1 Push	2 3-3-2 + answer	3 Shout	4 Swell + fall	5 Double push	6 3-3-2 long	7 On the a	8 Swell + push
Row 1 Brightness	CC 13 **Brightness** dull ↔ bright (low-pass 0.9–8 kHz).	CC 14 **Brightness** as 1 Push	CC 15 **Brightness** as 1 Push	CC 16 **Brightness** as 1 Push	CC 17 **Brightness** as 1 Push	CC 18 **Brightness** as 1 Push	CC 19 **Brightness** as 1 Push	CC 20 **Brightness** as 1 Push
Row 2 Space	CC 21 **Space** room at 0 ↔ hall and dotted-8th echo.	CC 22 **Space** as 1 Push	CC 23 **Space** as 1 Push	CC 24 **Space** as 1 Push	CC 25 **Space** as 1 Push	CC 26 **Space** as 1 Push	CC 27 **Space** as 1 Push	CC 28 **Space** as 1 Push
Row 3 Complexity	CC 29 **Complexity** core figure → + pickups and answers → + small extra hits.	CC 30 **Complexity** as 1 Push	CC 31 **Complexity** as 1 Push	CC 32 **Complexity** as 1 Push	CC 33 **Complexity** as 1 Push	CC 34 **Complexity** as 1 Push	CC 35 **Complexity** as 1 Push	CC 36 **Complexity** as 1 Push
Fader Level	CC 5 **Level** 0 = off.	CC 6 **Level** as 1 Push	CC 7 **Level** as 1 Push	CC 8 **Level** as 1 Push	CC 9 **Level** as 1 Push	CC 10 **Level** as 1 Push	CC 11 **Level** as 1 Push	CC 12 **Level** as 1 Push
Button 1 Solo / ensemble	CC 37 **Solo / ensemble** one trumpet ↔ the full section, from the next bar.	CC 38 **Solo / ensemble** as 1 Push	CC 39 **Solo / ensemble** as 1 Push	CC 40 **Solo / ensemble** as 1 Push	CC 41 **Solo / ensemble** as 1 Push	CC 42 **Solo / ensemble** as 1 Push	CC 43 **Solo / ensemble** as 1 Push	CC 44 **Solo / ensemble** as 1 Push
Button 2 Lift (held)	CC 45 **Lift** held: the section grows over 2 bars (voices, brightness, +3 dB); back over 1 bar after.	CC 46 **Lift** as 1 Push	CC 47 **Lift** as 1 Push	CC 48 **Lift** as 1 Push	CC 49 **Lift** as 1 Push	CC 50 **Lift** as 1 Push	CC 51 **Lift** as 1 Push	CC 52 **Lift** as 1 Push

Mode 2 — Context

	1	2	3	4	5 Progression	6 Drums	7 Bass	8 Keys
Row 1	CC 61 —	CC 62 —	CC 63 —	CC 64 —	CC 65 —	CC 66 **Swing** 50 % straight ↔ 70 %; 55–58 % = house.	CC 67 —	CC 68 —
Row 2	CC 69 —	CC 70 —	CC 71 —	CC 72 —	CC 73 —	CC 74 —	CC 75 —	CC 76 —
Row 3	CC 77 —	CC 78 —	CC 79 —	CC 80 —	CC 81 —	CC 82 —	CC 83 —	CC 84 —
Fader Level	CC 53 —	CC 54 —	CC 55 —	CC 56 —	CC 57 —	CC 58 **Drums** 909 kick, off-beat hat, clap, shaker.	CC 59 **Bass** off-beat bass on the chord root.	CC 60 **Keys** the keys of 009, following the progression.
Buttons 1	CC 85 —	CC 86 —	CC 87 —	CC 88 —	CC 89 **Next** next progression (all 21), at the next 8-bar phrase.	CC 90 —	CC 91 —	CC 92 —
Buttons 2	CC 93 —	CC 94 —	CC 95 —	CC 96 —	CC 97 **Previous** previous progression, at the next 8-bar phrase.	CC 98 **Drums out** everything but the drums while held.	CC 99 —	CC 100 —

Guide

What to listen for

Which figures groove? Does row 3 add groove without getting busy? Is the lift organic?

Live

Ensemble, row 3 low; hold button 2 for the big moments.