Launch Control XL 3 — Acid 2 (lab/acid, 009 Jonas 6: tamer acid — swing acid and squelch stabs, softer 303 voice)

One softer 303 voice everywhere (no drive, 12 dB low-pass, less envelope and resonance); columns differ only in the line.

Columns: 1 swing acid, 2 squelch stabs, 3 swing acid an octave down, 4 swing acid with an 8-bar filter build.

Knob Fader Button unused

Mode 16 — Candidates

	1 Swing acid	2 Squelch stabs	3 Swing, low	4 Build (8 bars)	5	6	7	8
Row 1 Cutoff	CC 13 **Cutoff** closed and dark ↔ open (low-pass 150–1800 Hz; column 4 opens by itself on top of it).	CC 14 **Cutoff** as 1 Swing acid	CC 15 **Cutoff** as 1 Swing acid	CC 16 **Cutoff** as 1 Swing acid	CC 17 —	CC 18 —	CC 19 —	CC 20 —
Row 2 Space	CC 21 **Space** dry ↔ a 1/8 echo, then room.	CC 22 **Space** as 1 Swing acid	CC 23 **Space** as 1 Swing acid	CC 24 **Space** as 1 Swing acid	CC 25 —	CC 26 —	CC 27 —	CC 28 —
Row 3 Acid	CC 29 **Acid** round pluck ↔ gentle squelch: envelope 0.5–2.5 octaves, resonance 2–9, decay 0.1–0.25 s.	CC 30 **Acid** as 1 Swing acid	CC 31 **Acid** as 1 Swing acid	CC 32 **Acid** as 1 Swing acid	CC 33 —	CC 34 —	CC 35 —	CC 36 —
Fader Level	CC 5 **Level** 0 = off.	CC 6 **Level** as 1 Swing acid	CC 7 **Level** as 1 Swing acid	CC 8 **Level** as 1 Swing acid	CC 9 —	CC 10 —	CC 11 —	CC 12 —
Button 1 Line	CC 37 **Line** three lines per column (1–2 bars).	CC 38 **Line** as 1 Swing acid	CC 39 **Line** as 1 Swing acid	CC 40 **Line** as 1 Swing acid	CC 41 —	CC 42 —	CC 43 —	CC 44 —
Button 2 Echo throw	CC 45 **Echo throw** held: long dotted-8th echo.	CC 46 **Echo throw** as 1 Swing acid	CC 47 **Echo throw** as 1 Swing acid	CC 48 **Echo throw** as 1 Swing acid	CC 49 —	CC 50 —	CC 51 —	CC 52 —

Mode 2 — Context

	1	2	3	4	5 Progression	6 Drums	7 Bass	8 Keys
Row 1	CC 61 —	CC 62 —	CC 63 —	CC 64 —	CC 65 —	CC 66 **Swing** 50 % straight ↔ 70 %; 55–58 % = house.	CC 67 —	CC 68 —
Row 2	CC 69 —	CC 70 —	CC 71 —	CC 72 —	CC 73 —	CC 74 —	CC 75 —	CC 76 —
Row 3	CC 77 —	CC 78 —	CC 79 —	CC 80 —	CC 81 —	CC 82 —	CC 83 —	CC 84 —
Fader Level	CC 53 —	CC 54 —	CC 55 —	CC 56 —	CC 57 —	CC 58 **Drums** 909 kick, off-beat hat, clap, shaker.	CC 59 **Bass** off-beat bass on the chord root.	CC 60 **Keys** the keys of 009, following the progression.
Buttons 1	CC 85 —	CC 86 —	CC 87 —	CC 88 —	CC 89 **Next** next progression (all 21), at the next 8-bar phrase.	CC 90 —	CC 91 —	CC 92 —
Buttons 2	CC 93 —	CC 94 —	CC 95 —	CC 96 —	CC 97 **Previous** previous progression, at the next 8-bar phrase.	CC 98 **Drums out** everything but the drums while held.	CC 99 —	CC 100 —

Guide

What to listen for

Still acid, but friendly enough for happy house? How far up can row 3 go?

Live

Ride Brightness and row 3 slowly. Button 2 = echo throw.