# Launch Control XL 3 — Midori 5 (lab/harmonie, 007: Eno bowed + marimba + toms)

The three new Jonas columns for 007, in D lydian over 007's context (Mode 2). Button 1 steps through the figures (plain → wild per family).

Knob | Fader | Button | unused

## Mode 16 — Candidates

| | 1 Eno Bowed | 2 Marimba | 3 Toms | 4 | 5 | 6 | 7 | 8 |
|---|---|---|---|---|---|---|---|---|
| **Row 1 Brightness** | CC 13<br>**Brightness**<br>soft ↔ bright (low-pass). | CC 14<br>**Brightness**<br>as 1 Eno Bowed | CC 15<br>**Brightness**<br>as 1 Eno Bowed | CC 16<br>— | CC 17<br>— | CC 18<br>— | CC 19<br>— | CC 20<br>— |
| **Row 2 Space** | CC 21<br>**Space**<br>room and dotted-8th echo (a little at 0). | CC 22<br>**Space**<br>as 1 Eno Bowed | CC 23<br>**Space**<br>as 1 Eno Bowed | CC 24<br>— | CC 25<br>— | CC 26<br>— | CC 27<br>— | CC 28<br>— |
| **Row 3 Character** | CC 29<br>**Complexity**<br>2 loops ↔ 6 loops drifting against each other. | CC 30<br>**Complexity**<br>0 = one figure ↔ all layers (Euclid: also denser; build-up: up to 7, louder and brighter). | CC 31<br>**Complexity**<br>0 = the figure alone ↔ fuller: rests fill up, canon voices, a drifting copy. | CC 32<br>— | CC 33<br>— | CC 34<br>— | CC 35<br>— | CC 36<br>— |
| **Fader Level** | CC 5<br>**Level**<br>0 = off. | CC 6<br>**Level**<br>as 1 Eno Bowed | CC 7<br>**Level**<br>as 1 Eno Bowed | CC 8<br>— | CC 9<br>— | CC 10<br>— | CC 11<br>— | CC 12<br>— |
| **Button 1 Change** | CC 37<br>**Change**<br>note set: calm (fifths) → lydian (G♯, C♯) → low and slower. | CC 38<br>**Change**<br>cycles → canon → cells → Euclid → build-up. | CC 39<br>**Change**<br>cycles → canon → Euclid → build-up → crossing → Clapping. | CC 40<br>— | CC 41<br>— | CC 42<br>— | CC 43<br>— | CC 44<br>— |
| **Button 2 Moment** | CC 45<br>**Echo throw**<br>held: long dotted-8th echo. | CC 46<br>**Echo throw**<br>as 1 Eno Bowed | CC 47<br>**Echo throw**<br>as 1 Eno Bowed | CC 48<br>— | CC 49<br>— | CC 50<br>— | CC 51<br>— | CC 52<br>— |

## Mode 2 — Context

| | 1 | 2 | 3 | 4 | 5 Progression | 6 Heartbeat | 7 Drone | 8 Pad |
|---|---|---|---|---|---|---|---|---|
| **Row 1** | CC 61<br>— | CC 62<br>— | CC 63<br>— | CC 64<br>— | CC 65<br>— | CC 66<br>— | CC 67<br>— | CC 68<br>— |
| **Row 2** | CC 69<br>— | CC 70<br>— | CC 71<br>— | CC 72<br>— | CC 73<br>— | CC 74<br>— | CC 75<br>— | CC 76<br>— |
| **Row 3** | CC 77<br>— | CC 78<br>— | CC 79<br>— | CC 80<br>— | CC 81<br>— | CC 82<br>— | CC 83<br>— | CC 84<br>— |
| **Fader Level** | CC 53<br>— | CC 54<br>— | CC 55<br>— | CC 56<br>— | CC 57<br>— | CC 58<br>**Heartbeat**<br>007's soft pulse on D. | CC 59<br>**Drone**<br>D–A drone, swelling every 2 bars. | CC 60<br>**Pad**<br>007's pad, high-passed (less mud). |
| **Buttons 1** | CC 85<br>— | CC 86<br>— | CC 87<br>— | CC 88<br>— | CC 89<br>**Progression**<br>next of 3, at the next 8 bars. | CC 90<br>— | CC 91<br>— | CC 92<br>— |
| **Buttons 2** | CC 93<br>— | CC 94<br>— | CC 95<br>— | CC 96<br>— | CC 97<br>**Back**<br>previous progression. | CC 98<br>**Pulse out**<br>the pulse pauses while held. | CC 99<br>— | CC 100<br>— |

## Guide

### What to listen for

Do bowed, marimba and toms work together? Which figures to keep on marimba and on toms? How far can the toms drift?