Launch Control XL 3 — Ambient Harmonie 2 (lab/harmonie, 007: a melodic voice that guides)

Columns 1–5 = melodic candidates, 6 Eno bowed and 7 Gas veil from round 1 to compare. All in D lydian over 007's context (Mode 2).

Knob | Fader | Button | unused

Mode 16 — Candidates

	1 Eno Rhodes	2 BoC Lead	3 Marimba Phase	4 Zither Theme	5 Vibes Motif	6 Eno Bowed	7 Gas Veil	8
Row 1 Brightness	CC 13 **Brightness** dull ↔ bright (low-pass over the sound's range).	CC 14 **Brightness** as 1 Eno Rhodes	CC 15 **Brightness** as 1 Eno Rhodes	CC 16 **Brightness** as 1 Eno Rhodes	CC 17 **Brightness** as 1 Eno Rhodes	CC 18 **Brightness** as 1 Eno Rhodes	CC 19 **Brightness** as 1 Eno Rhodes	CC 20 —
Row 2 Space	CC 21 **Space** room and dotted-8th echo (a little at 0).	CC 22 **Space** as 1 Eno Rhodes	CC 23 **Space** as 1 Eno Rhodes	CC 24 **Space** as 1 Eno Rhodes	CC 25 **Space** as 1 Eno Rhodes	CC 26 **Space** as 1 Eno Rhodes	CC 27 **Space** as 1 Eno Rhodes	CC 28 —
Row 3 Character	CC 29 **Length** shorter ↔ longer notes.	CC 30 **Length** as 1 Eno Rhodes	CC 31 **Second voice** 0 = one marimba ↔ a second one a 16th behind.	CC 32 **Length** shorter ↔ longer notes.	CC 33 **Length** as 4 Zither Theme	CC 34 **Voices** 2 loops ↔ 6 loops drifting against each other.	CC 35 **Smear** clear soft pulse ↔ a haze with echoes.	CC 36 —
Fader Level	CC 5 **Level** 0 = off.	CC 6 **Level** as 1 Eno Rhodes	CC 7 **Level** as 1 Eno Rhodes	CC 8 **Level** as 1 Eno Rhodes	CC 9 **Level** as 1 Eno Rhodes	CC 10 **Level** as 1 Eno Rhodes	CC 11 **Level** as 1 Eno Rhodes	CC 12 —
Button 1 Change	CC 37 **Change** motif → half speed → octave up.	CC 38 **Change** as 1 Eno Rhodes	CC 39 **Change** 3 figures.	CC 40 **Change** motif → half speed → octave up.	CC 41 **Change** as 4 Zither Theme	CC 42 **Change** note set: open → middle → high.	CC 43 **Change** quarters → off-beats → 3-3-2.	CC 44 —
Button 2 Moment	CC 45 **Echo throw** held: long dotted-8th echo.	CC 46 **Echo throw** as 1 Eno Rhodes	CC 47 **Echo throw** as 1 Eno Rhodes	CC 48 **Echo throw** as 1 Eno Rhodes	CC 49 **Echo throw** as 1 Eno Rhodes	CC 50 **Echo throw** as 1 Eno Rhodes	CC 51 **Echo throw** as 1 Eno Rhodes	CC 52 —

Mode 2 — Context

	1	2	3	4	5 Progression	6 Heartbeat	7 Drone	8 Pad
Row 1	CC 61 —	CC 62 —	CC 63 —	CC 64 —	CC 65 —	CC 66 —	CC 67 —	CC 68 —
Row 2	CC 69 —	CC 70 —	CC 71 —	CC 72 —	CC 73 —	CC 74 —	CC 75 —	CC 76 —
Row 3	CC 77 —	CC 78 —	CC 79 —	CC 80 —	CC 81 —	CC 82 —	CC 83 —	CC 84 —
Fader Level	CC 53 —	CC 54 —	CC 55 —	CC 56 —	CC 57 —	CC 58 **Heartbeat** 007's soft pulse on D.	CC 59 **Drone** D–A drone, swelling every 2 bars.	CC 60 **Pad** 007's pad, high-passed (less mud).
Buttons 1	CC 85 —	CC 86 —	CC 87 —	CC 88 —	CC 89 **Progression** next of 3, at the next 8 bars.	CC 90 —	CC 91 —	CC 92 —
Buttons 2	CC 93 —	CC 94 —	CC 95 —	CC 96 —	CC 97 **Back** previous progression.	CC 98 **Pulse out** the pulse pauses while held.	CC 99 —	CC 100 —

Guide

What to listen for

Which melody gives orientation without being one more held layer? Which could replace the whale?