Blast cabinet and blast pot maintenance schedule

FleetOptima
fleetoptima.org

For abrasive blast cabinets and portable pressure blast pots. Worn blast hose can burst under pressure, so squeeze it for soft spots and replace it before the wear reaches the fabric.

Typical intervals from manufacturer manuals and published service schedules. Your machine's manual comes first.

Daily, before blasting (air off)

TASK	HOW OFTEN	NOTES	✓
Blast hose: squeeze it for soft spots	Daily	Soft spots mean it's worn; replace it	
Couplings tight, lock pins and safety cables on	Daily		
Nozzle washer in place, threads not worn	Every time the nozzle goes on	A loose nozzle can blow out under pressure	
Deadman handle works	Daily	Only engages with the safety lock down, springs back up when let go	
Pot: empty the abrasive trap screen	At least twice a day		
Cabinet: media level, debris screen, door gasket	Daily		
Drain the air filter and moisture separator	Daily	Wet air makes media clump and stop flowing	
Cabinet: dust bin, empty by half full	Daily		

Daily, while blasting

TASK	HOW OFTEN	NOTES	✓
Leaks at couplings, pop-up valve, door, piping	Daily	Stop and fix; abrasive cuts through a leak fast	
Dust at the cabinet exhaust or door seals	Daily	Means a leaking or loaded filter cartridge	
Drain the collector's pulse reservoir	End of each day		

Weekly

TASK	HOW OFTEN	NOTES	✓
Nozzle: replace when worn 1/16 inch over size	Weekly	Or if the liner is cracked	
Gloves and window cover lens	Weekly	Extra static shocks can be the first sign of worn gloves	
Outlet valve diaphragm and flex hoses	Weekly		
Collector's inline filter	Weekly		

Monthly

TASK	HOW OFTEN	NOTES	✓
Pop-up valve and seal	Monthly	Replace at the first crack, groove or dry rot	
Reclaimer wear plate and liners	Monthly	Replace when worn through to metal	
Pot exhaust muffler	Monthly	Slow depressurizing means it's clogging	

Required by code? OSHA 1910.94 covers abrasive blasting: the nozzle must be bonded and grounded against static, blast enclosure baffles inspected regularly and replaced when needed, dust leaks repaired promptly, exhaust air run through a dust collector, and operators in blast rooms must wear NIOSH-approved abrasive blasting respirators. Code items apply where your city, state or insurer has adopted them. Requirements vary by jurisdiction, so check local code.

Service log: blast cabinet and blast pot

Machine / unit: _____ Make & model: _____

FleetOptima
fleetoptima.org

DATE	NEXT DUE	WORK DONE	PARTS USED	INITIALS

Free printable from fleetoptima.org/maintenance-schedules