VM und Modbus

VM

DB1,DT0	Zeit	Beschreibung	datatype
DB1,X1.0	I1	Input physischer Fernschalter Kompressor 1	bit
DB1,X1.1	I2	Input physischer Fernschalter Kompressor 2	bit
DB1,X1.2	I3	Input physischer Fernschalter Kompressor 3	bit
DB1,X1.3	I4	Input physischer Fernschalter Kompressor 4	bit
DB1,X1.4	I5	Input Störkontakt Trockner 1	bit
DB1,X1.5	I6	Input Störkontakt Trockner 2	bit
DB1,X1.6	I7	Input Störkontakt Trockner 3	bit
DB1,X1.7	I8	Input Störkontakt Trockner 4	bit
DB1,X4.0	Q1	Fernkontakt Kompressor 1	bit
DB1,X4.1	Q2	Fernkontakt Kompressor 1	bit
DB1,WORD1118	AM 1		
DB1,WORD1120	AM 2		
DB1,WORD1122	AM 3		
DB1,WORD1124	AM 4		
DB1,X1104.0	M1		
DB1,X1104.4	M5	Störmeldung Kompressor 1	bit
DB1,X1104.5	M6	Störmeldung Trockner 1	bit
DB1,X1104.6	M7	Störmeldung Kondensat	bit
DB1,WORD1136	AM10	Netzdruck	word
DB1,WORD1138	AM11	Taupunkt	word
DB1,WORD1140	AM12	Volumenstrom 1	word
DB1,WORD1142	AM13	Volumenstrom 2	word
DB1,X1104.1	M2	Kompressor 1 Fernsteuerung	bit
DB1,X1104.2	M3	Kompressor 2 Fernsteuerung	bit
DB1,X1104.3	M4	Kompressor 3 Fernsteuerung	bit
DB1,X1107.0	M25		
DB1,X1064.2	Q3	Fernkontakt Kompressor 3	bit
DB1,X1064.3	Q4	Fernkontakt Kompressor 4	bit
DB1,X1105.0	M9	Kompressor 4 Fernsteuerung	bit
DB1,X1105.1	M10	Störung Trockner 2	bit
DB1,X1105.2	M11	Störung Trockner 3	bit
DB1,X1105.3	M12	Störung Trockner 4	bit
DB1,X1105.4	M13		
DB1,X1065.1	Q10	Alarm Kompressor 1	bit
DB1,X1065.2	Q11	Alarm Kompressor 2	bit
DB1,X1065.3	Q12	Alarm Kompressor 3	bit
DB1,X1065.4	Q13	Alarm Kompressor 4	bit
DB1,X1065.5	Q14		
DB1,X1065.6	Q15		
DB1,X1065.7	Q16		
DB1,X1066.0	Q17		
DB1,X1066.1	Q18		
DB1,X1066.2	Q19		
DB1,X1065.3	Q20		
DB1,X1065.4	Q21		
DB1,X1064.4	Q5	Störung Trockner 1	bit
DB1,X1064.5	Q6	Störung Trockner 2	bit
DB1,X1064.6	Q7	Störung Trockner 3	bit
DB1,X1064.7	Q8	Störung Trockner 4	bit
DB1,X1065.0	Q9	Störung Kondensat	bit
DB1,X1025.0	I9		bit

Modbus

Modbus Siemens PAC 3200 10.200.1.144 Port 502

Adresse		
1	FC 3 Read Holding Register	Spannung L1
3	FC 3 Read Holding Register	Spannung L2
5	FC 3 Read Holding Register	Spannung L3
13	FC 3 Read Holding Register	Strom L1
15	FC 3 Read Holding Register	Strom L2
17	FC 3 Read Holding Register	Strom L3
63	FC 3 Read Holding Register	Summe Wirkleistung

Modbus Logo 10.200.1.142 Port 503

Adresse	Modbus Datgentyp	Logo	Bezeichnung	Format
8257	FC5 Write Single Coil	M2	Kompressor 1	true,false
8258	FC5 Write Single Coil	M3	Kompressor 2	true,false
8259	FC5 Write Single Coil	M4	Kompressor 3	true,false
8260	FC1 Read Coils	M5	Störung Kompressor 1	true,false
8261	FC1 Read Coils	M6	Störung Trockner 1	true,false
8262	FC1 Read Coils	M7	Störung Kondensat	true,false
8263	FC1 Read Coils	M8		
8264	FC5 Write Single Coil	M9	Kompressor 4	true,false
8265	FC1 Read Coils	M10	Störung Kompressor 2	true,false
8266	FC1 Read Coils	M11	Störung Kompressor 3	true,false

8267	FC1 Read Coils	M12	Störung Kompressor 4	true,false

529	FC3 Read Holding Register	AM2		
530	FC3 Read Holding Register	AM3		
531	FC3 Read Holding Register	AM4		
532	FC3 Read Holding Register	AM5		
533	FC3 Read Holding Register	AM6		
534	FC3 Read Holding Register	AM7		
535	FC3 Read Holding Register	AM8		
536	FC3 Read Holding Register	AM9		
537	FC3 Read Holding Register	AM10	Druck	Float
538	FC3 Read Holding Register	AM11	Taupunkt	Float
539	FC3 Read Holding Register	AM12	Volumenstrom 1	Float
540	FC3 Read Holding Register	AM13	Volumenstrom 2	Float
541	FC3 Read Holding Register	AM14		
542	FC3 Read Holding Register	AM15		
543	FC3 Read Holding Register	AM16		
544	FC3 Read Holding Register	AM17		
545	FC3 Read Holding Register	AM18		
546	FC3 Read Holding Register	AM19		
547	FC3 Read Holding Register	AM20		

1	FC2 Read Discrete Input	I2	Kompressor 2 Start über physischen Fe	true,false
2	FC2 Read Discrete Input	I3	Kompressor 3 Start über physischen Fe	true,false
3	FC2 Read Discrete Input	I4	Kompressor 4 Start über physischen Fe	true,false
4	FC2 Read Discrete Input	I5		
5	FC2 Read Discrete Input	I6		
6	FC2 Read Discrete Input	I7		
7	FC2 Read Discrete Input	I8		
8	FC2 Read Discrete Input	I9	Störung Kondensat	true,false
9	FC2 Read Discrete Input	I10	Störung Kompressor 1	true,false
10	FC2 Read Discrete Input	I11	Störung Kompressor 2	true,false
11	FC2 Read Discrete Input	I12	Störung Kompressor 3	true,false
12	FC2 Read Discrete Input	I13	Störung Kompressor 4	true,false

8196	FC1 Read Coil Status	Q5	Störung Trockner 1	true,false
8197	FC1 Read Coil Status	Q6	Störung Trockner 2	true,false
8198	FC1 Read Coil Status	Q7	Störung Trockner 3	true,false
8199	FC1 Read Coil Status	Q8	Störung Trockner 4	true,false