

RXC-3000 Programming Worksheet for Siren System Control

Please complete this worksheet and submit with your order.



Customer Nam	e								
Address									
City	State Zip								
Contact Name									
Tel	el Fax E-mail								
Shipping Addres	SS								
City					State			Zip	
Your order refe	erence:				Site Number or	Nar	ne:		
Receive Frequency	(MHz)		Channels are:	V	Vide or Narrowbane	d	CTCSS Code	DCS/DPL Code	
			50 to 174 MHz 50 to 490 MHz						
1. Pagin	g Cont	rol – Sin	gle-tone or	Two	-tone Sequenti	al		1	
Item No.	A To	ne (Hz)	A Length (s	ec)	B Tone (Hz)	В	Length (sec)	Function	
1 2									
3									
4									
5									
6									
7									
8									
10									
Example		▲ 422.1		1.0	470.5		3.0	Steady A	
Frequency inTones must l	oe betweer	of the activa 280Hz and		on-the-	air.		Valid Funder William Silver File Air Air Air Control of the Contro		





RXC-3000

Programming Worksheet for Siren System Control

2. DTMF Control

Item No.	DTMF Activation Codes								Function						
1															
2															
3															
4															
5															
6															
7															
8															
9															
10															
Example									4	1	X	1	#	2	Steady

(use the letter X to signify a "Wildcard" position where any digit will be accepted)

3. How will DTMF codes be sent?

- Manually One digit at a time. (3 second max inter-digit)
- Automatic Entire code sent as one uninterrupted group.
 - o (.5 second inter-digit)
- Both (3 second max inter-digit)

Valid Functions

- Wail
- Steady
- Fire–W (wail)
- Fire–S (steady)
- Aux-1
- Aux-2
- Cancel
- PA-Action



4. Relay Actions

	All times for Actions are in Seconds.								
Function	Total Run	Relay One	Relay One						
	Time	Cycle ON	Cycle OFF						
WAIL									
STEADY									
FIRE-W (wail)									
FIRE-S (steady)									
AUX-1									
AUX-2									

Relay 1 engages for all these Actions. It will cycle on/off for the Cycle time if any is specified.

Relay 2 engages for the total run time.

Relay 3 cycles on and off for the total run time.

Relay 4 is unassigned and can be field set for specific actions.

Relay 5 engages for PA and audio file events.





RXC-3000

Programming Worksheet for Siren System Control

By-pass this page if you are ordering the RXC without the time clock option.

The time related fields are only for initial settings. The Triggers, Lockouts, Current Time and Daylight Saving Time can all be adjusted, enabled and disabled in the field by using the Twist-n-TouchTM control on the RXC.



5. Triggers (clock option required)

3. Triggers (clock option required)										
Function	Time of Day	Duration in								
	to Activate	seconds	Mon	Tue	Wed	Thu	Fri	Sat	Sun	
NOON										
EVENING										
SPL-TRG1										
SPL-TRG2										
Evening example	00:00	8	X	X	X	X	X			

In the Evening example, relays 1 & 2 will engage for eight seconds at 6:00 PM every night, Monday - Friday.



6. Lockouts (clock option required)

Function	Lockout	Lockout
	FROM	TO
WAIL		
STEADY		
FIRE-W (wail)		
FIRE-S (steady)		
PA-ACTN		
AUX-1		
AUX-2		
CANCEL		
	_	-
Fire-W example	23:00	05:00

In above example, Fire-W actions will not be performed between the hours of 11:00 PM and 5:00 AM.



7. Initial Clock Settings (clock option required)

Time Zone

Automatic adjust for Daylight Saving Time.





RXC-3000

Programming Worksheet for Siren System Control

8. Audio Messages / Sound (audio module option required)

Function	Name	File
WAIL		
STEADY		
FIRE-W (wail)		
FIRE-S (steady)		
PA-ACTN		
AUX-1		
AUX-2		
CANCEL		
Steady example 1		steady-siren-three-minutes-heartsafe.wav
Steady example 2		cust-voice-msg-storm-warning-take-cover.wav
Aux-1 example		cust-voice-msg-take-shelter-in-athletic-center.wav

In the first example, in addition to the relay actions, a Steady activation will also play the wav file. The sound will be sent to the audio output for connection to independent amplifiers. Heartsafe indicates the audio file was produced to ramp from zero to full volume over several seconds to prevent startling people nearby.

In the second example, customer has supplied a custom wav file which delivers a voice message with general instructions and as well as alert tones.

In the third example, when Aux-1 is activated, it delivers a customer supplied wav file which gives specific instructions to participants at a ball field. In this instance it directs them to an approved storm shelter. Depending upon the exact relay configuration of Aux-1 the RXC could also activate flashing lights or other warning devices for extra impact as it delivers the message.

Customer supplied audio files can be sent to Genave via cd, dvd or email. If emailed, they must be sent in .zip format with a clearly descriptive filename and your contact information in the body of the email. All files need to be in .wav, mono format. Optional software is available from Genave to allow messages to be changed and uploaded to the RXC's SIM (memory) card in the field, via a laptop computer.

Notes:			