

Preventative Maintenance Procedures

FinalProof Engines

Customer Name: _____

FinalProof S/N: _____

FinalProof F/W Rev: _____

1. ☐ Review the **error log**. This will contain the last 100 error messages received. Look for any unusual patterns or frequency of certain error messages.
2. ☐ Check the **information log**. Are all firmware versions current? There are four firmware versions to check. RCP, Panel, Recording Head and FPGA. If any of these versions are not current, they will need to be updated.
3. ☐ Clean the **dust and transport rollers** for the film and receiver transport sections. Clean all guides in this transport section as well.
4. ☐ Clean the **dust and squeegee rollers** for the recording drum.
5. ☐ Clean Drum and clean Yellow Tape on drum. Inspect condition of Yellow Tape and Mylar on drum surface.
6. ☐ Clean all six sets of **film feed rollers, guides, and film lock bars** in film holder section.
7. ☐ Clean Receiver film loading area. Inspect Receiver end caps.
8. ☐ Remove any **dust** that has built up inside the print engine. Use a soft, water dampened cloth.
9. ☐ Reset **consumable counters** for the dust and squeegee rollers.
10. ☐ Clean the **air filters.** There are two filters located on the right side of the print engine. There is one filter located on the right side of the film holder unit. Replace if necessary.
11. ☐ Rest the **consumable counters** for the air filters.
12. ☐ Clean the **calibration sensor.** Clean the **Recording Head Lens.** Clean only using eyeglass or camera **lens paper**. **DO NOT** use a Q tip or any type of solvents.
13. ☐ Check and confirm the **Laser power and rotation series settings.** Make sure all three density tables are set the same.
14. ☐ Check the horizontal and vertical recording drum **load positioning** for the film and receiver material.
15. ☐ Check the **Film Loading Fiber Optic** sensors for stable operation. Stable operation is confirmed when there is a constant **green light** on Fiber Optic Amplifier. When loading films, light should always be green. If not, then re-adjust.
16. ☐ Verify the **vacuum unit calibration**.
17. ☐ On a yearly basis, remove cover and clean out **Vacuum Unit.** Excessive dust will buildup over time.
18. ☐ **Calibrate** the laser diodes for each resolution. **Read** the Iop values for each laser Diode for all resolutions and check for weak laser.
19. ☐ **C**heck the **Focus** value setting for **all resolutions used.** Ensure that the Final Proof print engine has been turned on and warmed up for a minimum of two hours before evaluating the Focus test.
20. ☐ Check the **Zoom** value setting for **all resolutions**.

21. ☐ Image and evaluate **internal test pattern** # 18 and # 22. Use magenta for test pattern # 18. Look for material scratching. Use black film for test pattern # 22. Look for hot spots on the drum.

22. ☐ Retrieve the **ASCII, FLASH and NVRAM** data. Copy this to a floppy disk and leave in the machine with the production record.

Laminator

1. ☐ Lubricate lower roller bushings. Use Biral Lube or Vaseline.

2. ☐ Clean dust from inside laminator and lower cooling fans.

3. ☐ Inspect Rollers for Damage or Dirt Buildup. Cleaning can be done by customer or on a separate service call.

PAT Unit

1. ☐ Check filter change period lights. Change filter if necessary. Make sure Filter replacement kit is on site.

2. ☐ Check Humidifier section lights for any problems. Sediment container will cause drain/fill problem.

3. ☐ Inspect PAT for any water leaks. Common leaks are from drain section or Nozzle section inside PAT filter area. To check Nozzle, remove HEPA filter and look up at small black rubber hose to see if it is still connected to Nozzle.

See the following page for a list of commonly used PM Parts

Notes:

Common PM Parts for FinalProof

PAT Yearly filter kit FSK505
Sediment Container 35131
Steam Nozzle 36010

Biral Oil 891F0013
Vaseline 891N0850001

PM Kit Contents
Air Filter (2) D70515162-00 (drum section upper)
Air Filter (3) D70515163-00 (drum section lower)
Air Filter (1) D70515161-00 (film holder section)