A motte @-@ and @-@ bailey castle is a fortification with a wooden or stone keep situated on a raised earthwork called a motte , accompanied by an enclosed courtyard , or bailey , surrounded by a protective ditch and palisade . Relatively easy to build with unskilled , often forced , labour , but still militarily formidable , these castles were built across northern Europe from the 10th century onwards , spreading from Normandy and Anjou in France , into the Holy Roman Empire in the 11th century . The Normans introduced the design into England and Wales following their invasion in 1066 . Motte @-@ and @-@ bailey castles were adopted in Scotland , Ireland , the Low Countries and Denmark in the 12th and 13th centuries . By the end of the 13th century , the design was largely superseded by alternative forms of fortification , but the earthworks remain a prominent feature in many countries .

= = Architecture = =

= = = Structures = = =

A motte @-@ and @-@ bailey castle was made up of two structures, a motte, a type of mound? often artificial? topped with a wooden or stone structure known as a keep; and at least one bailey, a fortified enclosure built next to the motte. The term " motte and bailey " is a relatively modern one, and is not medieval in origin. The word " motte " is the French version of the Latin mota, and in France the word motte was initially an early word for a turf; it then became used to refer to a turf bank, and by the 12th century was used to refer to the castle design itself. The word " bailey " comes from the Norman @-@ French baille, or basse @-@ cour, referring to a low yard. In medieval sources, the Latin term castellum was used to describe the bailey complex within these castles.

One contemporary account of these structures comes from Jean de Colmieu around 1130 , describing the Calais region in northern France . De Colmieu described how the nobles would build " a mound of earth as high as they can and dig a ditch about it as wide and deep as possible . The space on top of the mound is enclosed by a palisade of very strong hewn logs , strengthened at intervals by as many towers as their means can provide . Inside the enclosure is a citadel , or keep , which commands the whole circuit of the defences . The entrance to the fortress is by means of a bridge , which , rising from the outer side of the moat and supported on posts as it ascends , reaches to the top of the mound . " At Durham Castle , contemporaries described how the motte @-@ and @-@ bailey superstructure arose from the " tumulus of rising earth " with a keep rising " into thin air , strong within and without " with a " stalwart house ... glittering with beauty in every part "

Mottes were made out of earth and flattened on top , and it can be very hard to determine whether a mound is artificial or natural without excavation . Some were also built over older artificial structures , such as Bronze Age barrows . The size of mottes varied considerably , with these mounds being 3 metres to 30 metres in height (10 feet to 100 feet) , and from 30 metres to 90 metres in diameter (100 feet to 300 feet) . This minimum height of 3 metres (10 feet) for mottes is usually intended to exclude smaller mounds which often had non @-@ military purposes . In England and Wales , only 7 % of mottes were taller than ten metres high ; 24 % were between ten and five metres , and 69 % were less than five metres tall . A motte was protected by a ditch around it , which would typically have also been a source of the earth and soil for constructing the mound itself .

A keep and a protective wall would usually be built on top of the motte. Some walls would be large enough to have a wall @-@ walk around them, and the outer walls of the motte and the wall @-@ walk could be strengthened by filling in the gap between the wooden walls with earth and stones, allowing it to carry more weight; this was called a garillum. Smaller mottes could only support simple towers with room for a few soldiers, whilst larger mottes could be equipped with a much

grander building. Many wooden keeps were designed with a bretasche, a square building that overhung from the upper floors of the building, enabling better defences and a more sturdy structural design. The early 12th @-@ century chronicler Lambert of Ardres described the wooden keep on top of the motte at the castle of Ardres, where the "first storey was on the surface of the ground, where were cellars and granaries, and great boxes, tuns, casks, and other domestic utensils. In the storey above were the dwelling and common living @-@ rooms of the residents in which were the larders, the rooms of the bakers and butlers, and the great chamber in which the lord and his wife slept ... In the upper storey of the house were garret rooms ... In this storey also the watchmen and the servants appointed to keep the house took their sleep ". Wooden structures on mottes could be protected by skins and hides to prevent them being easily set alight during a siege.

The bailey was an enclosed courtyard overlooked by the motte and surrounded by a wooden fence called a palisade and another ditch . The bailey was often kidney @-@ shaped to fit against a circular motte , but could be made in other shapes according to the terrain . The bailey would contain a wide number of buildings , including a hall , kitchens , a chapel , barracks , stores , stables , forges or workshops , and was the centre of the castle 's economic activity . The bailey was linked to the motte either by a flying bridge stretching between the two , or , more popularly in England , by steps cut into the motte . Typically the ditch of the motte and the bailey joined , forming a figure of eight around the castle . Wherever possible , nearby streams and rivers would be dammed or diverted , creating water @-@ filled moats , artificial lakes and other forms of water defences .

In practice , there was a wide number of variations to this common design . A castle could have more than one bailey : at Warkworth Castle an inner and an outer bailey was constructed , or alternatively , several baileys could flank the motte , as at Windsor Castle . Some baileys had two mottes , such as those at Lincoln . Some mottes could be square instead of round , such as at Cabal Trump . Instead of single ditches , occasionally double @-@ ditch defences were built , as seen at Berkhamsted . Local geography and the intent of the builder produced many unique designs

= = = Construction and maintenance = = =

Various methods were used to build mottes . Where a natural hill could be used , scarping could produce a motte without the need to create an artificial mound , but more commonly much of the motte would have to be constructed by hand . Four methods existed for building a mound and a tower : the mound could either be built first , and a tower placed on top of it ; the tower could alternatively be built on the original ground surface and then buried within the mound ; the tower could potentially be built on the original ground surface and then partially buried within the mound , the buried part forming a cellar beneath ; or the tower could be built first , and the mound added later .

Regardless of the sequencing , artificial mottes had to be built by piling up earth ; this work was undertaken by hand , using wooden shovels and hand @-@ barrows , possibly with picks as well in the later periods . Larger mottes took disproportionately more effort to build than their smaller equivalents , because of the volumes of earth involved . The largest mottes in England , such as Thetford , are estimated to have required up to 24 @,@ 000 man @-@ days of work ; smaller ones required perhaps as little as 1 @,@ 000 . Contemporary accounts talk of some mottes being built in a matter of days , although these low figures have led to suggestions by historians that either these figures were an underestimate , or that they refer to the construction of a smaller design than that later seen on the sites concerned . Taking into account estimates of the likely available manpower during the period , historians estimate that the larger mottes might have taken between four and nine months to build . This contrasted favourably with stone keeps of the period , which typically took up to ten years to build . Very little skilled labour was required to build motte and bailey castles , which made them very attractive propositions if forced peasant labour was available , as was the case after the Norman invasion of England . Where the local workforce had to be paid - such as at Clones in Ireland , built in 1211 using imported labourers ? the costs would rise quickly , in this case

reaching £ 20.

The type of soil would make a difference to the design of the motte , as clay soils could support a steeper motte , whilst sandier soils meant that a motte would need a more gentle incline . Where available , layers of different sorts of earth , such as clay , gravel and chalk , would be used alternatively to build in strength to the design . Layers of turf could also be added to stabilise the motte as it was built up , or a core of stones placed as the heart of the structure to provide strength . Similar issues applied to the defensive ditches , where designers found that the wider the ditch was dug , the deeper and steeper the sides of the scarp could be , making it more defensive . Although militarily a motte was , as Norman Pounds describes it , " almost indestructible " , they required frequent maintenance . Soil wash was a problem , particularly with steeper mounds , and mottes could be clad with wood or stone slabs to protect them . Over time , some mottes suffered from subsidence or damage from flooding , requiring repairs and stabilisation work .

Although motte @-@ and @-@ bailey castles are the best known castle design , they were not always the most numerous in any given area . A popular alternative was the ringwork castle , involving a palisade being built on top of a raised earth rampart , protected by a ditch . The choice of motte and bailey or ringwork was partially driven by terrain , as mottes were typically built on low ground , and on deeper clay and alluvial soils . Another factor may have been speed , as ringworks were faster to build than mottes . Some ringwork castles were later converted into motte @-@ and @-@ bailey designs , by filling in the centre of the ringwork to produce a flat @-@ topped motte . The reasons for why this decision was taken are unclear ; motte @-@ and @-@ bailey castles may have been felt to be more prestigious , or easier to defend ; another theory is that like the terpen in Netherlands , or Vorburg and Hauptburg in Lower Rhineland , raising the height of the castle was done to create a drier site .

```
= = History = =
```

= = = Emergence of the design = = =

The motte @-@ and @-@ bailey castle is a particularly northern European phenomenon, most numerous in Normandy and Britain, but also seen in Denmark, Germany, Southern Italy and occasionally beyond. European castles first emerged in the 9th and 10th centuries, after the fall of the Carolingian Empire resulted in its territory being divided among individual lords and princes and local territories became threatened by the Magyars and the Norse. Against this background various explanations have been put forward to explain the origins and spread of the motte @-@ and @-@ bailey design across northern Europe; there is often a tension among the academic community between explanations that stress military and social reasons for the rise of this design. One suggestion is that these castles were built particularly in order to protect against external attack ? the Angevins, it is argued, began to build them to protect against the Viking raids, and the design spread to deal with the attacks along the Slav and Hungarian frontiers. Another argument is that, given the links between this style of castle and the Normans, who were of Viking descent, it was in fact originally a Viking design, transported to Normandy and Angers. The motte @-@ and @-@ bailey castle was certainly effective against assault, although as historian André Debord suggests, the historical and archaeological record of the military operation of motte @-@ and @-@ bailey castles remains relatively limited.

An alternative approach focuses on the links between this form of castle and what can be termed a feudal mode of society . The spread of motte @-@ and @-@ bailey castles was usually closely tied to the creation of local fiefdoms and feudal landowners , and areas without this method of governance rarely built these castles . Yet another theory suggests that the design emerged as a result of the pressures of space on ringworks , and that the earliest motte @-@ and @-@ baileys were converted ringworks . Finally , there may be a link between the local geography and the building of motte @-@ and @-@ bailey castles , which are usually built on low @-@ lying areas , in many cases subject to regular flooding . Regardless of the reasons behind the initial popularity of

the motte @-@ and @-@ bailey design, however, there is widespread agreement that the castles were first widely adopted in Normandy and Angevin territory in the 10th and 11th centuries.

= = = Initial development, 10th and 11th centuries = = =

The earliest purely documentary evidence for motte @-@ and @-@ bailey castles in Normandy and Angers comes from between 1020 and 1040 , but a combination of documentary and archaeological evidence pushes the date for the first motte and bailey castle , at Vincy , back to 979 . The castles were built by the more powerful lords of Anjou in the late 10th and 11th centuries , in particular Fulk III and his son , Geoffrey II , who built a great number of them between 987 and 1060 . Many of these earliest castles would have appeared quite crude and rustic by later standards , belying the power and prestige of their builders . William the Conqueror , as the Duke of Normandy , is believed to have adopted the motte @-@ and @-@ bailey design from neighbouring Anjou . Duke William went on to prohibit the building of castles without his consent through the Consuetudines et Justicie , with his legal definition of castles centring on the classic motte @-@ and @-@ bailey features of ditching , banking and palisading .

By the 11th century , castles were built throughout the Holy Roman Empire , which then spanned central Europe . They now typically took the form of an enclosure on a hilltop , or , on lower ground , a tall , free @-@ standing tower (German Bergfried .) The largest castles , known in German as Hohenburgen , had well @-@ defined inner and outer courts , but no mottes . The motte @-@ and @-@ bailey design began to spread into Alsace and the northern Alps from France during the first half of the 11th century , spreading further into Bohemia and Austria in the subsequent years . This form of castle was closely associated with the colonisation of newly cultivated areas within the Empire , as new lords were granted lands by the emperor and built castles close to the local gród , or town . Motte @-@ and @-@ bailey castle building substantially enhanced the prestige of local nobles , and it has been suggested that their early adoption was because they were a cheaper way of imitating the still more prestigious hohenburgen , but this is usually regarded as unlikely . In many cases , bergfrieds were converted into motte and bailey designs by burying existing castle towers within the mounds .

In England, William invaded from Normandy in 1066, resulting in three phases of castle building in England, around 80 % of which were in the motte @-@ and @-@ bailey pattern. The first of these was the establishment by the new king of royal castles in key strategic locations, including many towns. These urban castles could make use of the existing town 's walls and fortification, but typically required the demolition of local houses to make space for them . This could cause extensive damage: records suggest that in Lincoln 166 houses were destroyed, with 113 in Norwich and 27 in Cambridge. The second and third waves of castle building in the late @-@ 11th century were led by the major magnates and then the more junior knights on their new estates. Some regional patterns in castle building can be seen - relatively few castles were built in East Anglia compared to the west of England or the Marches, for example; this was probably due to the relatively settled and prosperous nature of the east of England and reflected a shortage of unfree labour for constructing mottes. In Wales, the first wave of the Norman castles were again predominantly made of wood in a mixture of motte @-@ and @-@ bailey and ringwork designs. The Norman invaders spread up the valleys, using this form of castle to occupy their new territories . After the Norman conquest of England and Wales, the building of motte @-@ and @-@ bailey castles in Normandy accelerated as well, resulting in a broad swath of these castles across the Norman territories, around 741 motte @-@ and @-@ bailey castles in England and Wales alone.

= = = Further expansion, 12th and 13th centuries = = =

Having become well established in Normandy, Germany and Britain, motte @-@ and @-@ bailey castles began to be adopted elsewhere, mainly in northern Europe, during the 12th and 13th centuries. Conflict through the Low Countries encouraged castle building in a number of regions from the late 12th century to the 14th century. In Flanders, the first motte and bailey castles began

relatively early at the end of the 11th century. The rural motte @-@ and @-@ bailey castles followed the traditional design, but the urban castles often lacked the traditional baileys, using parts of the town to fulfil this role instead. Motte @-@ and @-@ bailey castles in Flanders were particularly numerous in the south along the Lower Rhine, a fiercely contested border. Further along the coast in Friesland, the relatively decentralised, egalitarian society initially discouraged the building of motte and bailey castles, although terpen, raised "dwelling mounds" which lacked towers and were usually lower in height than a typical motte, were created instead. By the end of the medieval period, however, the terpen gave way to hege wieren, non @-@ residential defensive towers, often on motte @-@ like mounds, owned by the increasingly powerful nobles and landowners. On Zeeland the local lords had a high degree of independence during the 12th and 13th centuries, owing to the wider conflict for power between neighbouring Flanders and Friesland. The Zeeland lords had also built terpen mounds, but these gave way to larger werven constructions? effectively mottes? which were later termed bergen. Sometimes both terpen and werven are called vliedburg, or "refuge castles". During the 12th and 13th centuries a number of terpen mounds were turned into werven mottes, and some new werven mottes were built from scratch. Around 323 known or probable motte and bailey castles of this design are believed to have built within the borders of the modern Netherlands .

In neighbouring Denmark , motte @-@ and @-@ bailey castles appeared somewhat later in the 12th and 13th centuries and in more limited numbers than elsewhere , due to the less feudal society . Except for a handful of mote and bailey castles in Norway , built in the first half of the 11th century and including the royal residence in Oslo , the design did not play a role further north in Scandinavia

The Norman expansion into Wales slowed in the 12th century but remained an ongoing threat to the remaining native rulers . In response , the Welsh princes and lords began to build their own castles , frequently motte @-@ and @-@ bailey designs , usually in wood . There are indications that this may have begun from 1111 onwards under Prince Cadwgan ap Bleddyn , with the first documentary evidence of a native Welsh castle being at Cymmer in 1116 . These timber castles , including Tomen y Rhodywdd , Tomen y Faerdre , Gaer Penrhôs , were of equivalent quality to the equivalent Norman fortifications in the area , and it can prove difficult to distinguish the builders of some sites from the archaeological evidence alone .

Motte @-@ and @-@ bailey castles in Scotland emerged as a consequence of the centralising of royal authority in the 12th century. David I encouraged Norman and French nobles to settle in Scotland, introducing a feudal mode of landholding and the use of castles as a way of controlling the contested lowlands. The quasi @-@ independent polity of Galloway, which had resisted the rule of David and his predecessors, was a particular focus for this colonisation. The size of these Scottish castles, primarily wooden motte and bailey constructions, varied considerably, from larger designs such as the Bass of Inverurie to smaller castles like Balmaclellan.

Motte @-@ and @-@ bailey castles were introduced to Ireland following the Norman invasion of Ireland that began between 1166 and 1171 under first Richard de Clare and then Henry II of England , with the occupation of southern and eastern Ireland by a number of Anglo @-@ Norman barons . The rapid Norman success depended on key economic and military advantages ; their cavalry enabled Norman successes in battles , and castles enabled them to control the newly conquered territories . The new lords rapidly built castles to protect their possessions ; most of these were motte @-@ and @-@ bailey constructions , many of them strongly defended . Unlike Wales , the indigenous Irish lords do not appear to have constructed their own castles in any significant number during the period . Between 350 and 450 motte @-@ and @-@ bailey castles are believed to remain today , although the identification of these earthwork remains can be contentious .

A small number of motte @-@ and @-@ bailey castles were built outside of northern Europe . In the late @-@ 12th century , the Normans invaded southern Italy and Sicily ; although they had the technology to build more modern designs , in many cases wooden motte @-@ and @-@ bailey castles were built instead for reasons of speed . The Italians came to refer to a range of different castle types as motta , however , and there may not have been as many genuine motte @-@ and @-@ bailey castles in southern Italy as was once thought on the basis of the documentary evidence

alone. In addition, there is evidence of the Norman crusaders building a motte and bailey using sand and wood in Egypt in 1221 during the Fifth Crusade.

= = = Conversion and decline, 13th? 14th centuries = = =

Motte and bailey castles became a less popular design in the mid @-@ medieval period . In France , motte @-@ and @-@ bailey castles were not built after the start of the 12th century , and mottes ceased to be built in most of England after around 1170 , although they continued to be erected in Wales and along the Marches . Many motte @-@ and @-@ bailey castles were occupied relatively briefly and in England many were being abandoned by the 12th century , and others neglected and allowed to lapse into disrepair . In the Low Countries and Germany , a similar transition occurred in the 13th and 14th centuries .

One factor was the introduction of stone into castle building . The earliest stone castles had emerged in the 10th century , with stone keeps being built on mottes along the Catalonia frontier and several , including Château de Langeais , in Angers . Although wood was a more powerful defensive material than was once thought , stone became increasingly popular for military and symbolic reasons . Some existing motte @-@ and @-@ bailey castles were converted to stone , with the keep and the gatehouse usually the first parts to be upgraded . Shell keeps were built on many mottes , circular stone shells running around the top of the motte , sometime protected by a further chemise , or low protective wall , around the base . By the 14th century , a number of motte and bailey castles had been converted into powerful stone fortresses .

Newer castle designs placed less emphasis on mottes . Square Norman keeps built in stone became popular following the first such construction in Langeais in 994 . Several were built in England and Wales after the conquest ; by 1216 there were around 100 in the country . These massive keeps could be either erected on top of settled , well established mottes , or could have mottes built around them ? so @-@ called " buried " keeps . The ability of mottes , especially newly built mottes , to support the heavier stone structures , was limited , and many needed to be built on fresh ground . Concentric castles , relying on several lines of baileys and defensive walls , made increasingly little use of keeps or mottes at all .

Across Europe , motte @-@ and @-@ bailey construction came to an end . At the end of the 12th century the Welsh rulers began to build castles in stone , primarily in the principality of North Wales and usually along the higher peaks where mottes were unnecessary . In Flanders , decline came in the 13th century as feudal society changed . In the Netherlands , cheap brick started to be used in castles from the 13th century onwards in place of earthworks , and many mottes were levelled , to help develop the surrounding , low @-@ lying fields ; these " levelled mottes " are a particularly Dutch phenomenon . In Denmark , motte and baileys gave way in the 14th century to a castrum @-@ curia model , where the castle was built with a fortified bailey and a fortified mound , somewhat smaller than the typical motte . By the 12th century , the castles in Western Germany began to thin in number , due to changes in land ownership , and various mottes were abandoned . In Germany and Denmark , motte @-@ and @-@ bailey castles also provided the model for the later wasserburg , or " water castle " , a stronghold and bailey construction surrounded by water , and widely built in the late medieval period .

= = = Today = = =

In England , motte @-@ and @-@ bailey earthworks were put to various uses over later years ; in some cases , mottes were turned into garden features in the 18th century , or reused as military defences during the Second World War . Today , almost no mottes of motte @-@ and @-@ bailey castles remain in regular use in Europe , with one of the few exceptions being that at Windsor Castle , converted for the storage of royal documents . The landscape of northern Europe remains scattered with their earthworks , and many form popular tourist attractions as part of the European heritage industry .