

Sim Setup

1. Time / Weather / A/C Position **As Chosen**
 --- IF FLYING ON IVAO ---
 - a. A/C Position **Free of other traffic**
 - b. IVAO Pilot Client **Connect**
2. EFB **Request Nav Data from Simbrief**
3. EFB **Release Unnecessary Ground Equipment**

Electrical Power-Up

1. XPDR **STBY**
2. BAT SW **Guarded & ON**
3. EMER EXIT SW **Guarded**
4. Ground Power Cart **Connected**
5. Ground Power **ON**

Cockpit Check

1. Gear **DOWN & 3 Green**
2. Flaps **Up & Matching Indicators**
3. Fire Test SW **L & R, then Middle**
4. Fire Squib Test Lights **L & R, then Middle**
5. EMER GEAR EXTEND **Check Closed**
6. Circuit Breakers **Check in**
7. Flight Recorder **Test, then Guarded**
8. Mach Airspeed Warning Test **1 & 2**
9. Stall Warning Test **1 & 2**
10. IRS L & R **NAV**
11. Lights **Test, then BRT**
12. Oxygen **Test**

FMC Setup

1. POS INIT **Set IRS Position**
 - a. Use Pos Init > Next Page > GPS L coordinates
2. ROUTE Page **Enter Route**
3. DEP ARR Page **Enter Departure and Arrival Route**
 - a. DEP Page **Select RWY & SID**
 - b. ROUTE Page **Activate**
 - c. NEXT Page **Enter Route**
 - d. DEP ARR Page **Enter Arrival**
 - e. ROUTE Page **Check for Discontinuities**
4. EXEC **Press**
5. INIT REF Page **Fill**
 - a. Lower Left to Lower Right
 - b. Reserves **Final Reserve + Alternate**
 - c. CRZ WIND **Enter Wind at TOC**
 - d. TRANS ALT **Enter TA + 1**
 - e. EXEC **Press**
6. PERF INIT > N1 Limit Page **Enter TO Performance**
 - a. Select DERATE before entering Temperature
7. TAKEOFF REF Page **Fill**
 - a. Trim **Set according to TAKEOFF REF Page**
 - b. MCP **Set V2 Speed**

Final Flow

1. Yaw Damper	ON
2. Navigation Panel	Normal & Auto Selected
3. Fuel Pumps	ON, if Fuel in Tank
4. Cross Feed	Open, then Closed
5. Galley Power	ON
6. EQUIP COOLING	Norm
7. EMER EXIT Lights	Armed
8. Seat Belt Lights	ON
9. L & R Wipers	Parked
10. WINDOW HEAT L & R	ON
11. Anti-Ice	OFF
12. HYD PUMPS	ON
13. TRIM AIR	ON
14. RECIRC FANS	AUTO
15. PACKS	AUTO
16. ISOL VALVE	Open
17. ENG BLEEDS	ON
18. APU BLEED	OFF
19. FLT ALT	Set CRZ ALT
20. LAND ALT	Set Landing Altitude
21. PRESS MODE SELECTOR	AUTO
22. EXT Lights	As Required
23. APU	START
24. MCP HDG	Set RWY HDG
25. COURSE L & R	Set As Required
a. If NAVAID used, set Frequency as STBY	
26. BYPASS in LEGS page	Verify Route on ND
a. Predicted path might not follow charts	
27. ALT	Set Initial Climb
28. FD	L ON, then R ON
29. EFIS	Setup as required
30. Autobrakes	RTO
31. MFD SYS	Check HYD QTY & PRESS, then MFD ENG

Final Flow - CONTINUED

32. Parking Brake	Set
33. Speed Brake	Down
34. Throttle	Full Forward, then Idle
35. ENG Start Levers	CUTOFF
36. STAB TRIM SW	Normal
37. Radio Panel	Frequencies Set as Required (COMM / NAV)
38. XPDR	Check Code and STBY
39. TRIMS	Neutral

Before Pushback

1. APU Power	Check Available
2. APU GEN	On BUS
3. APU BLEED	ON
4. GND PWR & Chocks	Remove
5. Doors	Confirm Closed
6. XPDR	Mode as Required
7. Pushback	Request

Before Engine Start

1. PACKS L & R	OFF
2. ANTI-COL Light	ON
3. XPDR	ALT OFF

Engine Start

1. R ENG START SW	GND
Once N2 Above 25%	
2. R ENG CUTOUT SW	IDLE
3. Repeat for ENG 1	

After Engine Start

1. GEN 1 & 2 SW	ON
Once APU GEN OFF BUS illuminated	
2. APU	OFF

Before Taxi

1. ENG 1 & 2 START SW	CONT
2. PROBE HEATS	ON
3. ENG ANTI-ICE	As Required
4. PACKS L & R	Auto
5. APU Bleed	OFF
6. ISOLATION VALVE	AUTO
7. FLAPS	TO
8. STAB TRIM	As Required (TAKEOFF REF Page)
9. START LEVERS	IDLE
10. Flight Controls	Check
11. Recall	Perform
12. ENG MFS	Press (Blank lower DU)

Taxi

1. Taxi Lights	ON
2. Parking Brake	Release
3. Thrust	Full, then Idle (check for any warnings, "Config" check)

Before Takeoff

1. Config **Checked, no warnings**
 2. Flaps **As Required**
 3. STAB TRIM **As Required**
 4. Takeoff Briefing **Performed**
 5. ATTEND **Press**
 6. RETRACTABLE & FIXED Landing Lights **ON**
 7. RWY TURNOFF Lights **ON**
-
- Once Cleared For Takeoff**
-
8. Position Lights **STROBE & STEADY**
 9. Auto Throttle **Arm**
 10. NAV Mode **LNAV or HDG, as Required**
 11. XPDR **Mode TA/RA**

Takeoff

1. ENG N1 **40%**
-
- Once Engines Stabilized**
-
2. TOGA **Push**
 3. Initial Pitch **20 Degrees**
 4. At 400ft AGL **Check LNAV engaged**
 5. A/P **As Required**
 6. Speed **Set to UP Position on Speed Tape**
 7. Flaps **Up According to Speed**

After Takeoff

1. ENG START SW **OFF**
2. GEAR LEVER **OFF Position**
3. AUTO BRAKE **OFF**

Climb

1. ALT INTV BTN to remove ALT CTRZ from FMC
2. Climb Modes VNAV / LVL CHG / VS
- Once Passing Transition Altitude

3. BARO QNE
- Once Passing FL100

4. Fuel Check balanced
5. Landing Lights Both RETRACTABLE and STATIC OFF
6. RWY TURNOFF Lights OFF
7. APU OFF
8. Pressurization Check
9. SEAT BELTS AUTO
10. Recall Perform
11. Bank Angle Selector Set to 10

Before Descent

1. Destination Weather **Obtained**
2. FMC > DES Page **Set SPD REST 250 / 10000**
3. FMC > DES > FORECAST Page
 - a. TRL **Enter**
 - b. ISA DEV / QNH **Enter**
 - c. DES WINDS **Request**
 - d. TAI (Thermal Anti-ICE) **Enter FL Clouds enter / exit (optional)**
 - e. EXEC
4. FIX Page **Draw visual helpers**
5. RTE Page **Check Correct Approach Loaded**
6. LEGS Page **Check Information Correct**
7. Approach Procedure **Setup**
 - a. NAV 1 & NAV 2 **Tune ILS Frequency**
 - b. COURSE L & R **Set Approach Track**
 - c. Landing Elevation **Confirm Set**
 - d. Minimums **Set**
8. FMC > INIT REF Page (APPROACH REF) **Enter Information**
 - a. GROSS WT **Set Landing Weight**
 - b. (Pred & CUR Fuel on FMC > PROG Page)
 - c. FLAP / SPD **Set Landing Configuration from Performance Tool**
9. Auto Brake **Set as Required**

Descent

1. ALT INTV Mode	Descent with 1000 fpm until calculated VNAV profile
Once Passing FL300	
2. Bank Angle Selector	Set to 25
Once Passing FL100	
3. Fuel	Check Balanced
4. Fuel Pumps	ON
5. RWY TURNOFF Lights	ON
6. FIXED Landing Lights	ON
7. Angular Bank	Confirm 25 Degrees
8. Pressurization	Check
9. Seat Belts	ON
10. Recall	Perform
Once Passing Transition Level	
11. Baro	Set Local QNH
Once Passing 10 DME RWY Threshold	
12. Flaps	1 or 5, as Required
Once Passing 5 DME RWY Threshold	
13. Gear	Down
14. Flaps	15

ILS Approach

1. Baro	Local QNH
2. VSD	Enable (Push Twice EFIS CTR Button)
3. APP Mode	Arm
On Intercepting GS	
4. Flaps	5
5. HDG	RWY Heading
Once GS Captured	
6. ALT	Set Missed Approach Altitude
Once Cleared To Land	
7. RETRACTABLE Landing Lights	ON

RNAV Approach

1. GPA in FMC **Confirm within 0.1 degrees of GPA in charts**
2. MDA **Set according to approach type**
 - a. B737 needs 40ft to climb in TOGA mode
3. Baro **Local QNH**
 - a. VSD **Check RWY symbol exactly on terrain**
4. MCP **Confirm LNAV & VNAV modes engaged**

When 2 NM inbound FAF
5. MCP ALT **Set down to minimum**
6. VNAV PTH **Verify Engaged**
7. SPD INTV **Press to open speed window**

When Passing FAF
8. Altitude at FAF **Check max deviation of 75 ft**
9. FMC > PROG Page 4 **Verify Lateral Deviations**
 - a. RNP Approach **0.3 NM**
 - b. XTK Error **0.15 NM**

If no RW waypoint in FMC
 - c. FD **OFF**

Landing

1. ENG START SW **CONT**
2. Recall **Check**
3. Speed Brake **ARMED & Green Lights**
4. Landing Gear **DOWN & Green Lights**
5. Auto Brake **Check As Required**
6. Flaps **Check as Required**
7. Landing Lights **ON**
8. TAXI Lights **ON**

After Landing

1. Strobes	STEADY
2. XPDR	ALT OFF
3. Flaps	UP
4. Speed Brake	OFF
5. TRIM	5
6. Auto Brake	OFF
7. MFD SW	Push ENG (Lower DU shows ENG Page)
8. FD	OFF
9. MCP SPD	Set 100
10. MCP ALT	Set 3100
11. ENG START SW	OFF
12. PROBE HEAT SW	AUTO
13. Landing Lights	OFF
14. TAXI Lights	Check ON
15. Weather Radar	OFF
16. APU	Start

Parking

1. Parking Brake	Set
2. Lights	OFF
Once APU Power Available	
3. APU GEN	ON
4. Engines	Off
Once N2 Of Both Engines < 20%	
5. Anti-Collision Light	OFF

Shutdown

1. Fuel Pumps	OFF
2. Seat Belts	OFF
3. Window Heats	OFF
4. Probe Heat	AUTO / OFF
5. Anti-Ice	OFF
6. HYD ELEC Pumps	OFF
7. Voice Recorder	OFF
8. PACKS	AUTO
9. ENG Bleeds	ON
10. APU Bleed	OFF
11. ENG START SW	OFF
12. Auto Brake	OFF
13. Speed Brake	DOWN
14. Flaps	UP
15. ENG START LEVER	CUTOFF
16. XPDR	2000 & STBY

Securing

1. APU	OFF
Once 2 Minutes Passed	
2. IRS Mode Selectors	OFF
3. CAB / UTIL	OFF
4. EMER EXIT Lights	OFF
5. PACKS	OFF
6. TRIM AIR	AUTO / OFF
7. BAT	OFF