README.md 2023-12-21

# Sign Extend

```
iverilog -o tb_SignExtend/tb tb_SignExtend/tb_SignExtend.v SignExtend.v
vvp tb_SignExtend/tb


# open gtkwave to view the waveform
gtkwave tb_SignExtend/tb_sign_extend.vcd &
```

# Benchmark (verifying the correctness)

## Shell output

```
junweiwang@Juns-MacBook-Pro-4 project % iverilog -o SignExtend_tb/tb SignExtend_tb/SignExtend_tb.v SignExtend.v
junweiwang@Juns-MacBook-Pro-4 project % vvp SignExtend_tb/tb
VCD info: dumpfile tb_sign_extend.vcd opened for output.
                         At time
At time
                    100000, inst15_0 =
                                      0001
                                           (hex),
                                                           Extend32 = 00000001
                                                                              (hex)
At time
                    110000, inst15_0 =
                                           (hex), SEXT = 0,
                                                           Extend32 =
                                                                     00007fff
                                                                              (hex)
                    120000, inst15_0 =
At time
                                      8000
                                           (hex), SEXT = 1, Extend32 =
                                                                     ffff8000
At time
                    130000, inst15_0
                                      ffff
                                           (hex), SEXT = 1,
                                                           Extend32
                                                                              (hex)
                                           (hex), SEXT = 1, Extend32 = fffff000
                    140000, inst15_0 =
                                      f000
At time
                                                                              (hex)
                                           (hex), SEXT = 0,
                    150000, inst15_0 = ffff
                                                           Extend32 = 0000ffff (hex)
At time
SignExtend_tb/SignExtend_tb.v:55: $finish called at
                                                160000 (1ps)
```

#### Waveform



## **Documentation**

#### Module Declaration:

```
module SignExtend (inst15_0, SEXT, Extend32);
```

README.md 2023-12-21

This line declares the module's name SignExtend and specifies its interface, which consists of one 16-bit input (inst15\_0), one control input (SEXT), and one 32-bit output (Extend32).

#### Port Definitions:

- input [15:0] inst15\_0;: A 16-bit input vector that represents the value to be extended.
- input SEXT;: A single-bit input signal that determines the mode of extension. When SEXT is high (logic 1), the module performs sign extension; when SEXT is low (logic 0), the module performs zero extension.
- output reg [31:0] Extend32;: A 32-bit register output vector that holds the extended result of inst15 0.

#### **Procedural Block:**

```
always @(inst15_0 or SEXT) begin
   if (SEXT) begin
        // Sign extension logic
        Extend32[31:16] <= {16{inst15_0[15]}};
        Extend32[15:0] <= inst15_0;
end else begin
        // Zero extension logic
        Extend32[31:16] <= 16'h0000;
        Extend32[15:0] <= inst15_0;
end
end</pre>
```

- always @(inst15\_0 or SEXT) begin ... end: An always block that is sensitive to changes in either inst15\_0 or SEXT. Whenever a change is detected in these signals, the code within the block will execute.
- if (SEXT) begin ... end else begin ... end: A conditional statement within the always block that checks the value of SEXT. Depending on the value of SEXT, it performs one of two actions:
  - Sign Extension: If SEXT is high, the module replicates the sign bit (bit 15) of inst15\_0 across the upper 16 bits of Extend32. This preserves the sign of the input value when extended to 32 bits, which is essential for representing negative numbers correctly in two's complement notation.
  - Zero Extension: If SEXT is low, the module sets the upper 16 bits of Extend32 to 0. This
    effectively pads the input value with zeros, which is used for unsigned numbers where the sign
    does not need to be preserved.

#### Overall Functionality:

The SignExtend module takes a 16-bit input and extends it to a 32-bit output based on the mode selected by SEXT. Sign extension is used to preserve the sign of signed numbers when converting them to a larger bit width, while zero extension is used when the input is considered an unsigned number. This module is

README.md 2023-12-21

commonly used in instruction decoding stages of processors, where immediate values from instructions need to be extended to the processor's word size.

# Example Usage:

In a CPU architecture where instructions may contain 16-bit immediate values that need to be used in a 32-bit context, this module would be used to extend those immediate values appropriately, based on whether they are to be treated as signed or unsigned quantities.